



Continental is a US manufacturer of specialty tools, gages, and assemblies for military and other government agencies. We have over 4,000 active drawings of standard and special Military tools, and through the years, we've made over 10,000 different military end-use items. This list represents the most common NSN part numbers currently being supplied by Continental Tool to government agencies. Continental also manufactures large volume quantities of standard hand tools not found on this list, so be sure to inquire if we can help.

***To search, type Ctrl + F and enter the NSN (with dashes) you are looking for to determine if it is something we manufacture.
NOTE List may not be up to date, updates may take time to apply. Please inquire for more information

| National Stock Number (NSN) | Description | Continental Tool Part Number (CTM#) |
|-----------------------------|------------------------------|-------------------------------------|
| 5120-00-230-6373 | Handle Socket Wrench | 1 |
| 5110-00-131-4341 | REAMER,HAND | 2 |
| 5110-00-221-8133 | CHISEL,SIDE CUTTING | 4 |
| 5110-00-233-3883 | PUNCH,DIMPLING | 7 |
| 5110-00-293-0325 | DRILL,MASONRY,HAND | 9 |
| 5120-00-959-7634 | HANDLING TOOL | 10 |
| 5120-00-953-9664 | Driver Camshaft Bushing | 11 |
| 5120-00-106-7837 | Wrench Assembly | 12 |
| 5120-00-978-0805 | BUSHING MANDREL | 13 |
| 5120-00-099-8544 | Handle Socket Wrench | 14 |
| 5120-00-901-8651 | Compressor Piston Ring | 18 |
| 5120-00-511-1609 | Tip Tube & Ferrule Pulling | 19 |
| 5110-00-293-0363 | PUNCH,DIMPLING | 20 |
| 5130-00-177-6893 | Socket Wrench | 23 |
| 5120-00-759-5052 | Puller | 25 |
| 5120-00-795-0700 | Replacer | 28 |
| 5110-00-294-4474 | REAMER,HAND | 29 |
| 5110-00-294-4603 | REAMER,HAND | 30 |
| 5120-00-967-3059 | WRENCH SOCKET | 31 |
| 5120-01-088-0065 | Extractor Seat Ring | 32 |
| 5120-00-870-6920 | Bolt Replacer | 33 |
| 5120-00-832-9025 | Wrench Socket | 36 |
| 5120-00-788-9207 | Wrench | 38 |
| 5110-00-308-3782 | CUTTER,ASBESTOS CEM | 39 |
| 5120-00-984-6419 | WRENCH | 45 |
| 5120-00-708-2980 | Replacer Bearing | 46 |
| 5120-00-601-2227 | Puller Mechanical | 48 |
| 5120-00-824-5984 | Puller Mechanical | 49 |
| 5120-00-320-7595 | Expander | 52 |
| 5120-00-568-0891 | Wrench Spanner | 53 |
| 5120-01-015-2159 | EXTRACTOR SEAT RING | 54 |
| 5120-00-592-3368 | Puller Mechanical | 55 |
| 5130-00-600-1800 | Puller Mechanical | 56 |
| 5120-00-795-0619 | Lifter Road Wheel | 59 |
| 5120-00-470-0122 | Crowfoot Attachment | 61 |
| 5120-00-116-7991 | Wrench | 62 |
| 5120-00-169-7783 | Wrench Box | 63 |
| 5120-00-906-6379 | Socket Wrench | 67 |
| 5120-00-224-9809 | Dresser Lead Pipe | 68 |
| 5120-01-035-3350 | WRENCH BOX | 69 |
| 5120-01-004-2684 | LIFTING TOOL | 70 |
| 5120-00-967-3058 | WRENCH SOCKET | 71 |
| 5120-01-034-2626 | EXTRACTOR RING | 72 |
| 5120-00-596-4472 | Socket Wrench Face | 73 |
| 5120-00-778-6115 | Driver Seal | 74 |
| 5120-00-999-1207 | COMPRESSOR VALVE SPRING | 75 |
| 5120-00-994-3803 | WRENCH PULLER | 77 |
| 5120-00-301-1216 | Jack Screw Hand | 80 |
| 5120-00-089-1174 | Wrench Socket | 81 |
| 5120-00-133-3143 | Wrench Open End | 82 |
| 5120-00-821-3459 | Key Socket Head Screw | 83 |
| 5120-00-677-5728 | Wrench Spanner | 84 |
| 5120-01-035-5531 | ADAPTER TORQUE WRENCH | 85 |
| 5120-00-999-8515 | Wrench Socket | 86 |
| 5120-00-980-9283 | WRENCH SOCKET ASSEMBLY | 87 |
| 5110-00-596-1048 | CHISEL,BOILERMAKER' | 88 |
| 5120-00-217-0201 | WRENCH BEARING | 92 |
| 5120-00-118-4387 | Wrench Spanner | 93 |
| 5120-00-032-9441 | Puller Mechanical | 96 |
| 5120-00-727-4497 | Installing Tool Bearing Tool | 101 |
| 5120-00-541-0587 | Wrench Spanner | 102 |
| 5120-00-712-4975 | Wrench Spanner | 103 |
| 5110-00-316-4771 | RESEATING TOOL,AIR | 104 |
| 5120-00-399-4296 | Wrench Boss Sleeve | 105 |
| 5120-00-169-8133 | Wrench Spanner | 106 |
| 5120-00-330-0605 | Wrench Spanner | 107 |
| 5120-00-671-2117 | Extractor Seal | 109 |
| 5120-01-004-2681 | Release Tool Bowl Purifier | 112 |
| 5120-00-212-3376 | Wrench Generator | 115 |
| 5180-00-071-0736 | Tool Kit Cylinder | 116 |
| 5120-00-595-9183 | Wrench Spanner | 118 |
| 5120-00-060-2371 | Extension Socket Wrench | 121 |
| 5120-00-008-5675 | Compressor Seal | 122 |
| 5120-00-508-5544 | Key Socket Head Screw | 125 |
| 5120-00-965-9549 | ALIGNMENT TOOL ELECT. | 127 |
| 5120-00-473-7121 | Handle Remover | 130 |
| 5120-00-795-0946 | Socket Socket Wrench | 131 |
| 5120-00-575-7766 | Socket Socket Wrench | 132 |
| 5120-00-670-4372 | Dome Lifting Handle | 133 |
| 5120-00-884-6293 | Wrench Dome Cap | 134 |
| 5120-00-163-0174 | Wrench | 135 |
| 5120-00-789-0121 | Wrench | 140 |
| 5120-00-168-4775 | Clamp | 141 |
| 5120-00-067-8453 | Wrench Spanner | 143 |
| 5120-00-991-3166 | WRENCH SPANNER | 146 |
| 5120-00-610-4181 | Wrench Spanner | 147 |
| 5120-00-113-4941 | Wrenc Open End | 148 |
| 5120-00-628-4265 | Punch | 149 |
| 5120-00-545-6068 | Puller Mechancial | 151 |
| 5120-01-025-3237 | Socket Socket Wrench | 152 |
| 5120-00-142-7990 | Wrench Box | 154 |
| 5120-00-694-6455 | Wrench Spanner | 156 |
| 5120-00-064-4583 | Burnisher Contact | 159 |
| 5120-00-838-0197 | Key Socket Head Screw | 160 |
| 5120-00-835-9210 | Wrench Spanner | 162 |
| 5120-00-835-9209 | Wrench Spanner Bearing | 163 |
| 5120-00-629-5645 | Ram Lift Hydraulic | 165 |
| 5120-00-251-5046 | Mold Battery | 167 |
| 5120-01-058-7433 | TIM INJECTION | 168 |

| | | |
|------------------|-------------------------------|-----|
| 5120-00-720-1012 | Strainer Element | 170 |
| 5120-00-596-1355 | Wrench Spanner | 176 |
| 5120-00-131-9396 | Puller Mechanical | 178 |
| 5120-00-845-7916 | Tool Removal | 179 |
| 5120-00-837-2174 | Wrench Seat Ring | 180 |
| 5120-00-210-4940 | Wrench Socket Spanner | 181 |
| 5120-00-255-5516 | Socket Socket Wrench | 182 |
| 5120-00-177-9356 | Wrench Nut Transmission | 184 |
| 5120-00-169-2962 | Remover Valve Set | 185 |
| 5120-00-784-2878 | Wrench | 187 |
| 5120-00-521-0569 | Mechanical Linkage | 188 |
| 5120-00-277-3024 | WRENCH OPEN END | 189 |
| 5120-00-277-3025 | WRENCH OPEN END | 190 |
| 5120-00-715-8753 | Wrench Spanner | 191 |
| 5120-00-261-2825 | Socket Socket Wrench | 193 |
| 5110-00-399-5632 | RESEATING TOOL | 194 |
| 5120-00-261-2855 | Socket Socket Wrench | 195 |
| 5120-00-596-0923 | Socket Wrench Attachment | 196 |
| 5120-01-015-4015 | ADAPTER BEARING | 198 |
| 5120-00-203-9530 | Wrench Spanner | 201 |
| 5120-00-051-3668 | Crowfoot Attachment | 202 |
| 5120-00-704-3350 | Installing Tool | 203 |
| 5120-00-690-4327 | Tool Presetting Fla. | 204 |
| 5120-00-690-4328 | Tool Presetting Fla. | 205 |
| 5120-00-877-6841 | Rod Discharge | 206 |
| 5120-00-626-5122 | Puller Mechanical | 207 |
| 5120-00-189-8168 | Puller Chip Detector | 208 |
| 5120-00-770-7352 | Wrench Spanner | 209 |
| 5120-01-004-2682 | REMOVAL TOOL | 210 |
| 5120-00-125-4411 | Tool Oil Seal | 211 |
| 5130-00-837-6967 | Spacer Assembly Core | 212 |
| 5110-00-473-7294 | REAMER,HAND | 216 |
| 5120-00-566-3484 | Lifter Dome Assembly | 219 |
| 5120-00-987-5053 | Replacer | 220 |
| 5120-01-019-7743 | WRENCH SPANNER | 224 |
| 5120-00-860-5441 | Wrench Spanner | 226 |
| 5120-00-288-6488 | CROWFOOT ATTACH.SOCKET WRENCH | 227 |
| 5120-00-033-0786 | Wrench Spanner | 228 |
| 5120-00-610-5331 | Wrench Socket | 229 |
| 5120-00-084-6401 | Puller | 231 |
| 5120-00-095-3084 | Wrench Spanner | 233 |
| 5120-00-867-8148 | Wrench Spanner | 234 |
| 5120-00-277-3023 | WRENCH OPEN END | 238 |
| 5120-00-021-3190 | Punch Mechanical | 245 |
| 5120-00-586-0733 | Adapter Control Shaft | 246 |
| 5120-00-147-7869 | Wrench Box | 247 |
| 5120-00-032-4895 | Tamper Hand | 250 |
| 5120-00-026-8444 | Wrench, Spanner | 252 |
| 5120-00-033-5510 | Wrench Spanner | 253 |
| 5120-00-704-3770 | Puller Turbine Bearing | 254 |
| 5120-00-366-5065 | Installer Tool | 255 |
| 5120-00-169-2883 | Wrench Box | 257 |
| 5120-00-529-2724 | Mold Battery Terminal | 258 |
| 5120-00-317-8076 | Crowfoot Attachment Socket | 260 |
| 5120-00-177-6957 | Wrench Spanner | 261 |
| 5120-00-675-0845 | Wrench Spanner | 264 |
| 5120-00-494-1988 | Wrench Spanner | 265 |
| 5120-00-449-8159 | Wrench Open End | 266 |
| 5120-00-593-9332 | Wrench Spanner | 267 |
| 5120-00-293-1455 | Wrench Spanner | 268 |
| 5120-00-837-9483 | Spanner Wrench | 269 |
| 5120-00-540-6907 | Wrench Spanner | 270 |
| 5120-00-999-8619 | INSTALLER CRANKSHAFT | 273 |
| 5120-00-595-7366 | Punch Jewelers Stake | 274 |
| 5120-01-078-1921 | LAPPING TOOL SPECIAL | 275 |
| 5120-00-873-7502 | Wrench | 277 |
| 5120-00-017-7329 | Bearing Pusher | 279 |
| 5120-00-075-1048 | Puller Mechanical | 280 |
| 5120-00-071-9151 | Installer Bearing | 281 |
| 5120-00-138-3790 | Wrench Box | 282 |
| 5120-00-381-7052 | Dummy Shaft | 284 |
| 5120-00-092-8650 | Stem Release Valve | 285 |
| 5120-00-083-2834 | Puller Mechanical | 286 |
| 5120-00-907-9676 | Wrench Socket Key | 292 |
| 5120-00-028-0305 | Crowfoot Attachment | 294 |
| 5120-01-090-5859 | Puller Valve Poppet | 296 |
| 5120-00-116-7604 | Puller Injector Diesel Engine | 297 |
| 5120-00-016-3627 | Puller Mechanical | 298 |
| 5120-00-566-2845 | Puller Oil Seal | 299 |
| 5120-00-736-6315 | Puller Mechanical | 300 |
| 5120-00-948-3923 | Puller Pitch Beam | 301 |
| 5120-00-557-6543 | Wrench Open End | 302 |
| 5120-00-991-3174 | WRENCH SPANNER | 303 |
| 5120-00-670-4373 | Spanner Wrench | 304 |
| 5130-00-840-4872 | Adapter Impact Wire | 305 |
| 5120-00-484-9554 | Extractor Tool | 306 |
| 5120-00-056-6868 | Rod Driving | 307 |
| 5120-00-601-2228 | Wrench Box | 310 |
| 5120-00-148-7446 | Wrench Socket | 311 |
| 5120-00-953-3406 | | 312 |
| 5120-00-541-0589 | Wrench Spanner | 313 |
| 5120-00-675-2093 | Wrench Torque | 315 |
| 5120-00-891-7866 | Wrench Open End | 316 |
| 5120-00-704-3360 | Reactor Assembly Torque | 317 |
| 5120-00-980-2809 | SHAFT PROTECTOR | 318 |
| 5120-00-948-3945 | Wrench Assembly | 319 |
| 5120-00-876-2971 | Tool Adjusting | 321 |
| 5120-00-568-5122 | Wrench Flush Nut | 322 |
| 5130-00-608-4749 | Rivet Set Assort. | 324 |
| 5120-00-034-4858 | Handle Assembly | 326 |
| 5120-00-708-3302 | Wrench Plug | 327 |
| 5120-00-178-0941 | Socket Wrench | 330 |
| 5120-00-057-0768 | Wrench Open End | 332 |
| 5120-00-950-3425 | Wrench Open End Fixed | 333 |
| 5120-00-293-3488 | (Please Inquire) | 335 |
| 5120-00-679-1672 | Pliers Actuator | 337 |
| 5120-00-683-8610 | Compressor Piston Ring | 342 |
| 5120-00-839-0937 | Valve Tool | 343 |
| 5120-00-627-9311 | Wrench Spanner | 345 |
| 5120-00-595-9080 | Wrench | 346 |
| 5120-00-802-5558 | Wrench | 349 |
| 5120-00-058-8622 | Socket Socket Wrench | 350 |
| 5120-00-060-7596 | Adapter Socket Crowfoot | 352 |
| 5120-00-251-5045 | Mold Battery Terminal | 353 |
| 5120-00-044-1426 | Wrench Spanner | 354 |
| 5120-00-620-0473 | Wrench | 356 |

| | | |
|------------------|-------------------------------|-----|
| 5120-00-977-5578 | HANDLE INSTALLER | 358 |
| 5120-00-125-4402 | Driver Bearing & Bushing | 359 |
| 5120-00-261-2853 | SOCKET WRENCH | 360 |
| 5120-00-110-4541 | Tool Locking | 363 |
| 5210-00-708-0755 | GAGE | 365 |
| 5120-00-142-7673 | Puller Mechanical | 369 |
| 5120-00-628-1454 | Key Socket Head Screw | 370 |
| 5120-00-078-2888 | Driver Cam Seating | 371 |
| 5120-00-359-6460 | Bender | 372 |
| 5110-00-795-0248 | REAMER HAND | 374 |
| 5120-01-136-5853 | Jig Lapping Tool | 375 |
| 5120-00-323-1398 | Alignment Tool | 377 |
| 5120-01-036-3763 | PULLER ROD VALVE SEAL | 378 |
| 5120-00-106-7628 | Wrench Spanner | 379 |
| 5120-00-513-1754 | Spanner Attachment Set | 380 |
| 5120-00-235-5909 | Wrench Socket | 381 |
| 5120-00-251-1102 | Handle Socket Wrench | 382 |
| 5120-01-085-5567 | Key Socket Head Screw | 383 |
| 5120-00-075-1063 | Puller Pin | 385 |
| 5110-00-795-0124 | REAMER HAND | 386 |
| 5120-00-595-9026 | Wrench Open end | 387 |
| 5120-00-590-8030 | Alignment Tool | 389 |
| 5110-00-708-3696 | REAMER HAND | 390 |
| 5120-01-055-0019 | PLIERS | 392 |
| 5120-01-137-6064 | Remover & Replacer Assembly | 394 |
| 5120-00-596-1196 | Socket Wrench Face Spanner | 395 |
| 5120-00-117-4732 | Wrench Valve Stem | 396 |
| 5120-00-169-4816 | Pin Inserter | 398 |
| 5210-00-366-1422 | GAGE,ALIGNING | 399 |
| 5120-00-177-7341 | Key Socket Head Screw | 400 |
| 5120-00-441-2561 | Idler Bearing Placer | 401 |
| 5120-01-134-2334 | Tool Gland Ring | 402 |
| 5120-00-165-4075 | Adapter Torque | 403 |
| 5120-00-596-8652 | Spanner Attachment Set | 404 |
| 5120-00-081-9058 | Socket Wrench Attachment | 406 |
| 5120-01-004-2661 | Waveguide Assembly Wrench | 408 |
| 5120-00-049-7979 | Bar Spanner Wrench | 410 |
| 5120-00-104-1816 | Clamp Cylinder | 411 |
| 5120-00-525-6988 | 9999/99 Retaining | 412 |
| 5120-00-408-0343 | (Please Inquire) | 415 |
| 5120-00-383-0918 | (Please Inquire) | 417 |
| 5120-00-465-0694 | Tool Spring Compressor | 421 |
| 5120-00-970-1222 | WRENCH OPEN END | 422 |
| 5120-01-017-9521 | PACKING TOOL | 424 |
| 5120-00-537-8730 | Wrench Socket & Spanner Comb. | 425 |
| 5180-00-816-7455 | Tool Kit | 427 |
| 5120-00-561-0854 | Wrench Spanner | 429 |
| 5120-00-133-2577 | Cutter Valve Seat | 430 |
| 5120-00-034-2833 | Wrench Range Spring Adjuster | 432 |
| 5120-00-332-9378 | Puller Mechanical | 433 |
| 5120-00-540-6048 | Extractor | 434 |
| 5120-00-587-7036 | Socket Wrench Face | 435 |
| 5120-00-619-8554 | (Please Inquire) | 436 |
| 5120-00-880-4568 | Handle Punch | 439 |
| 5110-00-708-3697 | REAMER HAND | 441 |
| 5120-00-948-3943 | Tool Alignment | 442 |
| 5120-00-922-4928 | Key | 444 |
| 5120-01-134-8447 | Wrench Spline | 446 |
| 5120-00-075-1036 | Wrench Spanner | 447 |
| 5120-00-049-7949 | Wrench Open End | 448 |
| 5110-00-787-2613 | PUNCH | 449 |
| 5120-00-008-5655 | Wrench, Spanner | 450 |
| 5120-00-999-6172 | WRENCH | 453 |
| 5120-00-962-0152 | WRENCH RATCHET CROWFOOT | 455 |
| 5120-01-107-8351 | Pin Alignment | 458 |
| 5120-00-977-5579 | INSTALLER SEAL | 459 |
| 5120-00-113-5271 | Impact Injector Sleeve Puller | 460 |
| 5120-00-177-6845 | Wrench | 461 |
| 5120-00-629-5643 | Piston Hydraulic | 465 |
| 5120-00-804-7769 | Wrench Spanner | 466 |
| 5120-00-288-8709 | Wrench Open End | 467 |
| 5120-00-162-2813 | Clamp Assembly Spring | 469 |
| 5120-00-289-8211 | Wrench Open End | 470 |
| 5120-00-235-4670 | Wrench Spanner | 471 |
| 5120-00-116-7985 | Wrench Socket | 472 |
| 5120-00-955-1728 | Pin Straightener | 473 |
| 5120-00-132-5012 | Removal Tool | 474 |
| 5110-00-220-9558 | PUNCH,DIMPLING | 477 |
| 5120-00-891-5166 | Wrench Spanner | 478 |
| 5120-00-891-5167 | Wrench Spanner | 479 |
| 5120-01-121-4981 | Socket Wrench Attachment | 480 |
| 5120-00-317-9502 | Wrench Box Atomizer | 481 |
| 5120-01-032-7442 | Puller Seat Brass | 482 |
| 5120-00-404-9788 | Puller Mechanical | 483 |
| 5120-00-442-2275 | Wrench Spanner | 485 |
| 5120-00-614-8022 | Adjusting Tool | 487 |
| 5120-00-317-7925 | Crimping Tool Ferrule | 490 |
| 5120-01-181-5533 | Wrench Spanner | 492 |
| 5120-00-529-3074 | Wrench Spanner | 494 |
| 5120-01-067-2133 | SOCKET SOCKET WRENCH | 496 |
| 5120-01-064-3318 | SOCKET WRENCH ATTACHMENT | 497 |
| 5120-00-976-3105 | Wrench Socket | 501 |
| 5120-00-880-4574 | Punch Drive Pin | 503 |
| 5120-00-288-6551 | WRENCH OPEN END | 504 |
| 5120-00-293-1776 | Wrench Open End | 505 |
| 5120-00-981-7520 | WRENCH COMPRESSOR | 506 |
| 5120-00-932-9898 | Key Socket Head Screw | 509 |
| 5120-00-825-2729 | Wrench Open End | 510 |
| 5120-00-906-6377 | Socket Wrench | 511 |
| 5120-00-212-6284 | Wrench Open End | 513 |
| 5120-00-612-9876 | Tool Assembly | 514 |
| 5120-00-529-5121 | Wrench Double Head Open End | 515 |
| 5120-00-117-3429 | Wrench Spanner | 516 |
| 5120-00-924-7756 | Flap Stop | 517 |
| 5120-00-981-3108 | Driver | 518 |
| 5120-00-550-7360 | Wrench Spanner | 519 |
| 5120-00-706-6588 | Puller, Mechanical | 520 |
| 5120-00-587-1624 | WRENCH | 523 |
| 5120-00-293-1784 | Double End Opening | 524 |
| 5110-00-019-4350 | PIN STRAIGHTENER AN | 527 |
| 5120-00-293-0142 | Wrench Socket | 528 |
| 5120-00-224-2518 | Key Socket Head Screw | 529 |
| 5120-00-618-7870 | Socket Wrench Attachment | 530 |
| 5120-01-137-8403 | Socket Socket Wrench | 531 |
| 5120-00-714-2928 | Extractor Seal | 532 |
| 5110-00-061-6327 | REAMER HAND | 533 |

| | | |
|------------------|---------------------------------------|-----|
| 5180-00-010-5182 | Adapter Kit Torque Wrench | 534 |
| 5120-00-152-2418 | Wrench Spanner | 535 |
| 5120-01-177-9662 | Installation & Removal Tool | 537 |
| 5120-00-708-3384 | Puller Mechanical | 538 |
| 5110-00-873-8779 | TUBE PLUG SEAT REAMER | 539 |
| 5120-00-309-0494 | Adjuster Spring | 540 |
| 5120-00-277-3022 | (Please Inquire) | 543 |
| 5120-00-066-0752 | Compressing Tool | 544 |
| 5120-00-962-2280 | STAKING TOOL BEARING | 545 |
| 5110-00-795-0165 | REFACER WATER PUMP | 546 |
| 5120-00-348-7504 | Wrench Open End Fixed | 549 |
| 5120-00-033-0619 | Wrench, Valve Body | 552 |
| 5120-01-177-4938 | (Please Inquire) | 553 |
| 5120-00-807-9103 | Compressing Tool | 555 |
| 5120-00-255-5519 | (Please Inquire) | 556 |
| 5120-00-349-3810 | (Please Inquire) | 557 |
| 5110-00-837-9376 | RIVETING PUNCH TURBINE | 563 |
| 5110-00-837-9381 | PUNCH | 564 |
| 5110-00-837-9388 | RIVETING PUNCH TURBINE | 565 |
| 5110-00-837-9390 | RIVETING PUNCH TURBINE | 566 |
| 5110-00-980-7347 | REAMER | 567 |
| 5110-00-981-3106 | CUTTER BALL SEAT | 568 |
| 5110-00-981-3107 | REAMER FIXTURE | 569 |
| 5110-00-992-4701 | STRIPPER CABLE HAND | 570 |
| 5110-01-050-2240 | HAND REAMER VALVE GUIDE | 571 |
| 5110-01-071-5351 | SCRAPER FLOOR | 572 |
| 5120-00-NS8-0226 | Alignment Tool Special | 573 |
| 5120-00-001-9956 | Driver Plug Bearing | 575 |
| 5120-00-006-4690 | Special Alignment Tool | 576 |
| 5120-00-008-5593 | Expander Piston Rod Seals | 577 |
| 5120-00-008-5595 | Expander Piston Seal | 578 |
| 5120-00-008-5676 | Freeze Tool Piston | 579 |
| 5120-00-011-0543 | Adapter Bearing Press | 581 |
| 5120-00-013-7117 | Alignment Tool | 582 |
| 5120-00-013-7559 | Gage Height | 583 |
| 5120-00-014-1521 | Adapter Torque Wrench | 584 |
| 5120-00-014-1522 | Adapter Torque | 585 |
| 5120-00-014-2902 | Seal Installer | 586 |
| 5120-00-016-4347 | KNOB TOOL ADJUSTING (TOO BIG TO SCAN) | 587 |
| 5120-00-017-6081 | Wrench Open End | 588 |
| 5120-00-017-9204 | Wrench Single Open End | 590 |
| 5120-00-018-1519 | Spanner Wrench | 591 |
| 5120-00-018-9767 | Wrench Adapter | 594 |
| 5120-00-019-2036 | Compressor | 595 |
| 5120-00-019-5233 | Handle Remover Replacer | 597 |
| 5120-00-019-7090 | Card Puller | 598 |
| 5120-00-020-5926 | Extractor Electrical Contact | 602 |
| 5120-00-020-8661 | Wrench Pyrogen Unit | 603 |
| 5120-00-022-2815 | Wrench Alternator | 604 |
| 5120-00-022-7858 | Wrench | 605 |
| 5120-00-023-2263 | DRIFT | 606 |
| 5120-00-024-7332 | Socket Socket Wrench | 607 |
| 5120-00-025-0702 | Large Adjustable Spanner Assm. | 608 |
| 5120-00-025-0704 | Pin Spanner | 609 |
| 5120-00-025-0705 | Pin Spanner | 610 |
| 5120-00-025-0710 | Pin Spanner | 612 |
| 5120-00-025-2274 | Handle Extractor Lamp | 613 |
| 5120-00-027-3339 | Removal Tool | 614 |
| 5120-00-028-4992 | Earth-digging Bar | 615 |
| 5120-00-028-4997 | Remover Set | 616 |
| 5120-00-032-9444 | Wrench | 617 |
| 5120-00-032-9452 | Expander | 618 |
| 5120-00-032-9579 | Wrench Compressor Adjusting | 619 |
| 5120-00-032-9600 | Puller | 620 |
| 5120-00-033-0738 | Adapter | 621 |
| 5120-00-033-0858 | Compressor | 622 |
| 5120-00-033-2637 | Wrench | 623 |
| 5120-00-033-2682 | Wrench | 624 |
| 5120-00-033-7607 | Pliers Slip Joint | 625 |
| 5120-00-034-0878 | Replacer | 626 |
| 5120-00-034-0881 | Replacer | 627 |
| 5120-00-034-1002 | Bit Screwdriver | 628 |
| 5120-00-034-4861 | Wrench | 629 |
| 5120-00-034-4863 | Wrench Ratchet | 630 |
| 5120-00-034-7550 | Relief Valve | 631 |
| 5120-00-034-8078 | Wrench Assembly | 633 |
| 5120-00-035-7710 | Adjuster Spring | 634 |
| 5120-00-036-4736 | Clamp Wrench | 635 |
| 5120-00-037-0216 | Adapter | 636 |
| 5120-00-037-0232 | Torque Adapter | 637 |
| 5120-00-037-0243 | Adapter | 638 |
| 5120-00-037-0363 | Adapter | 639 |
| 5120-00-037-4999 | Puller Oil Pump Gears | 640 |
| 5120-00-038-7988 | Wrench Spanner | 641 |
| 5120-00-043-0103 | Clamp Assembly Bearing | 642 |
| 5120-00-043-0130 | Jackscrew Inlet | 643 |
| 5120-00-043-3989 | Bar Socket Wrench | 644 |
| 5120-00-050-6359 | Puller Oil Seal | 645 |
| 5120-00-053-3625 | Wrench Plug | 648 |
| 5120-00-055-9834 | Tube Extractor | 649 |
| 5120-00-060-6844 | Wrench Assembly | 653 |
| 5120-00-063-7992 | Wrench Box | 655 |
| 5120-00-064-6208 | Wrench Spanner | 656 |
| 5120-00-065-2761 | Extractor | 657 |
| 5120-00-068-8677 | Instalation & Removal Tool | 660 |
| 5120-00-069-6264 | Tool Adj | 661 |
| 5120-00-069-6313 | Fittings Variable | 662 |
| 5120-00-070-1295 | Gland Wrench | 663 |
| 5120-00-070-8256 | Jack Screw | 665 |
| 5120-00-072-1544 | Wrench | 666 |
| 5120-00-072-4451 | Puller Mechanical | 667 |
| 5120-00-072-5208 | Wrench Friction | 668 |
| 5120-00-072-5209 | Wrench Assembly | 669 |
| 5120-00-072-5212 | Wrench Friction | 670 |
| 5120-00-072-5213 | Wrench Friction | 671 |
| 5120-00-072-5327 | Wrench Spanner | 672 |
| 5120-00-072-5332 | Wrench T | 673 |
| 5120-00-072-5333 | Wrench Spanner | 674 |
| 5120-00-072-5361 | Strap Wrench Assembly | 675 |
| 5120-00-072-7107 | Puller | 676 |
| 5120-00-073-5675 | Adapter | 678 |
| 5120-00-074-0721 | Puller | 679 |
| 5120-00-074-1701 | Puller Bolt | 680 |
| 5120-00-075-1047 | Drift Assembly | 681 |
| 5120-00-075-1053 | Drift Assembly | 682 |
| 5120-00-075-1324 | Applicators Retaining Ring | 686 |

| | | |
|------------------|--------------------------------|-----|
| 5120-00-076-2175 | Tool Compression | 687 |
| 5120-00-076-4378 | Jack Screw Set | 688 |
| 5120-00-076-4380 | Wrench | 689 |
| 5120-00-077-1817 | Installation Tool | 691 |
| 5120-00-077-2704 | Wrench Assembly | 693 |
| 5120-00-078-2274 | Tool Conector Assembly | 695 |
| 5120-00-078-2433 | Key | 697 |
| 5120-00-078-2895 | Installing Tool | 698 |
| 5120-00-081-7343 | Key Socket Head Screw | 702 |
| 5120-00-081-9082 | Wrench Open End | 703 |
| 5120-00-081-9104 | Wrench Open End | 705 |
| 5120-00-083-7384 | Wrench Spanner | 706 |
| 5120-00-086-4263 | Header Assembly | 708 |
| 5120-00-087-2034 | Special Tool | 709 |
| 5120-00-087-2902 | Cutter Paper | 710 |
| 5120-00-087-2969 | Wrench Vent Plug | 711 |
| 5120-00-088-4009 | Knurl Tite Wrench | 714 |
| 5120-00-088-5785 | Driver Lens Clamp | 715 |
| 5120-00-088-6772 | Probe Bushing | 716 |
| 5120-00-088-6872 | Spin Staking Tool | 717 |
| 5120-00-088-8058 | Driver Hex Shank | 718 |
| 5120-00-089-4567 | Socket Socket Wrench | 720 |
| 5120-00-089-5519 | Key Socket Head Screw | 721 |
| 5120-00-089-7804 | Wrench | 723 |
| 5120-00-090-0885 | Wrench Spanner | 724 |
| 5120-00-090-4412 | Tool Fastener | 725 |
| 5120-00-090-9693 | Wrench | 726 |
| 5120-00-091-3149 | Kit | 727 |
| 5120-00-092-1515 | Extract Bearing | 728 |
| 5120-00-092-8652 | Guide Spring | 729 |
| 5120-00-094-1293 | Wrench Torque Adapter | 730 |
| 5120-00-094-1294 | Crowfoot Attachment | 731 |
| 5120-00-094-1305 | Wrench Box | 732 |
| 5120-00-094-1342 | Protractor Pendulum | 733 |
| 5120-00-094-3813 | Hammer Puller Pusher Knocker | 734 |
| 5120-00-094-3914 | Wrench | 735 |
| 5120-00-095-2740 | Wrench | 736 |
| 5120-00-095-2830 | Wrench | 738 |
| 5120-00-095-2834 | Adapter Extension Socket | 740 |
| 5120-00-095-2960 | Wrench Socket | 741 |
| 5120-00-095-2962 | DRIVE DOG | 742 |
| 5120-00-095-3041 | Wrench Cylinder Nut | 743 |
| 5120-00-095-3068 | Compressor Valve | 744 |
| 5120-00-095-3127 | Wrench | 745 |
| 5120-00-095-3147 | Wrench | 746 |
| 5120-00-095-6709 | Wrench Spanner | 747 |
| 5120-00-096-3227 | Key Socket Head Screw | 748 |
| 5120-00-096-3236 | Wrench | 749 |
| 5120-00-098-4326 | Knife | 750 |
| 5120-00-098-4366 | Wrench Servo Piston | 751 |
| 5120-00-098-4382 | Puller | 752 |
| 5120-00-103-2868 | Tool Gear Aligning | 753 |
| 5120-00-103-4685 | SSN Oxygen Generator Special | 754 |
| 5120-00-103-4686 | Wrench Blade | 755 |
| 5120-00-104-1782 | Alignment Tool | 756 |
| 5120-00-104-1795 | Holding Tool Injector | 757 |
| 5120-00-104-1835 | Removal Tool | 758 |
| 5120-00-104-1963 | Ball Bearing Removing Collar | 759 |
| 5120-00-104-4124 | Key Socket Head Screw | 760 |
| 5120-00-104-4128 | Handle Adjustable Spanner Wr. | 761 |
| 5120-00-104-6765 | Drift | 762 |
| 5120-00-104-9025 | Fixture Riveting | 763 |
| 5120-00-106-7835 | Washer | 764 |
| 5120-00-108-5319 | Adjuster Tool For Relay Spring | 765 |
| 5120-00-108-5351 | Ring Adapter | 766 |
| 5120-00-110-4568 | Insenter Screw Thread | 767 |
| 5120-00-112-9241 | Spanner Wrench | 768 |
| 5120-00-113-3167 | Torque Wrench | 769 |
| 5120-00-113-3899 | Extractor | 770 |
| 5120-00-113-4244 | Puller | 771 |
| 5120-00-113-4929 | Wrench | 772 |
| 5120-00-113-5265 | Removal Tool | 773 |
| 5120-00-113-5753 | Press Tube | 774 |
| 5120-00-115-0688 | Gage | 775 |
| 5120-00-115-6795 | Spanner Wrench | 776 |
| 5120-00-116-2880 | Wrench Inlet Impellar | 777 |
| 5120-00-116-6812 | Wrench | 778 |
| 5120-00-116-7333 | Blade | 779 |
| 5120-00-116-7365 | Extractor Lamp | 780 |
| 5120-00-116-7601 | SUPPORT BRIDGE, MECH | 781 |
| 5120-00-116-8312 | Staking Tool Roll | 782 |
| 5120-00-116-8381 | Alignment Tool | 783 |
| 5120-00-116-9016 | Nut Support | 785 |
| 5120-00-116-9321 | Pliers | 788 |
| 5120-00-116-9352 | Extractor Printed Board | 789 |
| 5120-00-117-2342 | Rigging Pin Assembly | 792 |
| 5120-00-117-2958 | Extractor P.C. Card | 793 |
| 5120-00-117-3601 | Bearing Locknut Wrench Adapter | 794 |
| 5120-00-117-4367 | Expander Flexible | 795 |
| 5120-00-117-4549 | Expander Flexible T | 796 |
| 5120-00-117-6821 | Double-end Type Wrench | 797 |
| 5120-00-124-3873 | Extraction Tool | 799 |
| 5120-00-124-7373 | Wrench Assembly Spanner Nut | 800 |
| 5120-00-124-8959 | Bearing Tool Assembly | 801 |
| 5120-00-124-8960 | Bearing Tool Assembly | 802 |
| 5120-00-125-4404 | 883 TOOL | 803 |
| 5120-00-126-0051 | Tool Assembly | 804 |
| 5120-00-126-3475 | Clamp Gear | 805 |
| 5120-00-127-6693 | Pusher Bearing | 807 |
| 5120-00-127-7920 | Hammer Hand | 808 |
| 5120-00-127-7937 | Grip Cable Woven | 809 |
| 5120-00-128-7942 | Hook Drawband | 810 |
| 5120-00-131-8968 | Wrench Spanner | 811 |
| 5120-00-132-0939 | Wrench Set Spanner Airtube | 812 |
| 5120-00-132-1027 | Switch Setting Tool | 813 |
| 5120-00-132-2219 | Trash Disposal Unit Linkage | 815 |
| 5120-00-132-2289 | Wrench Torque | 816 |
| 5120-00-132-5024 | Installing Tool | 817 |
| 5120-00-133-1109 | Extractor Electron Tube | 818 |
| 5120-00-133-1429 | Extractor Tool Filter | 822 |
| 5120-00-133-1591 | Wrench Spanner | 824 |
| 5120-00-133-1594 | Adjusting Tool Valve | 825 |
| 5120-00-133-1706 | Handle Spanner Wrench | 826 |
| 5120-00-133-1713 | Hull & Back-up Valve | 827 |
| 5120-00-133-1719 | Torque Adapter | 828 |
| 5120-00-133-1741 | Ball Valve Tool | 829 |

| | | |
|------------------|-------------------------------|------|
| 5120-00-133-1742 | Ball Valve | 830 |
| 5120-00-133-1743 | Wrench Spanner | 831 |
| 5120-00-133-2072 | Tool Connector Assembly | 835 |
| 5120-00-133-2144 | Wrench Socket | 836 |
| 5120-00-133-2156 | Puller Card | 837 |
| 5120-00-133-3039 | Spreader Spring | 838 |
| 5120-00-133-3577 | Stake Driver Manual Tool Kit | 840 |
| 5120-00-133-3928 | Oil Seal Insert Tool | 841 |
| 5120-00-134-1136 | Tool Die Plate Removal | 842 |
| 5120-00-134-1138 | Torque Arm Assembly | 843 |
| 5120-00-134-4594 | Extension Pitch Horn Stud | 844 |
| 5120-00-134-4597 | Puller Cable Installer | 845 |
| 5120-00-134-4725 | Handle | 846 |
| 5120-00-134-7763 | Dial Wrench | 848 |
| 5120-00-135-4926 | Tool Loading | 849 |
| 5120-00-136-2595 | Spreader Outer | 850 |
| 5120-00-136-2596 | Squeezer | 851 |
| 5120-00-142-3248 | Socket Wrench | 853 |
| 5120-00-142-3361 | Wrench | 854 |
| 5120-00-142-3446 | Wrench | 855 |
| 5120-00-142-3778 | Puller Mechanical | 856 |
| 5120-00-142-3803 | Wrench Box | 857 |
| 5120-00-142-5284 | Wrench Ratchet Reversible | 859 |
| 5120-00-142-6775 | Wrench Spanner | 863 |
| 5120-00-142-6819 | Drift Valve Guide Assembly | 865 |
| 5120-00-143-7608 | Paddle Parachute Packing | 872 |
| 5120-00-143-7934 | Crowfoot Attachment | 873 |
| 5120-00-143-7951 | "Removing Tool Stud" | 874 |
| 5120-00-143-7954 | "Removing Tool Stud" | 875 |
| 5120-00-143-7955 | Removing Tool | 876 |
| 5120-00-143-8124 | "Wrench Crowfoot" | 877 |
| 5120-00-143-8206 | Depressor Valve | 878 |
| 5120-00-144-2098 | "Die Eyelet" | 879 |
| 5120-00-144-2578 | "Adapter Stud" | 881 |
| 5120-00-144-2579 | Adapter Stud | 882 |
| 5120-00-144-5045 | Wrench | 883 |
| 5120-00-144-5049 | Wrench | 884 |
| 5120-00-144-5144 | Puller Mechanical | 885 |
| 5120-00-144-5430 | Boring Bar | 886 |
| 5120-00-144-5471 | Adapter Wrench | 887 |
| 5120-00-144-5831 | Plug & Collar | 888 |
| 5120-00-144-5996 | Installing Tool | 889 |
| 5120-00-147-7812 | Wrench Injection Pump | 891 |
| 5120-00-147-7844 | Clamp Tool | 893 |
| 5120-00-147-7874 | Tool Assembly | 895 |
| 5120-00-148-1165 | Anvil Riveter | 896 |
| 5120-00-148-7506 | Drift | 897 |
| 5120-00-150-5966 | Tool Pin Insertion Extraction | 901 |
| 5120-00-150-7346 | Installing Tool | 903 |
| 5120-00-150-7698 | Tool Bearing Remover | 906 |
| 5120-00-150-7700 | Tool | 907 |
| 5120-00-152-1830 | Bearing Pusher | 914 |
| 5120-00-152-1976 | Pusher | 915 |
| 5120-00-152-1977 | Pusher Bearing | 916 |
| 5120-00-152-1999 | Bit Screwdriver | 919 |
| 5120-00-152-2013 | Assembly | 921 |
| 5120-00-152-2462 | Installing Tool | 926 |
| 5120-00-169-2885 | (Please Inquire) | 969 |
| 5120-00-169-4813 | Spanner Wrench | 971 |
| 5120-00-169-4814 | Socket Socket Wrench | 972 |
| 5120-00-169-7593 | Slide Hammer | 974 |
| 5120-00-174-8545 | Alignment Tool | 979 |
| 5120-00-176-3291 | (Please Inquire) | 980 |
| 5120-00-176-9201 | Driver Bearing Valve | 991 |
| 5120-00-177-9398 | Staking Tool Drag T | 1012 |
| 5120-00-177-9403 | Tab Bender Rotor | 1013 |
| 5120-00-177-9412 | Wrench Spline | 1015 |
| 5120-00-178-1249 | Pliers Dorsal Connector | 1018 |
| 5120-00-180-0800 | Screwdriver Offset | 1020 |
| 5120-00-180-0904 | Clamp | 1022 |
| 5120-00-180-1011 | Socket Hexagon | 1023 |
| 5120-00-184-8566 | Wrench | 1038 |
| 5120-00-184-8576 | Wrench Open end | 1046 |
| 5120-00-184-8652 | Wrench Angle Double Head | 1050 |
| 5120-00-212-1539 | Head Puller Oil Seal | 1063 |
| 5120-00-212-2334 | Puller & Pusher | 1077 |
| 5120-00-212-2893 | Adapter Assembly Torque Wrenc | 1082 |
| 5120-00-212-4080 | Roller | 1084 |
| 5120-00-212-4700 | Wrench Assembly | 1086 |
| 5120-00-215-1882 | Wrench spanner adj. | 1093 |
| 5120-00-218-5944 | (Please Inquire) | 1097 |
| 5120-00-219-8400 | REMOVER | 1099 |
| 5120-00-222-1503 | Wrench Socket | 1113 |
| 5120-00-223-0999 | Vise Tweezers Forceps | 1118 |
| 5120-00-223-1010 | Punch Drive Pin | 1119 |
| 5120-00-223-3772 | Forming Tool Wire | 1120 |
| 5120-00-224-1386 | Pinch (offset) | 1129 |
| 5120-00-224-2622 | Wrench Socket | 1135 |
| 5120-00-224-6634 | Installing Tool Tube Pack. Rg | 1136 |
| 5120-00-224-9255 | Bar Socket Wrench Handle | 1137 |
| 5120-00-224-9444 | Marlinspike | 1138 |
| 5120-00-227-6706 | Socket Wrench | 1144 |
| 5120-00-230-7882 | Adjusting Spring | 1148 |
| 5120-00-230-7886 | Adjusting Spring | 1149 |
| 5120-00-232-9492 | Wrench Spanner | 1150 |
| 5120-00-237-4964 | Wrench | 1158 |
| 5120-00-239-0035 | Driftpin | 1160 |
| 5120-00-239-0036 | Driftpin | 1161 |
| 5120-00-239-0037 | Driftpin | 1162 |
| 5120-00-240-5282 | Key Socket Head Screw | 1166 |
| 5120-00-240-6073 | Brass Punches | 1170 |
| 5120-00-241-3523 | Driftpin | 1177 |
| 5120-00-243-2419 | Bar Socket Wrench | 1182 |
| 5120-00-246-2311 | Lubrication Fitting Tool | 1186 |
| 5120-00-251-9668 | Adapter Torque Wrench | 1191 |
| 5120-00-256-3265 | Locator | 1192 |
| 5120-00-256-5140 | Tool Multipurpose | 1193 |
| 5120-00-259-0263 | Adapter Torque Wrench | 1194 |
| 5120-00-259-2724 | Mold Battery Terminal | 1195 |
| 5120-00-260-1090 | Spoon Minors | 1196 |
| 5120-00-260-4834 | Screwdriver | 1197 |
| 5120-00-261-2822 | Socket | 1198 |
| 5120-00-261-2834 | Socket Socket Wrench | 1199 |
| 5120-00-261-2838 | Socket | 1200 |
| 5120-00-261-2857 | WRENCH | 1201 |
| 5120-00-263-1141 | SPRING ADJUSTER | 1202 |

| | | |
|------------------|-------------------------------|------|
| 5120-00-263-3397 | SPRING BENDER | 1203 |
| 5120-00-264-3783 | WRENCH SPANNER | 1204 |
| 5120-00-269-4174 | SOCKET SOCKET WRENCH | 1205 |
| 5120-00-272-2509 | WRENCH SPANNER | 1206 |
| 5120-00-277-1185 | (Please Inquire) | 1207 |
| 5120-00-277-1320 | Wrench Open End | 1208 |
| 5120-00-277-1489 | WRENCH SOCKET-T-HANDLE | 1209 |
| 5120-00-277-3308 | BASE ADJ. WRENCH | 1210 |
| 5120-00-277-3414 | WRENCH | 1212 |
| 5120-00-277-3601 | BIT SCREWDRIVER | 1213 |
| 5120-00-277-7027 | WRENCH SOCKET | 1214 |
| 5120-00-277-8308 | WRENCH | 1215 |
| 5120-00-277-8310 | WRENCH | 1217 |
| 5120-00-277-8311 | WRENCH | 1218 |
| 5120-00-277-8312 | WRENCH | 1219 |
| 5120-00-277-8313 | WRENCH | 1220 |
| 5120-00-277-8314 | WRENCH | 1221 |
| 5120-00-278-0321 | WRENCH BOX | 1222 |
| 5120-00-278-1261 | ADJUST.BEARING WRENCH | 1223 |
| 5120-00-288-6501 | CROWFOOT ATTACHMENT | 1224 |
| 5120-00-288-6502 | Head Crowfoot Socket Wrench | 1225 |
| 5120-00-288-9080 | WRENCH BOX | 1232 |
| 5120-00-293-0014 | WRENCH SET CRWFT RATCHETING | 1238 |
| 5120-00-293-0015 | Wrench Set Crowfoot | 1239 |
| 5120-00-293-0016 | WRENCH SET CROWFOOT | 1240 |
| 5120-00-293-0655 | Alignment Tool | 1247 |
| 5120-00-293-1282 | Crowfoot Attachment | 1265 |
| 5120-00-293-1283 | Crowfoot Attachment | 1266 |
| 5120-00-293-1376 | Sonar Bottomside Hoist Mech. | 1271 |
| 5120-00-293-1380 | Alignment Tool | 1272 |
| 5120-00-293-1835 | TOOL ALIGNMENT | 1280 |
| 5120-00-293-2086 | ALIGNMENT TOOL ELECT. EQUIP. | 1284 |
| 5120-00-293-2089 | ALIGNMENT TOOL ELECT. EQUIP. | 1285 |
| 5120-00-293-2122 | WRENCH DOUBLE HEAD | 1287 |
| 5120-00-293-2500 | (Please Inquire) | 1296 |
| 5120-00-293-2540 | CONTACT POSITIONER | 1297 |
| 5120-00-293-2541 | CONTACT POSITIONER | 1298 |
| 5120-00-293-2595 | WRENCH SPANNER | 1300 |
| 5120-00-293-2603 | WRENCH SPANNER | 1301 |
| 5120-00-293-2699 | EXTRACTOR ELECTRON TUBE | 1305 |
| 5120-00-293-2786 | WRENCH SPANNER | 1308 |
| 5120-00-293-2839 | EXTRACTOR ELECTRON TUBE | 1309 |
| 5120-00-293-3491 | WRENCH OPEN END | 1313 |
| 5120-00-302-5696 | Wrench Double Open End | 1318 |
| 5120-00-303-7737 | Wrench Military | 1324 |
| 5120-00-308-3878 | (Please Inquire) | 1327 |
| 5120-00-313-3036 | Ratchet Tool | 1330 |
| 5120-00-313-9484 | Wrench Assembly | 1331 |
| 5120-00-314-7914 | Wrench Socket | 1332 |
| 5120-00-315-4003 | Socket Adapter Assembly | 1337 |
| 5120-00-315-4004 | Socket Adapter Assembly | 1338 |
| 5120-00-316-2995 | Socket Wrench | 1342 |
| 5120-00-317-8077 | Wrench Injection Nut | 1347 |
| 5120-00-318-9760 | Inj. Noz. Filter Puller Tool | 1351 |
| 5120-00-319-7763 | Wrench Assembly | 1354 |
| 5120-00-321-4507 | Pliers Slip Joint | 1356 |
| 5120-00-339-0606 | Hook Brush Spring | 1372 |
| 5120-00-343-8074 | Tool Flaring | 1381 |
| 5120-00-343-8210 | Die Button Fastener Tool | 1382 |
| 5120-00-346-0891 | Extractor Electron Tube | 1385 |
| 5120-00-346-2274 | Handle | 1386 |
| 5120-00-347-2583 | Wrench Assembly | 1387 |
| 5120-00-356-4354 | Alignment Tool | 1393 |
| 5120-00-357-5787 | Punch Drive Pin | 1398 |
| 5120-00-357-7721 | Wrench Outlet Valve | 1400 |
| 5120-00-357-7722 | Wrench Inlet Valve | 1401 |
| 5120-00-357-8850 | Wrench Socket | 1404 |
| 5120-00-357-8876 | Wrench Socket | 1405 |
| 5120-00-359-6463 | Bender | 1406 |
| 5120-00-359-6480 | Block Typewriter Repair | 1407 |
| 5120-00-362-2148 | Bulkhead Terminal | 1411 |
| 5120-00-366-1426 | Piston Ring Guide Compressor | 1418 |
| 5120-00-369-2649 | Wrench Spanner | 1425 |
| 5120-00-371-9622 | Puller Mechanical | 1427 |
| 5120-00-377-2194 | Bar | 1429 |
| 5120-00-380-8723 | Wrench Socket | 1431 |
| 5120-00-381-6175 | Key Socket Head Screw | 1433 |
| 5120-00-381-7070 | (Please Inquire) | 1435 |
| 5120-00-387-9615 | Remover Cylinder Sleeve Liner | 1439 |
| 5120-00-391-6804 | Bar | 1445 |
| 5120-00-391-6831 | Wrench | 1446 |
| 5120-00-392-8339 | Extractor Jack Sleeve | 1447 |
| 5120-00-394-7630 | Wrench Seat Ring | 1453 |
| 5120-00-399-8649 | Wrench Pinion | 1465 |
| 5120-00-406-5077 | Lamp Extractor | 1466 |
| 5120-00-417-2952 | Puller Mechanical | 1472 |
| 5120-00-421-4353 | Key Socket Head Screw | 1473 |
| 5120-00-441-2562 | Idler Bearing Placer | 1489 |
| 5120-00-441-2564 | Placer Bearing | 1491 |
| 5120-00-449-7311 | Hand Set Die | 1504 |
| 5120-00-463-7302 | Remover Tool Resilient Mount | 1512 |
| 5120-00-473-6320 | Handle Extension Wrench | 1518 |
| 5120-00-473-6337 | Gaurd Safety | 1519 |
| 5120-00-473-6511 | Wrench Socket | 1520 |
| 5120-00-473-6927 | Adapter Road Wheel Arm Spdl. | 1523 |
| 5120-00-473-7025 | Driver Oil & Wate | 1524 |
| 5120-00-473-7372 | Remover & Replacer | 1527 |
| 5120-00-473-7374 | Remover & Replacer | 1528 |
| 5120-00-473-7393 | Remover & Replacer | 1529 |
| 5120-00-473-7599 | Tool Check Valve | 1530 |
| 5120-00-473-7768 | Wrench Track Support | 1533 |
| 5120-00-474-3249 | Hammer Peening | 1534 |
| 5120-00-475-2283 | Tool Assembly | 1538 |
| 5120-00-479-6124 | Wrench Spanner | 1542 |
| 5120-00-490-4856 | Wrench Open End Fixed | 1544 |
| 5120-00-498-2759 | Extractor Connector | 1563 |
| 5120-00-500-7488 | Wrench Spanner | 1567 |
| 5120-00-501-7615 | Wrench Spanner | 1568 |
| 5120-00-505-5918 | Driftpin | 1569 |
| 5120-00-508-5456 | Extension Socket Wrench | 1570 |
| 5120-00-513-5925 | Extractor Electron Tube | 1577 |
| 5120-00-516-3863 | Wrench Adjustable Spanner | 1580 |
| 5120-00-517-7801 | Wrench Air | 1582 |
| 5120-00-529-4124 | Carrier Storage Battery Hand | 1590 |
| 5120-00-540-1643 | Punch Drive Pin | 1599 |
| 5120-00-544-5736 | Wrench Atomizer Tip | 1609 |

| | | |
|------------------|-------------------------------|------|
| 5120-00-545-6067 | Puller Mechanical | 1610 |
| 5120-00-550-7928 | Wrench Spanner | 1613 |
| 5120-00-556-8334 | Wrench Combination | 1624 |
| 5120-00-557-0605 | (Please Inquire) | 1625 |
| 5120-00-560-0496 | Pliers Slip Joint | 1626 |
| 5120-00-562-4735 | Wrench Spanner | 1629 |
| 5120-00-563-7342 | Wrench Open End | 1630 |
| 5120-00-565-4147 | Wrench Open End | 1632 |
| 5120-00-566-0885 | Lever Hand Vane Actuating | 1633 |
| 5120-00-567-2492 | Wedge Assembly Bearing Puller | 1636 |
| 5120-00-571-2619 | Crowfoot Attachment | 1645 |
| 5120-00-585-6169 | Alignment Tool | 1654 |
| 5120-00-588-4808 | Socket Wrench Face Spanner | 1662 |
| 5120-00-592-9976 | Screw Type Pin Remover | 1665 |
| 5120-00-592-9977 | Screw Type Pin Remover | 1666 |
| 5120-00-593-3565 | Compressing Tool | 1667 |
| 5120-00-595-8997 | Wrench Spanner | 1672 |
| 5120-00-595-9141 | Wrench Socket Key Assembly | 1677 |
| 5120-00-595-9193 | Wrench Aligator Jaw | 1679 |
| 5120-00-596-0880 | Spanner Attachment | 1686 |
| 5120-00-596-4005 | Wrench | 1691 |
| 5120-00-596-4477 | Spanner Wrench | 1697 |
| 5120-00-596-8632 | Wrench | 1702 |
| 5120-00-596-9829 | Wrench Open End Fixed | 1704 |
| 5120-00-602-0947 | Wire Retriever Antenna | 1708 |
| 5120-00-604-8819 | Set Hand Rivet | 1711 |
| 5120-00-610-5516 | Wrench Spanner | 1720 |
| 5120-00-611-6736 | Wrench Assembly | 1723 |
| 5120-00-612-4269 | Pin | 1724 |
| 5120-00-616-3502 | Tool Breechlock Unlocking | 1726 |
| 5120-00-617-0995 | Handspike | 1728 |
| 5120-00-622-5827 | Seat Lapping Tool | 1736 |
| 5120-00-623-2178 | Alignment Tool | 1738 |
| 5120-00-629-5628 | Piston Pump Hydraulic | 1748 |
| 5120-00-629-5636 | Ram Lift Hydraulic | 1749 |
| 5120-00-629-9781 | Aligning Studs Flywheel | 1750 |
| 5120-00-631-0838 | Pusher & Puller Tachometer | 1751 |
| 5120-00-631-5766 | Puller Assembly Transmission | 1752 |
| 5120-00-632-9676 | Wrench Oil Screen | 1754 |
| 5120-00-633-1850 | Pointer Fuel Control | 1755 |
| 5120-00-653-3501 | Wrench Seat | 1763 |
| 5120-00-658-9805 | Wrench Set Spanner | 1770 |
| 5120-00-659-8984 | Extractor Tool | 1771 |
| 5120-00-661-2913 | Tool Assembly | 1772 |
| 5120-00-670-3301 | Puller Mechanical | 1775 |
| 5120-00-670-4379 | Pin Gaging Bolt | 1777 |
| 5120-00-671-2129 | Bar Locating | 1783 |
| 5120-00-671-4022 | Puller Mechanical | 1788 |
| 5120-00-674-6071 | Valve Assembly | 1790 |
| 5120-00-678-5119 | Guide Pice Tool | 1792 |
| 5120-00-678-5285 | Lifter Assembly | 1793 |
| 5120-00-678-5286 | Wrench Open End Fixed | 1794 |
| 5120-00-683-8655 | Wrench Spanner | 1795 |
| 5120-00-684-3605 | Wrench Box | 1796 |
| 5120-00-690-4329 | Tool Presetting Fla. | 1799 |
| 5120-00-691-6845 | Wrench Spanner | 1806 |
| 5120-00-694-1197 | Pin Straightener | 1807 |
| 5120-00-703-9152 | Socket Wrench Face | 1813 |
| 5120-00-703-9153 | Wrench | 1814 |
| 5120-00-704-3293 | Installer Bearing Hydraulic | 1816 |
| 5120-00-704-3320 | Tool Assembly Removal | 1821 |
| 5120-00-704-3343 | Wrench Assembly | 1823 |
| 5120-00-708-2661 | Replacer | 1831 |
| 5120-00-708-2670 | Replacer Oil Seal | 1832 |
| 5120-00-708-3800 | Lug Track Connecting | 1840 |
| 5120-00-709-4072 | Handle Socket Wrench | 1844 |
| 5120-00-710-6901 | Clamp | 1848 |
| 5120-00-714-4741 | Wrench Special | 1851 |
| 5120-00-717-1412 | Socket Wrench Face | 1857 |
| 5120-00-717-6239 | Wrench | 1858 |
| 5120-00-719-6634 | (Please Inquire) | 1863 |
| 5120-00-721-2467 | Socket Socket Wrench | 1866 |
| 5120-00-722-8728 | Wrench Spanner | 1869 |
| 5120-00-725-4261 | Wrench Thin Double Open End | 1871 |
| 5120-00-727-9744 | Wrench Spanner | 1874 |
| 5120-00-731-7439 | Key Socket Head Screw | 1879 |
| 5120-00-733-7113 | Driver | 1881 |
| 5120-00-737-1131 | Wing Tank Wrench | 1885 |
| 5120-00-756-9714 | Alignment Tool | 1894 |
| 5120-00-758-6649 | Tool Filter | 1898 |
| 5120-00-759-6683 | Guide Pin | 1899 |
| 5120-00-759-7711 | Punch Drive Pin | 1900 |
| 5120-00-759-7712 | Punch Drive Pin | 1901 |
| 5120-00-763-1852 | Wrench | 1907 |
| 5120-00-770-7335 | Puller Mechanical | 1916 |
| 5120-00-775-4315 | Adapter Socket | 1925 |
| 5120-00-776-1858 | Driver Bearing | 1927 |
| 5120-00-777-7596 | Wrench Flight | 1931 |
| 5120-00-777-8932 | Extractor Ring Retaining | 1932 |
| 5120-00-778-6118 | Puller | 1934 |
| 5120-00-779-4740 | Crowfoot Attachment | 1947 |
| 5120-00-781-7891 | Tool Hand Adjustable | 1948 |
| 5120-00-786-5704 | Spanner Wrench | 1952 |
| 5120-00-788-1623 | Extractor Electron | 1956 |
| 5120-00-795-0082 | Replacer Bearing | 1984 |
| 5120-00-795-0147 | Screw | 1991 |
| 5120-00-801-9691 | Crowfoot Attachment | 2004 |
| 5120-00-802-5600 | Puller Assemby | 2007 |
| 5120-00-815-0603 | Wrench Sway Brace Adjustment | 2017 |
| 5120-00-817-7460 | Wrench Socket | 2020 |
| 5120-00-820-9478 | Blade Socket Head Screw Key | 2022 |
| 5120-00-834-3732 | Wrench Socket | 2033 |
| 5120-00-837-5091 | Adapter Mechanical | 2036 |
| 5120-00-837-9167 | Wrench Power Turbine | 2037 |
| 5120-00-837-9180 | Wrench | 2040 |
| 5120-00-840-7261 | Punch Drive in | 2054 |
| 5120-00-841-9433 | Drift Accessory Gear | 2057 |
| 5120-00-850-6861 | Mirror Inspection | 2063 |
| 5120-00-851-8683 | Wrench Socket | 2064 |
| 5120-00-851-8684 | Wrench Socket | 2065 |
| 5120-00-855-7473 | Tool Puller | 2067 |
| 5120-00-856-5648 | Key Socket Head Screw | 2070 |
| 5120-00-856-5649 | Key Socket Head Screw | 2071 |
| 5120-00-860-1543 | Wrench Tap Plug | 2085 |
| 5120-00-860-8178 | Puller Mechanical | 2090 |
| 5120-00-860-8189 | Puller Mechanical | 2091 |

| | | |
|------------------|-------------------------------|------|
| 5120-00-862-7023 | Coupling Bolt Remover | 2096 |
| 5120-00-867-7234 | Puller Oil Seal | 2100 |
| 5120-00-868-9562 | Punch Installation Gromet | 2101 |
| 5120-00-870-6919 | Remover & Replacer Kit | 2105 |
| 5120-00-870-8836 | Nut Driver | 2109 |
| 5120-00-875-2588 | Wrench Socket | 2116 |
| 5120-00-880-4564 | Punch Drive Pin | 2124 |
| 5120-00-880-4567 | Handle Punch | 2125 |
| 5120-00-880-4569 | Tool Box | 2126 |
| 5120-00-880-4576 | (Please Inquire) | 2128 |
| 5120-00-880-4579 | Punch Drive Pin | 2129 |
| 5120-00-882-6615 | Adapter | 2136 |
| 5120-00-885-1791 | Wrench Pylon Torque Wrench | 2140 |
| 5120-00-885-6471 | Wrench | 2141 |
| 5120-00-888-3361 | Wrench | 2146 |
| 5120-00-888-3368 | Wrench Hex | 2147 |
| 5120-00-891-5168 | Wrench Spanner | 2156 |
| 5120-00-891-6814 | Special Tool | 2157 |
| 5120-00-892-2057 | (Please Inquire) | 2160 |
| 5120-00-892-6004 | Blade Socket | 2163 |
| 5120-00-892-6005 | Blade | 2164 |
| 5120-00-892-6006 | Blade Splined | 2165 |
| 5120-00-892-6007 | Blade | 2166 |
| 5120-00-893-2519 | Socket Wrench Face Spanner | 2169 |
| 5120-00-893-3144 | Driftpin | 2170 |
| 5120-00-895-5425 | Alignment Tool | 2173 |
| 5120-00-896-8087 | Assembly Tool Tachometer | 2175 |
| 5120-00-896-8097 | Front Seal Assembly | 2177 |
| 5120-00-900-5952 | Wrench | 2185 |
| 5120-00-901-1573 | Wrench Socket | 2186 |
| 5120-00-906-6213 | Drift For Punch Shear Pin | 2188 |
| 5120-00-906-6376 | Pin Drift | 2189 |
| 5120-00-907-0696 | Remover Shock Absorber | 2194 |
| 5120-00-908-1742 | Guide Pliers | 2195 |
| 5120-00-909-9566 | Compressor | 2198 |
| 5120-00-909-9567 | Compressor | 2199 |
| 5120-00-909-9667 | Insertion Tool | 2200 |
| 5120-00-910-4044 | Key Socket Head Screw | 2201 |
| 5120-00-919-9888 | Wrench Open End | 2220 |
| 5120-00-922-2764 | Solenoid Valve Adjusting Tool | 2222 |
| 5120-00-926-7123 | Wrench Jam Nut | 2230 |
| 5120-00-926-7161 | Wrench Torque | 2237 |
| 5120-00-927-4042 | Die Head | 2238 |
| 5120-00-909-9666 | Wrench | 2241 |
| 5120-00-919-2927 | Wrench | 2242 |
| 5120-00-927-9588 | Key Socket Head Screw | 2243 |
| 5120-00-928-6382 | Wrench Jam Nut | 2248 |
| 5120-00-932-5555 | Wrench Adapter Special | 2259 |
| 5120-00-935-4651 | Wrench | 2266 |
| 5120-00-937-5438 | Tool Hand Adjustable | 2271 |
| 5120-00-937-7834 | Wrench Cylinder Head Nut | 2273 |
| 5120-00-939-8932 | Removal Tool Assembly | 2275 |
| 5120-00-946-8707 | Wrench Pocket | 2281 |
| 5120-00-948-3889 | Pin Puller | 2286 |
| 5120-00-948-3922 | Wrench Assembly | 2295 |
| 5120-00-948-3941 | Seal Puller Assembly | 2300 |
| 5120-00-948-3944 | Installer Carbon Seal | 2301 |
| 5120-00-948-3953 | Crowfoot Attachment | 2302 |
| 5120-00-950-4330 | Wrench Spanner | 2315 |
| 5120-00-951-0082 | Spacer Nozzle | 2317 |
| 5120-00-952-3772 | Wrench Spark Plug | 2320 |
| 5120-00-953-3395 | (Please Inquire) | 2323 |
| 5120-00-953-3397 | (Please Inquire) | 2325 |
| 5120-00-953-3398 | Socket | 2326 |
| 5120-00-953-3409 | Crowfoot Attachment | 2328 |
| 5120-00-955-5810 | Extractor | 2334 |
| 5120-00-959-5743 | WRENCH BOX | 2338 |
| 5120-00-959-7635 | HANDLING TOOL DETEN | 2339 |
| 5120-00-961-6470 | (Please Inquire) | 2342 |
| 5120-00-961-8538 | DEPRESSOR SPRING FUEL | 2343 |
| 5120-00-962-7580 | WRENCH | 2345 |
| 5120-00-970-8950 | (Please Inquire) | 2353 |
| 5120-00-973-4960 | WRENCH | 2360 |
| 5120-00-977-3347 | TORQUE WRENCH ADAPTOR | 2362 |
| 5120-00-981-3916 | Hook Unlocking | 2369 |
| 5120-00-986-9080 | (Please Inquire) | 2373 |
| 5120-00-987-5058 | GAGE,SETTING | 2375 |
| 5120-00-991-3152 | REPLACER OIL SEAL | 2385 |
| 5120-00-991-3163 | COMPRESSOR SPRING | 2389 |
| 5120-00-991-3171 | REPLACER | 2393 |
| 5120-00-991-3176 | REMOVER AND REPLACER | 2395 |
| 5120-00-994-3157 | ALIGNMENT TOOL | 2397 |
| 5120-00-996-2119 | COMPRESSING TOOL | 2399 |
| 5120-00-996-4508 | PULLING WIRING BOARD | 2400 |
| 5120-00-999-1263 | (Please Inquire) | 2402 |
| 5120-00-999-1505 | INSTALLING TOOL | 2404 |
| 5120-00-999-7453 | BAR RIGGING | 2405 |
| 5120-01-006-6602 | PULLER ROD ASSEMBLY | 2411 |
| 5120-01-008-7957 | WRENCH SPANNER | 2415 |
| 5120-01-009-7889 | LIFTING TOOL | 2417 |
| 5120-01-014-6298 | TOOL ROADWAY | 2425 |
| 5120-01-015-2086 | WRENCH SOCKET | 2427 |
| 5120-01-017-9525 | PULLER COUPLING | 2431 |
| 5120-01-018-5908 | STICK WOOD | 2433 |
| 5120-01-030-1629 | INSTALLING TOOL | 2447 |
| 5120-01-039-8134 | TWEEZERS | 2459 |
| 5120-01-042-7410 | TOOL SEAL PUSHER | 2462 |
| 5120-01-042-7411 | DRIVER END FITTING | 2463 |
| 5120-01-046-7323 | ALIGNMENT TOOL ELECTRON | 2465 |
| 5120-01-047-9284 | (Please Inquire) | 2474 |
| 5120-01-048-1366 | WRENCH SPANNER | 2475 |
| 5120-01-048-1391 | TRUNION ASSEMBLY TOOL | 2476 |
| 5120-01-058-7424 | Wrench Spanner | 2487 |
| 5120-01-058-7425 | KEY SOCKET HEAD SCREW | 2488 |
| 5120-01-058-7426 | WRENCH OPEN END | 2489 |
| 5120-01-069-9939 | HAMMER | 2499 |
| 5120-01-073-2824 | EXTRACTOR SEAT RING | 2500 |
| 5120-01-074-0661 | LAPPING TOOL SPECIAL | 2502 |
| 5120-01-079-7816 | Extension Socket Wrench | 2509 |
| 5120-01-083-2923 | Handle Lapping Tool | 2513 |
| 5120-01-084-3895 | Wrench Spanner | 2514 |
| 5120-01-090-5858 | Wrench Liner Puller | 2517 |
| 5120-01-106-0086 | Wrench Relief Valve | 2522 |
| 5120-01-116-5026 | Wrench Fuel Injector | 2529 |
| 5120-01-117-7855 | Wrench Set | 2530 |
| 5120-01-117-7856 | Puller Kit | 2531 |

| | | |
|------------------|-----------------------------------|------|
| 5120-01-120-0636 | Puller Tube | 2532 |
| 5120-01-120-7998 | (Please Inquire) | 2533 |
| 5120-01-126-3262 | Extension Seat Lapping | 2535 |
| 5120-01-134-2333 | Torque Tool Hex | 2536 |
| 5120-01-135-7115 | Valve | 2539 |
| 5120-01-141-0029 | (Please Inquire) | 2540 |
| 5120-01-146-4397 | Seating Tool | 2542 |
| 5120-01-158-7776 | Wrench Spanner | 2545 |
| 5120-01-158-7777 | Key Socket Head Screw | 2546 |
| 5120-01-159-3043 | Wrench Seat Ring Valve | 2547 |
| 5120-01-159-4363 | (Please Inquire) | 2549 |
| 5120-01-159-9300 | Wrench Spanner | 2550 |
| 5120-01-160-1318 | Wrench Seat Ring Valve | 2551 |
| 5120-01-166-6484 | Wrench Seat Ring Valve | 2556 |
| 5120-01-170-4452 | Wrench Slotteo Seat | 2559 |
| 5120-01-177-3030 | Wrench Diode | 2562 |
| 5120-01-177-4105 | Pliers Switch Button Adjust | 2563 |
| 5130-00-343-8073 | Puller | 2574 |
| 5133-00-133-3795 | Cutter Countersink | 2586 |
| 5136-00-991-8563 | Thread Chaser Tool | 2590 |
| 5140-00-313-9486 | Carrying Case | 2596 |
| 5210-00-134-3219 | BLADE,THICKNESS GAG | 2620 |
| 5210-00-181-9122 | GAGE,THICKNESS | 2622 |
| 5210-00-197-9678 | GAGE,THICKNESS | 2625 |
| 5210-00-313-3105 | Adapter | 2629 |
| 5210-00-399-3715 | GAGE,TAPER | 2634 |
| 5210-00-474-9165 | GAGE,UNIVERSAL PUMP | 2635 |
| 5210-00-994-8552 | GAGE,THICKNESS | 2657 |
| 5210-01-025-3256 | Picker Eight Gage | 2658 |
| 5120-00-021-3188 | Punch Mechanical | 2662 |
| 5120-00-022-7793 | Alignment Tool Rotor | 2663 |
| 5120-00-140-1218 | Lifting Assembly | 2664 |
| 5120-00-895-5424 | Alignment Tool | 2665 |
| 5120-01-137-7499 | Screwdriver | 2666 |
| 5110-00-220-9539 | DIE,DIPLING | 2667 |
| 5110-00-837-9389 | RIVETING PUNCH TURBINE | 2668 |
| 5120-00-030-2738 | Fittings Deck Drain | 2669 |
| 5120-00-795-7962 | Socket Wrench Face Spanner | 2670 |
| 5120-00-926-7124 | Wrench Socket | 2671 |
| 5120-00-933-5983 | Wrench Socket | 2672 |
| 5110-00-316-4785 | RESEATING TOOL,LUBE | 2673 |
| 5110-00-596-1050 | CHISEL,BOILERMAKER' | 2675 |
| 5110-00-596-1049 | CHISEL,BOILERMAKER' | 2676 |
| 5120-00-058-4029 | Wrench Turbine Rear Bearing | 2678 |
| 5120-00-111-3563 | PACKING INSTALLTION TOOL | 2679 |
| 5120-00-235-5818 | (Please Inquire) | 2682 |
| 5120-00-293-1507 | (Please Inquire) | 2685 |
| 5120-00-317-2227 | (Please Inquire) | 2686 |
| 5120-00-398-3574 | (Please Inquire) | 2687 |
| 5120-00-880-4583 | (Please Inquire) | 2688 |
| 5120-01-135-7105 | (Please Inquire) | 2695 |
| 5120-00-222-4440 | (Please Inquire) | 2696 |
| 5120-00-152-1831 | (Please Inquire) | 2707 |
| 5120-00-477-0874 | (Please Inquire) | 2708 |
| 5120-00-288-9293 | (Please Inquire) | 2710 |
| 5120-00-277-1237 | (Please Inquire) | 2711 |
| 5120-00-277-1191 | (Please Inquire) | 2714 |
| 5120-00-032-9544 | Wrench, Socket Att. | 2717 |
| 5120-00-025-0701 | Large Adjustable Spanner Assm. | 2718 |
| 5120-00-464-4204 | (Please Inquire) | 2723 |
| 5120-00-078-0532 | SPANNER WRENCH | 2724 |
| 5120-00-277-3663 | (Please Inquire) | 2725 |
| 5120-00-444-7818 | (Please Inquire) | 2727 |
| 5120-00-117-5459 | KEY, SOCKET HEAD SCREW | 2728 |
| 5120-00-268-3589 | (Please Inquire) | 2729 |
| 5120-00-892-2058 | (Please Inquire) | 2736 |
| 5120-00-264-3777 | (Please Inquire) | 2739 |
| 5120-00-277-9077 | (Please Inquire) | 2743 |
| 5120-00-277-9076 | (Please Inquire) | 2744 |
| 5120-00-277-9075 | (Please Inquire) | 2745 |
| 5120-00-288-6463 | (Please Inquire) | 2747 |
| 5120-00-104-9028 | ADAPTER, TORQUE WRENCH BLOCK ASSY | 2749 |
| 5120-00-587-1631 | (Please Inquire) | 2750 |
| 5120-00-784-6033 | (Please Inquire) | 2754 |
| 5120-00-870-6958 | (Please Inquire) | 2766 |
| 5120-01-135-3322 | (Please Inquire) | 2768 |
| 5120-00-042-4426 | Wrench, Socket Att. | 2770 |
| 5120-01-170-6663 | (Please Inquire) | 2772 |
| 5120-00-277-9078 | (Please Inquire) | 2777 |
| 5180-01-168-7083 | (Please Inquire) | 2778 |
| 5120-01-179-4039 | (Please Inquire) | 2789 |
| 5120-00-699-3558 | (Please Inquire) | 2798 |
| 5120-00-239-0038 | (Please Inquire) | 2799 |
| 5210-00-757-2745 | GAGE,SPROCKET TOOTH | 2803 |
| 5120-00-090-1538 | SPANNER WRENCH | 2812 |
| 5120-00-072-6977 | CAULKING TOOL | 2816 |
| 5120-00-033-8428 | Wrench | 2819 |
| 5120-00-152-1076 | (Please Inquire) | 2820 |
| 5120-00-075-1056 | WRENCH | 2822 |
| 5120-00-169-6725 | (Please Inquire) | 2823 |
| 5120-00-488-9245 | (Please Inquire) | 2824 |
| 5120-00-317-8082 | (Please Inquire) | 2826 |
| 5120-00-658-9269 | (Please Inquire) | 2837 |
| 5120-00-243-1671 | (Please Inquire) | 2842 |
| 5120-00-262-8498 | (Please Inquire) | 2844 |
| 5120-00-224-2503 | (Please Inquire) | 2847 |
| 5120-00-107-0037 | KEY SOCKET HEAD SCREW | 2848 |
| 5120-00-671-2115 | (Please Inquire) | 2853 |
| 5120-00-143-8217 | (Please Inquire) | 2854 |
| 5120-00-068-8673 | DRIVER, OIL PUMP | 2855 |
| 5120-00-061-6347 | SCREWDRIVER | 2862 |
| 5120-00-256-2112 | (Please Inquire) | 2864 |
| 5120-01-170-3276 | (Please Inquire) | 2875 |
| 5120-00-017-6166 | Key, Socket Head | 2877 |
| 5120-00-104-1860 | Key Socket Head Screw | 2878 |
| 5120-00-189-2997 | (Please Inquire) | 2879 |
| 5120-00-189-2998 | (Please Inquire) | 2880 |
| 5120-01-170-6664 | (Please Inquire) | 2883 |
| 5120-00-718-8573 | (Please Inquire) | 2885 |
| 5120-01-177-3011 | (Please Inquire) | 2887 |
| 5120-01-095-7820 | (Please Inquire) | 2889 |
| 5120-00-116-6755 | BRUSH WIRE FURNACE AND FLUE | 2890 |
| 5120-00-323-3100 | (Please Inquire) | 2892 |
| 5120-00-081-2304 | WRENCH OPEN END | 2896 |
| 5120-00-293-0191 | (Please Inquire) | 2897 |
| 5120-00-277-1198 | (Please Inquire) | 2908 |

| | | |
|------------------|---------------------------------|------|
| 5120-01-186-1035 | (Please Inquire) | 2910 |
| 5120-00-105-8555 | WRENCH, SPANNER | 2911 |
| 5120-01-193-5056 | (Please Inquire) | 2912 |
| 5120-00-712-0517 | (Please Inquire) | 2913 |
| 5120-00-778-4215 | (Please Inquire) | 2914 |
| 5120-00-802-5555 | (Please Inquire) | 2915 |
| 5120-00-802-8447 | (Please Inquire) | 2916 |
| 5120-01-185-6831 | (Please Inquire) | 2920 |
| 5120-01-177-4936 | (Please Inquire) | 2924 |
| 5120-00-959-0997 | (Please Inquire) | 2925 |
| 5120-00-110-4536 | DRIFT-COMPRESSOR REAR LABYRINTH | 2926 |
| 5120-00-908-1248 | (Please Inquire) | 2927 |
| 5120-00-948-3917 | (Please Inquire) | 2938 |
| 5120-01-046-4948 | (Please Inquire) | 2940 |
| 5120-01-160-1025 | (Please Inquire) | 2944 |
| 5120-01-195-9779 | (Please Inquire) | 2945 |
| 5120-01-196-7056 | (Please Inquire) | 2947 |
| 5120-00-133-3040 | WRENCH, SPANNER | 2948 |
| 5120-00-288-4052 | (Please Inquire) | 2949 |
| 5120-00-061-3188 | Socket Wrench Attachment | 2953 |
| 5120-01-166-7027 | (Please Inquire) | 2954 |
| 5120-01-160-1028 | (Please Inquire) | 2955 |
| 5120-01-179-4033 | (Please Inquire) | 2956 |
| 5120-00-224-9440 | (Please Inquire) | 2957 |
| 5120-00-293-1136 | (Please Inquire) | 2958 |
| 5120-00-133-2570 | ADAPTER BALL PULLER | 2959 |
| 5120-00-033-0653 | Wrench | 2965 |
| 5120-00-072-5211 | TOOL, INFINITY SETTING | 2966 |
| 5120-00-104-6817 | SPACER-CLUTCH RETAINER | 2967 |
| 5120-00-113-3314 | TOOL, OIL PACKING | 2968 |
| 5120-00-156-9771 | (Please Inquire) | 2969 |
| 5120-00-301-5445 | (Please Inquire) | 2971 |
| 5120-00-378-3139 | (Please Inquire) | 2978 |
| 5120-00-371-9623 | (Please Inquire) | 2979 |
| 5120-00-124-5433 | INSTALLING TOOL | 2980 |
| 5180-00-073-5671 | (Please Inquire) | 2982 |
| 5210-00-513-9139 | GAGE,GAP SETTING | 2987 |
| 5210-00-513-9140 | GAGE,GAP SETTING | 2988 |
| 5210-00-513-9141 | GAGE,GAP SETTING | 2989 |
| 5210-00-513-9142 | GAGE,GAP SETTING | 2990 |
| 5120-01-170-0628 | (Please Inquire) | 2999 |
| 5120-01-180-4606 | (Please Inquire) | 3001 |
| 5120-01-167-2289 | (Please Inquire) | 3002 |
| 5120-01-134-0422 | (Please Inquire) | 3006 |
| 5120-00-042-7082 | Installing Tool | 3007 |
| 5120-00-862-4081 | (Please Inquire) | 3008 |
| 5120-00-580-2950 | (Please Inquire) | 3009 |
| 5120-00-880-4565 | (Please Inquire) | 3012 |
| 5210-00-232-6975 | GAGE,GAP SHOE | 3014 |
| 5120-00-025-2411 | Socket, Wrench | 3015 |
| 5120-00-215-5761 | (Please Inquire) | 3016 |
| 5120-01-078-1922 | (Please Inquire) | 3021 |
| 5120-01-084-3298 | (Please Inquire) | 3022 |
| 5120-00-972-6029 | (Please Inquire) | 3023 |
| 5180-01-101-8004 | (Please Inquire) | 3027 |
| 5120-00-293-1324 | (Please Inquire) | 3034 |
| 5110-00-268-1238 | REAMER,HAND | 3036 |
| 5120-00-596-0809 | (Please Inquire) | 3041 |
| 5120-00-081-9073 | WRENCH, OPEN END | 3045 |
| 5120-00-293-1769 | (Please Inquire) | 3046 |
| 5120-00-262-8503 | (Please Inquire) | 3047 |
| 5120-00-277-1261 | (Please Inquire) | 3061 |
| 5120-00-277-1262 | (Please Inquire) | 3071 |
| 5120-00-277-1259 | (Please Inquire) | 3072 |
| 5120-00-277-1260 | (Please Inquire) | 3073 |
| 5120-00-277-1258 | (Please Inquire) | 3074 |
| 5120-00-277-2691 | (Please Inquire) | 3075 |
| 5120-00-277-1256 | (Please Inquire) | 3076 |
| 5120-00-277-1253 | (Please Inquire) | 3077 |
| 5120-00-277-1254 | (Please Inquire) | 3078 |
| 5120-00-277-1251 | (Please Inquire) | 3079 |
| 5120-00-277-1252 | (Please Inquire) | 3080 |
| 5120-00-277-1249 | (Please Inquire) | 3081 |
| 5120-00-277-1250 | (Please Inquire) | 3082 |
| 5120-00-277-1247 | WRENCH, SINGLE END | 3083 |
| 5120-00-277-1248 | (Please Inquire) | 3084 |
| 5120-00-277-1246 | (Please Inquire) | 3085 |
| 5120-00-277-1244 | (Please Inquire) | 3086 |
| 5120-00-277-1245 | (Please Inquire) | 3087 |
| 5120-00-277-1242 | (Please Inquire) | 3088 |
| 5120-00-277-1243 | (Please Inquire) | 3089 |
| 5120-00-277-1240 | (Please Inquire) | 3090 |
| 5120-00-277-1238 | (Please Inquire) | 3091 |
| 5120-00-277-1239 | (Please Inquire) | 3092 |
| 5120-00-277-1236 | (Please Inquire) | 3093 |
| 5120-00-064-2614 | WRENCH, OPEN END | 3126 |
| 5120-00-081-9072 | WRENCH, OPEN END | 3127 |
| 5120-00-081-9074 | WRENCH, OPEN END | 3128 |
| 5120-00-081-9075 | WRENCH, OPEN END | 3129 |
| 5120-00-081-9083 | Wrench Open End | 3135 |
| 5120-00-277-1610 | (Please Inquire) | 3137 |
| 5120-00-277-1562 | (Please Inquire) | 3139 |
| 5120-00-277-1563 | (Please Inquire) | 3140 |
| 5120-00-277-1565 | (Please Inquire) | 3141 |
| 5120-00-277-1566 | (Please Inquire) | 3142 |
| 5120-00-277-1567 | (Please Inquire) | 3143 |
| 5120-00-277-1568 | (Please Inquire) | 3144 |
| 5120-00-277-1569 | (Please Inquire) | 3145 |
| 5120-00-277-1571 | (Please Inquire) | 3146 |
| 5120-00-277-1572 | (Please Inquire) | 3147 |
| 5120-00-277-1573 | (Please Inquire) | 3148 |
| 5120-00-277-1574 | (Please Inquire) | 3149 |
| 5120-00-277-1575 | (Please Inquire) | 3150 |
| 5120-00-277-1576 | (Please Inquire) | 3151 |
| 5120-00-277-1577 | (Please Inquire) | 3152 |
| 5120-00-277-1578 | (Please Inquire) | 3153 |
| 5120-00-277-1579 | (Please Inquire) | 3154 |
| 5120-00-261-2856 | (Please Inquire) | 3156 |
| 5120-00-277-7393 | (Please Inquire) | 3157 |
| 5120-00-949-1768 | (Please Inquire) | 3159 |
| 5120-00-880-4559 | (Please Inquire) | 3161 |
| 5120-00-278-0812 | (Please Inquire) | 3162 |
| 5120-00-555-8894 | (Please Inquire) | 3165 |
| 5120-00-277-9606 | (Please Inquire) | 3171 |
| 5120-01-106-2155 | (Please Inquire) | 3172 |
| 5120-01-166-6987 | (Please Inquire) | 3173 |

| | | |
|------------------|---------------------------------|------|
| 5120-00-107-1514 | SCREWDRIVER, HEXAGONAL TIP | 3175 |
| 5120-01-180-4884 | (Please Inquire) | 3178 |
| 5120-00-486-0013 | (Please Inquire) | 3186 |
| 5120-01-108-1654 | (Please Inquire) | 3188 |
| 5120-01-132-7561 | (Please Inquire) | 3190 |
| 5120-00-488-0437 | (Please Inquire) | 3193 |
| 5120-00-555-8939 | (Please Inquire) | 3194 |
| 5120-00-488-0440 | (Please Inquire) | 3195 |
| 5120-01-120-0637 | (Please Inquire) | 3199 |
| 5120-00-125-7730 | COMPRESSOR OIL TANK CHAIN PIN | 3200 |
| 5120-00-150-5964 | (Please Inquire) | 3201 |
| 5120-00-189-8167 | (Please Inquire) | 3202 |
| 5120-00-150-5963 | (Please Inquire) | 3203 |
| 5120-00-150-5965 | (Please Inquire) | 3204 |
| 4920-00-971-0169 | PILOT,SEAL INSTALLI | 3205 |
| 5120-00-230-3696 | (Please Inquire) | 3206 |
| 5120-00-592-3672 | (Please Inquire) | 3215 |
| 5120-00-315-4000 | (Please Inquire) | 3216 |
| 5120-00-058-6297 | WRENCH, BOX | 3220 |
| 5120-00-168-5253 | (Please Inquire) | 3221 |
| 5120-00-135-4925 | WRENCH | 3223 |
| 5120-00-222-4445 | (Please Inquire) | 3227 |
| 5120-00-607-0966 | (Please Inquire) | 3235 |
| 5120-00-619-3825 | (Please Inquire) | 3236 |
| 5120-00-633-7122 | (Please Inquire) | 3237 |
| 5120-00-788-0186 | (Please Inquire) | 3238 |
| 5120-00-892-2062 | (Please Inquire) | 3239 |
| 5120-00-064-8590 | Wrench Spanner | 3240 |
| 5120-01-169-8482 | -3532 | 3244 |
| 5120-00-026-7063 | Wrench, Box | 3246 |
| 5120-00-542-2348 | (Please Inquire) | 3247 |
| 5120-01-156-7296 | (Please Inquire) | 3248 |
| 5120-00-435-8291 | (Please Inquire) | 3252 |
| 5120-00-505-8362 | (Please Inquire) | 3254 |
| 5120-00-511-0252 | (Please Inquire) | 3255 |
| 5120-00-788-1775 | (Please Inquire) | 3259 |
| 5120-00-026-7289 | Wrench, Spanner | 3262 |
| 5120-00-382-6918 | (Please Inquire) | 3263 |
| 5120-00-949-8913 | (Please Inquire) | 3268 |
| 5120-00-819-5827 | (Please Inquire) | 3270 |
| 5120-00-808-7910 | (Please Inquire) | 3271 |
| 5120-00-839-0969 | (Please Inquire) | 3272 |
| 5120-00-878-0624 | (Please Inquire) | 3273 |
| 5120-01-184-5725 | (Please Inquire) | 3276 |
| 5120-01-161-5911 | (Please Inquire) | 3277 |
| 5120-01-162-8325 | (Please Inquire) | 3279 |
| 5120-01-194-4033 | (Please Inquire) | 3280 |
| 5120-00-629-5641 | (Please Inquire) | 3284 |
| 5120-00-455-9890 | (Please Inquire) | 3285 |
| 5120-01-149-0018 | (Please Inquire) | 3288 |
| 5120-01-127-5142 | (Please Inquire) | 3293 |
| 5120-00-711-6753 | (Please Inquire) | 3296 |
| 5120-00-118-5808 | PUNCH DRIVE PIN | 3300 |
| 5120-00-008-5111 | Adjustment Tool | 3302 |
| 5120-01-077-7558 | (Please Inquire) | 3303 |
| 5120-00-949-8915 | (Please Inquire) | 3305 |
| 5120-00-590-1937 | (Please Inquire) | 3306 |
| 5120-01-072-2295 | (Please Inquire) | 3310 |
| 5120-00-289-0501 | (Please Inquire) | 3313 |
| 5120-01-147-7475 | (Please Inquire) | 3316 |
| 5120-00-972-6020 | (Please Inquire) | 3320 |
| 5120-00-100-4663 | SEA WATER BALL & POPPING VALVE | 3332 |
| 5120-01-175-0128 | (Please Inquire) | 3336 |
| 5120-01-071-3671 | (Please Inquire) | 3337 |
| 5120-00-117-4565 | TORQUE REACTOR ASSY | 3338 |
| 5120-00-224-9443 | (Please Inquire) | 3340 |
| 5120-00-221-2731 | (Please Inquire) | 3341 |
| 5120-01-197-2963 | (Please Inquire) | 3343 |
| 5120-00-455-9887 | (Please Inquire) | 3345 |
| 5120-01-024-1767 | (Please Inquire) | 3348 |
| 5120-00-473-7494 | (Please Inquire) | 3351 |
| 5120-00-473-7373 | (Please Inquire) | 3352 |
| 5120-01-158-7775 | (Please Inquire) | 3354 |
| 5120-00-541-1805 | (Please Inquire) | 3356 |
| 5120-00-252-0262 | (Please Inquire) | 3358 |
| 5120-00-867-5518 | (Please Inquire) | 3362 |
| 5120-01-127-2913 | (Please Inquire) | 3372 |
| 5120-00-380-8722 | (Please Inquire) | 3374 |
| 5120-01-166-7037 | (Please Inquire) | 3375 |
| 5120-01-166-7038 | (Please Inquire) | 3376 |
| 5120-00-627-3170 | (Please Inquire) | 3378 |
| 5120-00-083-4869 | PLIERS | 3379 |
| 5120-00-049-7878 | Adjuster, Spring | 3382 |
| 5120-01-018-7790 | (Please Inquire) | 3383 |
| 5120-01-202-2190 | (Please Inquire) | 3384 |
| 5120-00-134-5027 | WRENCH | 3387 |
| 5120-00-888-3362 | (Please Inquire) | 3388 |
| 5120-00-459-4490 | (Please Inquire) | 3389 |
| 4931-00-561-0836 | PIN,STRAIGHT,HEADLE | 3391 |
| 4931-00-561-0837 | PIN,STRAIGHT,HEADLE | 3392 |
| 5120-01-032-9182 | (Please Inquire) | 3398 |
| 5120-01-013-6178 | (Please Inquire) | 3399 |
| 5120-01-101-4250 | (Please Inquire) | 3400 |
| 5120-00-888-3365 | (Please Inquire) | 3401 |
| 5120-00-143-9393 | (Please Inquire) | 3402 |
| 5120-00-322-5954 | (Please Inquire) | 3403 |
| 5120-01-067-0636 | (Please Inquire) | 3406 |
| 5120-01-027-1107 | (Please Inquire) | 3407 |
| 5120-00-795-7617 | (Please Inquire) | 3410 |
| 5210-01-027-8446 | GAGE,BREECH SPACE | 3421 |
| 5120-00-113-4928 | BOX WRENCH | 3425 |
| 5120-00-277-1590 | (Please Inquire) | 3431 |
| 5120-00-277-1594 | (Please Inquire) | 3432 |
| 5120-00-277-8306 | (Please Inquire) | 3433 |
| 5120-00-891-6679 | (Please Inquire) | 3436 |
| 5120-01-025-0218 | <i>PART IS NO LONGER QUOTED</i> | 3439 |
| 5120-00-672-7403 | (Please Inquire) | 3440 |
| 5120-00-026-6374 | Lamp Changer | 3441 |
| 5120-00-033-0249 | Remover, Elec. | 3443 |
| 5120-00-927-6195 | (Please Inquire) | 3446 |
| 5120-00-150-7492 | (Please Inquire) | 3449 |
| 5120-01-043-7632 | (Please Inquire) | 3451 |
| 5120-00-176-8182 | (Please Inquire) | 3455 |
| 5120-01-029-3022 | (Please Inquire) | 3456 |
| 5130-00-048-3030 | (Please Inquire) | 3457 |
| 5120-00-049-7876 | Adjuster, Spring | 3462 |

| | | |
|------------------|-------------------------------|------|
| 5120-00-595-9307 | (Please Inquire) | 3464 |
| 5120-01-233-3545 | (Please Inquire) | 3465 |
| 5120-00-288-6491 | (Please Inquire) | 3469 |
| 5120-00-423-1599 | (Please Inquire) | 3470 |
| 5120-00-651-5591 | (Please Inquire) | 3471 |
| 5120-00-361-1800 | (Please Inquire) | 3474 |
| 5120-00-573-6338 | (Please Inquire) | 3476 |
| 5120-00-513-5924 | (Please Inquire) | 3479 |
| 5210-01-084-8100 | RING,TEST | 3480 |
| 5120-00-735-4701 | (Please Inquire) | 3483 |
| 5120-00-022-9783 | Wrench, Release Tool | 3484 |
| 5120-00-620-0020 | (Please Inquire) | 3485 |
| 5120-00-111-3565 | STACKING TOOL ASSY | 3491 |
| 5120-00-102-8670 | WRENCH, OPEN END | 3492 |
| 5120-00-624-7004 | (Please Inquire) | 3493 |
| 5120-01-161-1922 | (Please Inquire) | 3494 |
| 5120-00-142-7056 | (Please Inquire) | 3496 |
| 5120-00-716-8934 | (Please Inquire) | 3497 |
| 5120-00-473-7779 | (Please Inquire) | 3498 |
| 5120-00-216-7434 | (Please Inquire) | 3502 |
| 5120-00-380-8726 | WRENCH, SPANNER | 3510 |
| 5120-00-178-0854 | (Please Inquire) | 3526 |
| 5120-00-288-8715 | (Please Inquire) | 3529 |
| 5120-00-293-0096 | (Please Inquire) | 3532 |
| 5120-00-467-4878 | (Please Inquire) | 3534 |
| 5120-00-561-9917 | (Please Inquire) | 3541 |
| 5120-00-880-4604 | (Please Inquire) | 3542 |
| 5120-00-032-9461 | Wrench | 3545 |
| 5120-01-148-2422 | (Please Inquire) | 3546 |
| 5120-00-710-5815 | (Please Inquire) | 3548 |
| 5120-00-061-1283 | CAULKING GUN | 3549 |
| 5120-00-715-8467 | (Please Inquire) | 3558 |
| 5210-00-640-0337 | BLADE,THICKNESS GAG | 3564 |
| 5120-00-545-6123 | (Please Inquire) | 3567 |
| 5120-00-514-1407 | (Please Inquire) | 3568 |
| 5210-01-060-1491 | (Please Inquire) | 3578 |
| 5120-01-105-4110 | (Please Inquire) | 3591 |
| 5120-00-849-8179 | (Please Inquire) | 3592 |
| 5120-01-200-1842 | SPANNER WRENCH | 3595 |
| 5120-00-050-5740 | Hammer, Hand | 3601 |
| 5120-01-129-2138 | (Please Inquire) | 3614 |
| 5120-01-086-1603 | (Please Inquire) | 3616 |
| 5120-01-086-1602 | (Please Inquire) | 3617 |
| 5120-00-937-5474 | (Please Inquire) | 3618 |
| 5120-00-839-0974 | (Please Inquire) | 3620 |
| 5120-00-113-4738 | TAPER-LOC BOLT KNOCK OUT | 3623 |
| 5120-00-126-3863 | TAPER-LOC BOLT KNOCK OUT | 3624 |
| 5120-00-277-9811 | (Please Inquire) | 3625 |
| 5120-00-679-4460 | (Please Inquire) | 3626 |
| 5120-01-179-0023 | (Please Inquire) | 3629 |
| 5120-00-838-6882 | NO LONGER MANUFACTURING | 3633 |
| 5120-01-229-9134 | (Please Inquire) | 3638 |
| 5120-00-240-9769 | (Please Inquire) | 3652 |
| 5120-00-449-3877 | (Please Inquire) | 3653 |
| 5120-00-283-1911 | (Please Inquire) | 3654 |
| 5120-00-027-2051 | Key Set, Off Set | 3657 |
| 5120-00-585-8169 | | 3664 |
| 5120-00-264-3778 | (Please Inquire) | 3668 |
| 5120-00-288-6468 | (Please Inquire) | 3670 |
| 5120-00-464-6389 | (Please Inquire) | 3674 |
| 5120-01-163-4725 | (Please Inquire) | 3676 |
| 5120-01-219-6753 | (Please Inquire) | 3683 |
| 5120-00-888-3371 | (Please Inquire) | 3685 |
| 5120-00-759-9568 | (Please Inquire) | 3686 |
| 5120-00-594-0172 | (Please Inquire) | 3688 |
| 5120-00-240-5292 | (Please Inquire) | 3700 |
| 5120-00-080-9288 | ALLEN WRENCH | 3716 |
| 5120-00-684-7055 | (Please Inquire) | 3720 |
| 5120-00-935-4641 | (Please Inquire) | 3725 |
| 5120-00-198-5403 | (Please Inquire) | 3746 |
| 5120-00-116-9326 | STEP PLATE, MECH PULLER | 3750 |
| 5120-00-134-1995 | WRENCH | 3757 |
| 5120-00-015-1305 | Screw Key Blade, Socket Head | 3761 |
| 5120-00-015-1303 | Wrench, Allen | 3762 |
| 5120-00-015-1313 | Wrench, Allen | 3764 |
| 5120-00-740-3940 | (Please Inquire) | 3780 |
| 5120-00-293-9206 | (Please Inquire) | 3782 |
| 5120-00-072-5188 | WRENCH | 3787 |
| 5120-00-912-1085 | (Please Inquire) | 3789 |
| 5120-00-851-4247 | (Please Inquire) | 3790 |
| 5120-00-156-8735 | (Please Inquire) | 3800 |
| 5120-00-136-5334 | SAFETY TOOL | 3805 |
| 5120-01-202-0706 | (Please Inquire) | 3806 |
| 5120-00-892-2059 | (Please Inquire) | 3808 |
| 5120-00-106-5972 | CYLINDER LINBER REMOVING TOOL | 3813 |
| 5120-00-759-5048 | (Please Inquire) | 3815 |
| 5120-00-540-4346 | (Please Inquire) | 3816 |
| 5120-00-334-3085 | (Please Inquire) | 3819 |
| 5120-00-865-8975 | (Please Inquire) | 3820 |
| 5120-00-596-4496 | (Please Inquire) | 3825 |
| 5120-01-118-0770 | (Please Inquire) | 3828 |
| 5120-00-177-9422 | (Please Inquire) | 3829 |
| 5120-00-893-1736 | (Please Inquire) | 3830 |
| 5120-00-523-2250 | (Please Inquire) | 3831 |
| 5120-00-090-4422 | DRIVE TOOL | 3839 |
| 5120-00-996-2272 | (Please Inquire) | 3841 |
| 5120-00-115-5450 | CONTROL UNIT SOCKET | 3843 |
| 5120-00-860-6150 | (Please Inquire) | 3847 |
| 5120-00-345-1381 | (Please Inquire) | 3848 |
| 5120-00-345-1401 | (Please Inquire) | 3868 |
| 5120-00-345-1402 | (Please Inquire) | 3869 |
| 5120-00-345-1411 | (Please Inquire) | 3878 |
| 5120-00-345-1412 | (Please Inquire) | 3879 |
| 5120-00-345-1414 | (Please Inquire) | 3881 |
| 5120-00-345-1415 | (Please Inquire) | 3882 |
| 5120-00-345-1419 | (Please Inquire) | 3886 |
| 5120-00-345-1420 | (Please Inquire) | 3887 |
| 5120-00-345-1424 | (Please Inquire) | 3891 |
| 5120-00-345-1427 | (Please Inquire) | 3894 |
| 5120-00-345-1429 | (Please Inquire) | 3896 |
| 5120-00-345-1436 | (Please Inquire) | 3903 |
| 5120-00-345-1437 | (Please Inquire) | 3904 |
| 5120-00-345-1438 | (Please Inquire) | 3905 |
| 5120-00-345-1441 | (Please Inquire) | 3908 |
| 5120-00-345-1442 | (Please Inquire) | 3909 |
| 5120-00-345-1447 | (Please Inquire) | 3914 |

| | | |
|------------------|--------------------------------------|------|
| 5120-00-345-1448 | (Please Inquire) | 3915 |
| 5120-00-858-0969 | (Please Inquire) | 3918 |
| 5210-00-639-9683 | BLADE, THICKNESS GAG | 3920 |
| 5210-01-230-3088 | GAGE, DEPTH | 3921 |
| 5120-00-890-2867 | (Please Inquire) | 3924 |
| 5120-00-185-9371 | (Please Inquire) | 3927 |
| 5120-00-124-8449 | WRENCH, TORQUE | 3928 |
| 5110-00-132-3431 | STRIPPER, WIRE, HAND | 3931 |
| 5120-00-363-7543 | (Please Inquire) | 3932 |
| 5136-01-215-4760 | (Please Inquire) | 3934 |
| 5110-00-186-4190 | REAMER, HAND | 3935 |
| 5110-00-186-4212 | REAMER, HAND | 3936 |
| 5110-00-186-6702 | REAMER, HAND | 3937 |
| 5110-00-240-6023 | BAR, CHISEL | 3939 |
| 5110-00-277-9808 | PUNCH, CUTTING, SINGL | 3940 |
| 5120-00-152-1732 | (Please Inquire) | 3941 |
| 5120-00-357-8701 | (Please Inquire) | 3945 |
| 5120-00-473-7651 | (Please Inquire) | 3947 |
| 5120-00-554-7898 | (Please Inquire) | 3949 |
| 5120-00-381-7975 | (Please Inquire) | 3956 |
| 5120-00-723-0851 | (Please Inquire) | 3957 |
| 5120-00-277-3662 | (Please Inquire) | 3964 |
| 5120-01-221-3986 | (Please Inquire) | 3969 |
| 5120-01-238-7396 | (Please Inquire) | 3972 |
| 5120-00-278-0813 | (Please Inquire) | 3973 |
| 5120-00-277-7028 | (Please Inquire) | 3974 |
| 5120-00-467-5104 | (Please Inquire) | 3975 |
| 5120-00-467-5137 | (Please Inquire) | 3976 |
| 5120-00-467-5140 | (Please Inquire) | 3977 |
| 5120-00-467-5141 | (Please Inquire) | 3978 |
| 5120-00-467-5143 | (Please Inquire) | 3979 |
| 5120-00-959-7636 | (Please Inquire) | 3983 |
| 5120-00-999-1267 | (Please Inquire) | 3984 |
| 5120-01-164-1455 | (Please Inquire) | 3986 |
| 5120-01-214-8704 | (Please Inquire) | 3988 |
| 5120-00-384-6579 | (Please Inquire) | 3990 |
| 5210-01-230-3089 | GAGE, CORROSION | 3992 |
| 5180-00-289-9597 | (Please Inquire) | 3993 |
| 5120-00-073-9026 | EXTENSION, WRENCH, ANGLED | 3994 |
| 5120-00-303-5160 | (Please Inquire) | 3995 |
| 5120-00-380-9291 | (Please Inquire) | 3996 |
| 5120-01-164-7328 | (Please Inquire) | 3999 |
| 5120-01-249-6358 | (Please Inquire) | 4000 |
| 5120-00-381-9088 | (Please Inquire) | 4005 |
| 5120-00-381-7943 | (Please Inquire) | 4009 |
| 5120-00-167-8504 | (Please Inquire) | 4011 |
| 5120-00-554-7938 | (Please Inquire) | 4013 |
| 5120-00-112-8586 | SOCKET, HEX | 4015 |
| 5120-00-113-3432 | SOCKET WRENCH ATTACHMENT SCREWDRIVER | 4016 |
| 5120-00-126-4076 | SOCKET, SOCKET WRENCH | 4017 |
| 5120-00-403-5548 | (Please Inquire) | 4019 |
| 5120-00-935-4612 | (Please Inquire) | 4022 |
| 5120-01-070-8386 | (Please Inquire) | 4024 |
| 5120-00-230-7900 | (Please Inquire) | 4031 |
| 5120-01-047-0250 | (Please Inquire) | 4033 |
| 5120-00-034-3820 | Wrench | 4034 |
| 5120-00-467-5145 | (Please Inquire) | 4037 |
| 5120-00-467-5147 | (Please Inquire) | 4038 |
| 5120-00-555-0998 | (Please Inquire) | 4039 |
| 5120-00-659-6815 | (Please Inquire) | 4040 |
| 5120-00-221-2728 | (Please Inquire) | 4041 |
| 5120-00-650-7830 | (Please Inquire) | 4044 |
| 5120-01-210-9544 | (Please Inquire) | 4047 |
| 5120-01-210-9545 | (Please Inquire) | 4048 |
| 5120-01-215-9384 | (Please Inquire) | 4050 |
| 5120-01-245-7546 | (Please Inquire) | 4051 |
| 5120-01-251-8283 | (Please Inquire) | 4053 |
| 5210-00-158-4055 | GAGE, CANNON BORE ER | 4054 |
| 5110-00-070-0973 | CUTTER, CABLE, HAND | 4056 |
| 5120-00-069-8411 | INSERTER, CONTACT | 4060 |
| 5120-00-525-9290 | (Please Inquire) | 4061 |
| 5120-01-031-7647 | (Please Inquire) | 4062 |
| 5120-00-529-2727 | (Please Inquire) | 4064 |
| 5120-00-999-3488 | STRAIGHTENING TOOL, ELECT | 4065 |
| 5120-01-160-1319 | (Please Inquire) | 4074 |
| 5120-00-525-7244 | (Please Inquire) | 4075 |
| 5120-00-113-3329 | WRENCH, RELIEF VALVE | 4076 |
| 5110-00-693-6349 | CHISEL, COLD | 4077 |
| 5120-00-765-4345 | (Please Inquire) | 4081 |
| 5120-01-160-1026 | (Please Inquire) | 4083 |
| 5120-01-169-5415 | (Please Inquire) | 4085 |
| 5120-01-230-3090 | (Please Inquire) | 4086 |
| 5120-00-235-5913 | (Please Inquire) | 4087 |
| 5120-00-888-3363 | (Please Inquire) | 4099 |
| 5120-00-131-6473 | BUCKING BAR | 4104 |
| 5120-00-381-4034 | (Please Inquire) | 4105 |
| 5120-00-009-8602 | Wrench, Wheel Bearing | 4111 |
| 5120-00-227-0634 | (Please Inquire) | 4112 |
| 5120-00-227-0636 | (Please Inquire) | 4113 |
| 5120-00-004-4919 | PLATE (TOO BIG TO SCAN) | 4127 |
| 5120-01-077-2421 | (Please Inquire) | 4129 |
| 5120-00-117-3776 | Bearing Locknut Wrench Adapter | 4130 |
| 5120-00-125-9228 | RESET TOOL-ASSY | 4131 |
| 5120-00-043-0061 | Puller | 4133 |
| 5120-00-612-9717 | (Please Inquire) | 4134 |
| 5120-00-277-1216 | (Please Inquire) | 4137 |
| 5120-00-287-2508 | (Please Inquire) | 4138 |
| 5120-00-595-8423 | (Please Inquire) | 4139 |
| 5120-01-227-7042 | (Please Inquire) | 4141 |
| 5120-01-227-7043 | (Please Inquire) | 4142 |
| 5120-01-227-7044 | (Please Inquire) | 4143 |
| 5120-01-229-9135 | (Please Inquire) | 4144 |
| 5120-01-239-8202 | (Please Inquire) | 4149 |
| 5120-00-379-7807 | (Please Inquire) | 4151 |
| 5120-00-034-7626 | Adapter, Mech. Puller | 4155 |
| 5120-00-277-1482 | (Please Inquire) | 4156 |
| 5120-00-277-4068 | (Please Inquire) | 4157 |
| 5120-01-211-2672 | (Please Inquire) | 4161 |
| 5130-00-468-0849 | (Please Inquire) | 4162 |
| 5120-00-032-6192 | Wrench, Box | 4164 |
| 5120-00-004-9981 | Wrench, Torque | 4166 |
| 5120-00-006-2878 | Expander Puller | 4172 |
| 5120-00-751-9799 | (Please Inquire) | 4173 |
| 5120-00-861-7393 | (Please Inquire) | 4176 |
| 5120-01-161-1915 | (Please Inquire) | 4180 |
| 5120-00-277-2406 | (Please Inquire) | 4181 |

| | | |
|------------------|---------------------------|------|
| 5120-00-088-0099 | WRENCH ASSEMBLY | 4182 |
| 5120-01-075-1200 | (Please Inquire) | 4205 |
| 5120-01-075-9098 | (Please Inquire) | 4206 |
| 5120-00-219-8397 | (Please Inquire) | 4210 |
| 5120-00-150-7358 | (Please Inquire) | 4211 |
| 5120-00-094-1285 | ADAPTER-TORQUE WRENCH | 4212 |
| 5120-00-810-0107 | (Please Inquire) | 4216 |
| 5120-00-251-4499 | (Please Inquire) | 4217 |
| 5120-00-189-7896 | (Please Inquire) | 4224 |
| 5120-00-181-6765 | (Please Inquire) | 4227 |
| 5120-00-184-8385 | (Please Inquire) | 4245 |
| 5120-00-184-8398 | (Please Inquire) | 4252 |
| 5120-00-236-2261 | (Please Inquire) | 4253 |
| 5120-00-184-8401 | (Please Inquire) | 4255 |
| 5120-00-184-8403 | (Please Inquire) | 4257 |
| 5120-00-595-8213 | (Please Inquire) | 4258 |
| 5120-00-293-2567 | (Please Inquire) | 4262 |
| 5120-00-277-3661 | (Please Inquire) | 4277 |
| 5120-00-277-3664 | (Please Inquire) | 4278 |
| 5120-00-277-3665 | (Please Inquire) | 4279 |
| 5120-00-540-6735 | (Please Inquire) | 4284 |
| 5120-01-190-4940 | (Please Inquire) | 4301 |
| 5120-01-149-0019 | (Please Inquire) | 4305 |
| 5120-00-412-9119 | (Please Inquire) | 4314 |
| 5120-01-190-9828 | (Please Inquire) | 4320 |
| 5120-00-402-2172 | (Please Inquire) | 4323 |
| 5120-00-554-7827 | (Please Inquire) | 4328 |
| 5120-01-026-1666 | (Please Inquire) | 4329 |
| 5120-01-190-9423 | (Please Inquire) | 4330 |
| 5120-00-332-4219 | (Please Inquire) | 4337 |
| 5120-00-116-9401 | SPANNER WRENCH | 4356 |
| 5120-00-330-6575 | (Please Inquire) | 4357 |
| 5110-00-220-9534 | DIE,DIMPLING | 4358 |
| 5120-01-251-2685 | (Please Inquire) | 4364 |
| 5120-01-243-9267 | (Please Inquire) | 4366 |
| 5120-01-266-1940 | (Please Inquire) | 4368 |
| 5120-00-133-1203 | PUNCH, CRIMPING | 4373 |
| 5120-01-083-6729 | (Please Inquire) | 4379 |
| 5120-01-000-3556 | SLEEVE, GUIDING ASSEMBLY | 4390 |
| 5130-00-863-7987 | (Please Inquire) | 4400 |
| 5120-00-719-7663 | (Please Inquire) | 4402 |
| 5120-00-148-7981 | (Please Inquire) | 4403 |
| 5120-00-264-6849 | (Please Inquire) | 4405 |
| 5120-00-121-6840 | SOCKET SET, SOCKET WRENCH | 4407 |
| 5110-00-299-8441 | PUNCH,CUTTING.RECTA | 4408 |
| 5120-00-927-4043 | (Please Inquire) | 4413 |
| 5120-00-288-7791 | (Please Inquire) | 4417 |
| 5120-00-837-9263 | (Please Inquire) | 4419 |
| 5120-01-117-5543 | (Please Inquire) | 4426 |
| 5120-00-305-2306 | (Please Inquire) | 4428 |
| 5120-00-542-4171 | (Please Inquire) | 4429 |
| 5120-01-170-4036 | (Please Inquire) | 4431 |
| 5120-01-170-4035 | (Please Inquire) | 4432 |
| 5120-01-159-9307 | (Please Inquire) | 4433 |
| 5120-01-040-3732 | (Please Inquire) | 4442 |
| 5120-00-093-1528 | WRENCH, SOCKET | 4449 |
| 5120-00-102-8586 | SOCKET WRENCH ATTACHMENT | 4453 |
| 5120-00-044-7067 | Wrench, Socket Att. | 4454 |
| 5120-00-381-7075 | (Please Inquire) | 4461 |
| 5120-01-024-4017 | (Please Inquire) | 4462 |
| 5120-00-408-1474 | (Please Inquire) | 4464 |
| 5120-00-072-5330 | WRENCH | 4465 |
| 5120-00-049-7877 | Adjuster, Tool | 4470 |
| 5120-01-271-6290 | (Please Inquire) | 4471 |
| 5120-00-230-7888 | (Please Inquire) | 4475 |
| 5120-00-488-0441 | (Please Inquire) | 4476 |
| 5120-00-150-6971 | (Please Inquire) | 4478 |
| 5120-00-197-3330 | (Please Inquire) | 4479 |
| 5120-00-197-3901 | (Please Inquire) | 4480 |
| 5120-00-540-4328 | (Please Inquire) | 4481 |
| 5120-00-277-3660 | (Please Inquire) | 4483 |
| 5120-00-277-4835 | (Please Inquire) | 4488 |
| 5120-00-293-1207 | (Please Inquire) | 4490 |
| 5120-00-277-2311 | (Please Inquire) | 4491 |
| 5120-00-277-2312 | (Please Inquire) | 4492 |
| 5120-00-277-2307 | (Please Inquire) | 4493 |
| 5120-00-277-2308 | (Please Inquire) | 4495 |
| 5120-00-277-2342 | (Please Inquire) | 4496 |
| 5120-00-187-7123 | (Please Inquire) | 4498 |
| 5120-00-277-4834 | (Please Inquire) | 4499 |
| 5120-00-187-7124 | (Please Inquire) | 4500 |
| 5120-00-187-7126 | (Please Inquire) | 4501 |
| 5120-00-277-9517 | (Please Inquire) | 4503 |
| 5120-00-277-8301 | (Please Inquire) | 4504 |
| 5120-00-277-8299 | (Please Inquire) | 4506 |
| 5120-00-277-8300 | (Please Inquire) | 4507 |
| 5120-00-277-2309 | (Please Inquire) | 4512 |
| 5120-00-277-2310 | (Please Inquire) | 4513 |
| 5120-00-277-2693 | (Please Inquire) | 4515 |
| 5120-00-187-7133 | (Please Inquire) | 4516 |
| 5120-00-187-7134 | (Please Inquire) | 4518 |
| 5120-00-277-2694 | (Please Inquire) | 4519 |
| 5120-00-184-8438 | (Please Inquire) | 4520 |
| 5120-00-277-2695 | (Please Inquire) | 4522 |
| 5120-00-277-2321 | (Please Inquire) | 4523 |
| 5120-00-277-2322 | (Please Inquire) | 4525 |
| 5120-00-449-8141 | (Please Inquire) | 4526 |
| 5120-00-277-2324 | (Please Inquire) | 4527 |
| 5120-00-277-2325 | (Please Inquire) | 4528 |
| 5120-00-277-2326 | (Please Inquire) | 4529 |
| 5120-00-218-0616 | (Please Inquire) | 4535 |
| 5120-00-020-8632 | Combination Wrench | 4536 |
| 5120-00-230-7892 | (Please Inquire) | 4542 |
| 5120-00-460-2915 | (Please Inquire) | 4543 |
| 5120-00-412-5968 | (Please Inquire) | 4544 |
| 5120-00-884-8618 | (Please Inquire) | 4546 |
| 5120-00-837-9198 | (Please Inquire) | 4548 |
| 5120-01-159-9308 | (Please Inquire) | 4554 |
| 5120-01-160-1322 | (Please Inquire) | 4555 |
| 5120-00-197-3781 | (Please Inquire) | 4557 |
| 5120-01-042-0989 | (Please Inquire) | 4559 |
| 5120-00-224-3142 | (Please Inquire) | 4572 |
| 5120-00-264-5210 | (Please Inquire) | 4575 |
| 5120-00-264-5211 | (Please Inquire) | 4576 |
| 5120-00-264-5212 | (Please Inquire) | 4577 |
| 5120-00-264-5217 | (Please Inquire) | 4578 |

| | | |
|------------------|-----------------------|------|
| 5120-00-274-9653 | (Please Inquire) | 4579 |
| 5120-00-274-9655 | (Please Inquire) | 4580 |
| 5120-00-274-9657 | (Please Inquire) | 4581 |
| 5120-00-274-9658 | (Please Inquire) | 4582 |
| 5120-00-274-9661 | (Please Inquire) | 4583 |
| 5120-00-277-1582 | (Please Inquire) | 4584 |
| 5120-00-277-1583 | (Please Inquire) | 4585 |
| 5120-00-277-2291 | (Please Inquire) | 4586 |
| 5120-00-277-5781 | (Please Inquire) | 4587 |
| 5120-00-277-7582 | (Please Inquire) | 4588 |
| 5120-00-278-0634 | (Please Inquire) | 4589 |
| 5120-00-287-4164 | (Please Inquire) | 4590 |
| 5120-00-287-4165 | (Please Inquire) | 4591 |
| 5120-00-287-4167 | (Please Inquire) | 4592 |
| 5120-00-287-4168 | (Please Inquire) | 4593 |
| 5120-00-287-4169 | (Please Inquire) | 4594 |
| 5120-00-287-4170 | (Please Inquire) | 4595 |
| 5120-00-287-4171 | (Please Inquire) | 4596 |
| 5120-00-287-4172 | (Please Inquire) | 4597 |
| 5120-00-287-4527 | (Please Inquire) | 4598 |
| 5120-00-293-0674 | (Please Inquire) | 4614 |
| 5120-01-179-4837 | (Please Inquire) | 4632 |
| 5120-00-868-1815 | (Please Inquire) | 4634 |
| 5120-01-215-9383 | (Please Inquire) | 4638 |
| 5120-00-236-7590 | (Please Inquire) | 4640 |
| 5120-00-000-0291 | Handle, Socket Wrench | 4641 |
| 5120-00-065-4903 | HANDLE, SOCKET WRENCH | 4642 |
| 5120-00-000-0298 | Handle, Socket Wrench | 4643 |
| 5120-00-269-7971 | (Please Inquire) | 4652 |
| 5120-00-224-9219 | (Please Inquire) | 4663 |
| 5120-00-240-8702 | (Please Inquire) | 4665 |
| 5120-00-144-5207 | (Please Inquire) | 4666 |
| 5120-00-243-1689 | (Please Inquire) | 4672 |
| 5120-00-273-9205 | (Please Inquire) | 4677 |
| 5120-00-227-8074 | (Please Inquire) | 4679 |
| 5120-00-277-8079 | (Please Inquire) | 4681 |
| 5120-00-168-9826 | (Please Inquire) | 4683 |
| 5110-01-034-6377 | CUTTER | 4686 |
| 5110-01-034-6375 | CUTTER | 4687 |
| 5120-00-548-3448 | (Please Inquire) | 4689 |
| 5120-00-347-2329 | (Please Inquire) | 4690 |
| 5120-00-072-1498 | SCREWDRIVER HANDLE | 4693 |
| 5120-00-287-2507 | (Please Inquire) | 4700 |
| 5110-00-078-3957 | REAMER,HAND | 4706 |
| 5120-00-063-7173 | GRIP CABLE, WOVEN | 4709 |
| 5120-00-473-6450 | (Please Inquire) | 4715 |
| 5120-00-856-2622 | (Please Inquire) | 4717 |
| 5120-00-316-9170 | (Please Inquire) | 4724 |
| 5120-01-166-7026 | (Please Inquire) | 4727 |
| 5120-00-287-4677 | (Please Inquire) | 4729 |
| 5120-00-287-4678 | (Please Inquire) | 4730 |
| 5110-00-449-7383 | REAMER SET,HAND | 4732 |
| 5120-00-275-5837 | (Please Inquire) | 4736 |
| 5120-00-264-5206 | (Please Inquire) | 4737 |
| 5120-00-264-5207 | (Please Inquire) | 4738 |
| 5120-00-264-5208 | (Please Inquire) | 4739 |
| 5120-00-277-1475 | (Please Inquire) | 4740 |
| 5110-00-293-1263 | PUNCH,CUTTING,SINGL | 4743 |
| 5120-00-115-9185 | EXTRACTOR TOOL | 4744 |
| 5120-01-195-2777 | (Please Inquire) | 4745 |
| 5120-00-545-6107 | (Please Inquire) | 4746 |
| 5120-00-595-9445 | (Please Inquire) | 4753 |
| 5110-00-186-6780 | REAMER,HAND | 4756 |
| 5110-00-198-4289 | REAMER,HAND | 4762 |
| 5120-00-277-4067 | (Please Inquire) | 4764 |
| 5120-00-144-2092 | (Please Inquire) | 4768 |
| 5120-00-015-6957 | Wrench | 4769 |
| 5120-00-135-4869 | DRIFT | 4770 |
| 5120-00-133-2360 | BUSHING WRENCH | 4771 |
| 5120-00-595-9468 | (Please Inquire) | 4775 |
| 5120-00-277-1197 | (Please Inquire) | 4777 |
| 5120-01-022-1442 | (Please Inquire) | 4780 |
| 5120-01-223-7978 | (Please Inquire) | 4783 |
| 5120-01-288-4381 | (Please Inquire) | 4785 |
| 5120-00-026-7969 | Screw Driver, Off Set | 4786 |
| 5120-01-176-1803 | (Please Inquire) | 4788 |
| 5120-00-914-6707 | (Please Inquire) | 4790 |
| 5136-00-224-7120 | (Please Inquire) | 4792 |
| 5136-00-027-8721 | (Please Inquire) | 4793 |
| 5136-00-223-6638 | (Please Inquire) | 4797 |
| 5136-00-223-6640 | (Please Inquire) | 4798 |
| 5136-00-223-6641 | (Please Inquire) | 4799 |
| 5136-00-223-6647 | (Please Inquire) | 4801 |
| 5136-00-243-1535 | (Please Inquire) | 4813 |
| 5136-00-243-1538 | (Please Inquire) | 4815 |
| 5136-00-243-1540 | (Please Inquire) | 4817 |
| 5136-00-264-3776 | (Please Inquire) | 4822 |
| 5136-00-273-0148 | (Please Inquire) | 4823 |
| 5136-00-585-2381 | (Please Inquire) | 4833 |
| 5136-00-585-2382 | (Please Inquire) | 4834 |
| 5136-00-585-2412 | (Please Inquire) | 4835 |
| 5136-00-585-2419 | (Please Inquire) | 4837 |
| 5136-00-585-2421 | (Please Inquire) | 4838 |
| 5136-00-618-0516 | (Please Inquire) | 4842 |
| 5136-00-889-2090 | (Please Inquire) | 4847 |
| 5136-00-223-6228 | (Please Inquire) | 4868 |
| 5136-00-254-4518 | (Please Inquire) | 4905 |
| 5136-00-276-1031 | (Please Inquire) | 4908 |
| 5136-00-276-1032 | (Please Inquire) | 4909 |
| 5120-00-144-5508 | (Please Inquire) | 4918 |
| 5136-00-555-8910 | (Please Inquire) | 4922 |
| 5136-00-580-7182 | (Please Inquire) | 4935 |
| 5136-00-580-7184 | (Please Inquire) | 4936 |
| 5136-00-580-7186 | (Please Inquire) | 4937 |
| 5136-00-580-7188 | (Please Inquire) | 4938 |
| 5136-00-580-7343 | (Please Inquire) | 4943 |
| 5136-00-580-7359 | TAP, THREAD CUTTING | 4948 |
| 5136-00-580-7360 | (Please Inquire) | 4949 |
| 5136-00-708-0088 | (Please Inquire) | 4952 |
| 5136-00-729-5690 | (Please Inquire) | 4956 |
| 5136-00-729-5691 | (Please Inquire) | 4957 |
| 5136-00-729-5692 | (Please Inquire) | 4958 |
| 5136-00-729-5693 | (Please Inquire) | 4959 |
| 5136-00-729-5701 | (Please Inquire) | 4961 |
| 5136-00-729-5702 | (Please Inquire) | 4962 |
| 5136-00-585-2413 | (Please Inquire) | 4985 |

| | | |
|------------------|------------------------------|------|
| 5120-00-015-6958 | Wrench | 4986 |
| 5136-00-616-7299 | (Please Inquire) | 4989 |
| 5120-00-935-7366 | (Please Inquire) | 5002 |
| 5120-00-076-3270 | WRENCH | 5005 |
| 5120-00-081-9055 | SOCKET WRENCH ATTACHMENT | 5006 |
| 5120-00-103-9149 | SOCKET WRENCH | 5007 |
| 5120-00-132-0921 | SOCKET, SOCKET WRENCH | 5008 |
| 5120-00-892-4946 | (Please Inquire) | 5013 |
| 5120-00-723-0830 | (Please Inquire) | 5031 |
| 5120-00-935-4570 | (Please Inquire) | 5035 |
| 5120-00-346-6044 | (Please Inquire) | 5046 |
| 5110-00-596-0705 | BLADE SET,JEWELER'S | 5050 |
| 5110-01-034-6374 | MATERIAL CUTTER | 5051 |
| 5120-01-138-7560 | (Please Inquire) | 5055 |
| 5120-00-633-5085 | (Please Inquire) | 5063 |
| 5120-00-937-7266 | (Please Inquire) | 5064 |
| 5110-00-595-8234 | CUTTER, PIPE | 5065 |
| 5120-01-166-7020 | (Please Inquire) | 5070 |
| 5120-00-293-2562 | (Please Inquire) | 5082 |
| 5120-00-850-3315 | (Please Inquire) | 5083 |
| 5110-01-158-2657 | CHOPPING AX | 5087 |
| 5110-01-135-7112 | CONDUIT | 5088 |
| 5120-00-103-9766 | SOCKET WRENCH | 5089 |
| 5120-00-142-5233 | WRENCH SET, BOX | 5090 |
| 5120-00-177-7325 | (Please Inquire) | 5092 |
| 5120-00-467-5127 | (Please Inquire) | 5095 |
| 5120-00-880-4575 | (Please Inquire) | 5120 |
| 5120-00-316-9207 | (Please Inquire) | 5121 |
| 5120-00-906-6214 | (Please Inquire) | 5122 |
| 5120-00-708-1665 | (Please Inquire) | 5126 |
| 5120-01-166-7036 | (Please Inquire) | 5137 |
| 5180-00-313-9496 | (Please Inquire) | 5140 |
| 5120-00-787-7548 | (Please Inquire) | 5141 |
| 5120-00-671-2111 | (Please Inquire) | 5144 |
| 5120-00-670-3304 | (Please Inquire) | 5145 |
| 5120-00-303-7738 | (Please Inquire) | 5146 |
| 5120-00-020-2948 | Lift, Handle | 5147 |
| 5120-00-277-1195 | (Please Inquire) | 5149 |
| 5120-00-504-2436 | (Please Inquire) | 5150 |
| 5120-00-690-7254 | (Please Inquire) | 5153 |
| 5120-00-159-8180 | (Please Inquire) | 5154 |
| 5120-01-302-4387 | (Please Inquire) | 5156 |
| 5120-00-653-2354 | (Please Inquire) | 5157 |
| 5120-00-513-9279 | (Please Inquire) | 5158 |
| 5120-00-756-4975 | (Please Inquire) | 5160 |
| 5120-00-672-7426 | (Please Inquire) | 5172 |
| 5120-01-167-1134 | (Please Inquire) | 5196 |
| 5120-00-035-6143 | Wrench, Socket Att. | 5197 |
| 5120-00-111-5318 | REPLACEMENT KIT | 5198 |
| 5120-00-221-7957 | (Please Inquire) | 5206 |
| 5120-00-240-5364 | (Please Inquire) | 5207 |
| 5120-00-221-7960 | (Please Inquire) | 5212 |
| 5120-00-221-7958 | (Please Inquire) | 5213 |
| 5120-00-273-9203 | (Please Inquire) | 5217 |
| 5120-00-273-9208 | (Please Inquire) | 5221 |
| 5120-00-227-8079 | (Please Inquire) | 5223 |
| 5120-00-277-1207 | (Please Inquire) | 5226 |
| 5120-00-227-8103 | (Please Inquire) | 5227 |
| 5120-01-176-1828 | (Please Inquire) | 5231 |
| 5120-01-034-5033 | (Please Inquire) | 5233 |
| 5120-00-756-1195 | (Please Inquire) | 5235 |
| 5120-00-240-8898 | (Please Inquire) | 5236 |
| 5120-00-293-0448 | (Please Inquire) | 5237 |
| 5120-00-242-0763 | (Please Inquire) | 5238 |
| 5120-00-242-0764 | (Please Inquire) | 5240 |
| 5120-00-278-1264 | (Please Inquire) | 5245 |
| 5120-00-293-3509 | (Please Inquire) | 5248 |
| 5120-00-237-4956 | (Please Inquire) | 5249 |
| 5120-00-240-6082 | (Please Inquire) | 5251 |
| 5120-00-242-3435 | (Please Inquire) | 5252 |
| 5120-00-242-5966 | (Please Inquire) | 5253 |
| 5120-00-273-0001 | (Please Inquire) | 5259 |
| 5120-00-752-9031 | (Please Inquire) | 5262 |
| 5120-00-223-1016 | (Please Inquire) | 5264 |
| 5120-00-223-1017 | (Please Inquire) | 5265 |
| 5120-00-223-1018 | (Please Inquire) | 5266 |
| 5120-00-242-3433 | (Please Inquire) | 5268 |
| 5120-00-293-1408 | (Please Inquire) | 5269 |
| 5120-00-222-1906 | (Please Inquire) | 5271 |
| 5120-00-223-0989 | (Please Inquire) | 5272 |
| 5120-00-541-7704 | (Please Inquire) | 5277 |
| 5120-01-160-1029 | (Please Inquire) | 5278 |
| 5120-00-172-7801 | (Please Inquire) | 5280 |
| 5120-00-026-6663 | Wrench, Spanner | 5281 |
| 5120-00-026-7281 | Wrench, Spanner | 5282 |
| 5120-00-093-1546 | HANDLE | 5283 |
| 5120-00-269-4707 | (Please Inquire) | 5287 |
| 4820-01-152-3082 | EXTENSION LAPPING T | 5290 |
| 5120-00-144-2085 | (Please Inquire) | 5291 |
| 5120-01-045-4912 | (Please Inquire) | 5292 |
| 5120-00-690-7328 | (Please Inquire) | 5294 |
| 5120-00-071-5796 | HEX SOCKET-TYPE SPEED WRENCH | 5295 |
| 5120-00-104-1762 | KEY SOCKET HEAD SCREW | 5296 |
| 5120-01-170-3583 | (Please Inquire) | 5297 |
| 5120-00-026-7282 | Wrench, Box | 5298 |
| 5120-01-194-8931 | (Please Inquire) | 5305 |
| 5120-00-888-5829 | (Please Inquire) | 5311 |
| 5120-01-301-5783 | (Please Inquire) | 5313 |
| 5120-00-278-2425 | (Please Inquire) | 5315 |
| 5120-00-026-6664 | Wrench, Open End | 5317 |
| 5120-00-026-6665 | Wrench, Open End | 5318 |
| 5120-00-028-8502 | Wrench, Open End | 5319 |
| 5120-00-041-1471 | Spring Adjuster | 5320 |
| 5120-01-140-4972 | (Please Inquire) | 5322 |
| 5120-01-262-5401 | (Please Inquire) | 5324 |
| 5120-00-293-2925 | (Please Inquire) | 5328 |
| 5120-00-030-7942 | Puller, Mech. | 5330 |
| 5120-00-288-7711 | (Please Inquire) | 5331 |
| 5120-00-378-4293 | (Please Inquire) | 5332 |
| 5120-00-516-3120 | (Please Inquire) | 5337 |
| 5120-00-293-1429 | (Please Inquire) | 5341 |
| 5120-00-288-7713 | (Please Inquire) | 5342 |
| 5120-00-288-7714 | (Please Inquire) | 5343 |
| 5120-00-595-8424 | (Please Inquire) | 5345 |
| 5120-01-127-1127 | (Please Inquire) | 5347 |
| 5120-00-026-6667 | Wrench, Open End | 5350 |

| | | |
|------------------|-----------------------------|------|
| 5120-00-026-6668 | Wrench, Open End | 5351 |
| 5120-00-026-6666 | Wrench, Open End | 5352 |
| 5120-00-203-4811 | (Please Inquire) | 5353 |
| 5120-00-203-4810 | (Please Inquire) | 5354 |
| 5120-00-203-4809 | (Please Inquire) | 5355 |
| 5120-00-203-4808 | (Please Inquire) | 5356 |
| 5120-00-203-4807 | (Please Inquire) | 5357 |
| 5120-00-203-4806 | (Please Inquire) | 5358 |
| 5120-00-203-4804 | (Please Inquire) | 5359 |
| 5120-00-203-4799 | (Please Inquire) | 5360 |
| 5120-00-203-4792 | (Please Inquire) | 5361 |
| 5120-00-026-6403 | Wrench, Spanner | 5363 |
| 5120-00-945-1987 | (Please Inquire) | 5367 |
| 5120-00-088-4996 | PUSHER | 5369 |
| 5120-00-197-1303 | (Please Inquire) | 5370 |
| 5120-00-197-3785 | (Please Inquire) | 5371 |
| 5120-00-469-1810 | (Please Inquire) | 5376 |
| 5130-01-133-1739 | (Please Inquire) | 5381 |
| 5120-00-093-1052 | PLIERS | 5382 |
| 5120-00-540-0163 | (Please Inquire) | 5455 |
| 5120-00-277-8302 | (Please Inquire) | 5459 |
| 5120-00-277-1230 | (Please Inquire) | 5460 |
| 5120-00-830-5683 | (Please Inquire) | 5462 |
| 5120-00-288-9085 | (Please Inquire) | 5465 |
| 5120-00-087-6415 | KEY SET, SOCKET HEAD SCREW | 5479 |
| 5120-00-439-8988 | (Please Inquire) | 5483 |
| 5120-01-219-6752 | (Please Inquire) | 5494 |
| 5120-01-168-9472 | (Please Inquire) | 5497 |
| 5120-00-024-7632 | Spacer adapter | 5502 |
| 5120-01-105-2029 | WRENCH, BOX | 5505 |
| 5120-01-170-0618 | (Please Inquire) | 5508 |
| 5120-00-277-2323 | (Please Inquire) | 5509 |
| 5120-00-894-6540 | (Please Inquire) | 5510 |
| 5120-00-467-5142 | (Please Inquire) | 5512 |
| 5120-00-142-5327 | Handle Socket Wrench | 5513 |
| 5120-01-184-5752 | (Please Inquire) | 5514 |
| 5110-00-693-6344 | CHISEL,COLD,HAND | 5517 |
| 5110-00-221-1372 | CHISEL,COLD,HAND | 5518 |
| 5110-00-222-2127 | CHISEL,COLD,HAND | 5519 |
| 5110-00-238-8296 | CHISEL,DIAMOND POIN | 5520 |
| 5120-00-288-9707 | (Please Inquire) | 5526 |
| 5120-00-288-7769 | (Please Inquire) | 5538 |
| 5110-00-595-9490 | PLIERS,DIAGONAL CUT | 5541 |
| 5120-00-240-6217 | (Please Inquire) | 5543 |
| 5110-00-540-1693 | SAW,HAND,CROSSCUT | 5544 |
| 5110-00-277-2690 | SCRAPER,SHIP | 5545 |
| 5120-00-561-8021 | (Please Inquire) | 5552 |
| 5120-00-287-2502 | (Please Inquire) | 5557 |
| 5120-00-287-2503 | (Please Inquire) | 5558 |
| 5120-00-270-3112 | (Please Inquire) | 5559 |
| 5120-00-278-0340 | (Please Inquire) | 5565 |
| 5120-00-264-3794 | (Please Inquire) | 5568 |
| 5120-00-277-9086 | (Please Inquire) | 5570 |
| 5120-00-277-9087 | (Please Inquire) | 5571 |
| 5120-00-277-9089 | (Please Inquire) | 5572 |
| 5120-00-601-3386 | (Please Inquire) | 5578 |
| 5120-00-277-4833 | (Please Inquire) | 5581 |
| 5120-00-184-8621 | (Please Inquire) | 5582 |
| 5120-00-277-2327 | (Please Inquire) | 5583 |
| 5120-00-277-1322 | (Please Inquire) | 5584 |
| 5120-00-277-2328 | (Please Inquire) | 5585 |
| 5120-00-277-2329 | (Please Inquire) | 5587 |
| 5120-00-277-1324 | (Please Inquire) | 5591 |
| 5120-00-293-2121 | (Please Inquire) | 5592 |
| 5120-00-277-9818 | (Please Inquire) | 5593 |
| 5120-00-081-9099 | WRENCH, OPEN END | 5594 |
| 5120-00-770-2032 | (Please Inquire) | 5620 |
| 5120-00-277-9088 | (Please Inquire) | 5626 |
| 5120-00-633-5074 | (Please Inquire) | 5636 |
| 5120-00-337-1813 | (Please Inquire) | 5638 |
| 5120-00-980-2924 | BUSHING DRIVER SET | 5640 |
| 5120-01-034-6884 | (Please Inquire) | 5647 |
| 5120-00-251-9503 | (Please Inquire) | 5670 |
| 5120-00-137-9140 | INSTALLING TOOL | 5672 |
| 5120-00-018-0529 | Installing Tool | 5676 |
| 5120-00-018-0531 | Installing Tool | 5678 |
| 5120-00-103-9708 | REMOVAL TOOL | 5679 |
| 5120-00-018-0575 | Installing Tool | 5680 |
| 5120-00-132-6328 | INSTALLING AND REMOVAL TOOL | 5684 |
| 5120-00-132-5451 | INSTALLING AND REMOVAL TOOL | 5685 |
| 5120-00-132-5808 | INSTALLING AND REMOVAL TOOL | 5686 |
| 5120-00-079-4599 | INSTALLING TOOL | 5687 |
| 5120-00-079-4600 | INSTALLING TOOL | 5688 |
| 5120-00-079-4598 | INSTALLING TOOL | 5689 |
| 5120-00-079-4601 | REMOVER TOOL | 5691 |
| 5120-00-079-4602 | REMOVER TOOL | 5692 |
| 5120-00-079-9461 | REMOVER TOOL | 5693 |
| 5120-00-133-0367 | REMOVAL TOOL | 5696 |
| 5120-00-104-4066 | REMOVEL TOOL | 5697 |
| 5120-00-132-0396 | INSTALLING AND REMOVAL TOOL | 5698 |
| 5120-00-263-1137 | (Please Inquire) | 5702 |
| 5120-00-678-2431 | (Please Inquire) | 5708 |
| 5120-00-277-1463 | (Please Inquire) | 5734 |
| 5120-00-277-1464 | (Please Inquire) | 5735 |
| 5120-00-277-4252 | (Please Inquire) | 5739 |
| 5120-00-237-0978 | (Please Inquire) | 5746 |
| 5120-00-277-4251 | (Please Inquire) | 5753 |
| 5120-00-116-8197 | SPLINE KIT | 5765 |
| 5120-01-062-5607 | (Please Inquire) | 5766 |
| 5120-00-771-7015 | LIFTER | 5768 |
| 5120-00-611-7137 | (Please Inquire) | 5769 |
| 5120-00-690-7257 | (Please Inquire) | 5772 |
| 5120-01-179-4038 | (Please Inquire) | 5779 |
| 5120-01-117-1215 | (Please Inquire) | 5782 |
| 5120-00-711-8418 | (Please Inquire) | 5785 |
| 5120-01-161-2834 | (Please Inquire) | 5790 |
| 5120-01-144-8802 | (Please Inquire) | 5791 |
| 5120-00-098-4431 | ADAPTER | 5798 |
| 5120-01-296-5515 | (Please Inquire) | 5803 |
| 5120-01-094-1475 | (Please Inquire) | 5804 |
| 5130-00-863-7986 | (Please Inquire) | 5807 |
| 5120-00-277-8823 | (Please Inquire) | 5816 |
| 5120-00-277-1982 | (Please Inquire) | 5817 |
| 5120-00-061-9310 | SOCKET WRENCH | 5825 |
| 5120-00-066-3361 | SOCKET | 5846 |
| 5120-01-195-3086 | (Please Inquire) | 5849 |

| | | |
|------------------|-------------------------------------|------|
| 5120-00-565-9751 | (Please Inquire) | 5850 |
| 5120-01-064-0871 | (Please Inquire) | 5857 |
| 5120-00-050-8774 | Screw Driver, Spline | 5858 |
| 5120-00-795-0979 | (Please Inquire) | 5865 |
| 5110-00-520-9718 | REAMER | 5867 |
| 5110-00-520-9719 | REAMER | 5868 |
| 5120-00-016-3093 | Wrench | 5869 |
| 5110-00-200-6129 | CUTTER,CABLE,HAND O | 5874 |
| 5120-00-546-5934 | (Please Inquire) | 5876 |
| 5120-00-946-8708 | (Please Inquire) | 5877 |
| 5120-00-947-3945 | (Please Inquire) | 5878 |
| 5120-01-214-2920 | (Please Inquire) | 5882 |
| 5120-00-080-2429 | BIT SCREWDRIVER | 5884 |
| 5120-00-596-1370 | (Please Inquire) | 5889 |
| 5120-01-316-7527 | (Please Inquire) | 5890 |
| 5120-00-363-0960 | (Please Inquire) | 5891 |
| 5120-00-177-7281 | (Please Inquire) | 5897 |
| 5120-00-220-2481 | (Please Inquire) | 5898 |
| 5120-01-202-1709 | (Please Inquire) | 5900 |
| 5120-00-116-2395 | STAKE PULLER ASSY - TOOL KIT | 5904 |
| 5110-00-313-9488 | REAMER,HAND | 5906 |
| 5120-01-312-1267 | (Please Inquire) | 5907 |
| 5120-00-103-9785 | SOCKET SET, SOCKET WRENCH | 5911 |
| 5120-00-103-9791 | SOCKET WRENCH | 5912 |
| 5120-00-104-1720 | SOCKET WRENCH ATTACHMENT | 5913 |
| 5120-00-148-3705 | (Please Inquire) | 5914 |
| 5120-00-148-3706 | (Please Inquire) | 5915 |
| 5120-00-467-5128 | (Please Inquire) | 5923 |
| 5120-01-055-1308 | (Please Inquire) | 5953 |
| 5120-01-055-8681 | (Please Inquire) | 5954 |
| 5210-00-640-0351 | BLADE,THICKNESS GAG | 5960 |
| 5210-00-640-0336 | BLADE,THICKNESS GAG | 5961 |
| 5210-00-640-0338 | BLADE,THICKNESS GAG | 5962 |
| 5120-00-482-4177 | (Please Inquire) | 5967 |
| 5120-00-277-6631 | (Please Inquire) | 5972 |
| 5120-01-270-8979 | (Please Inquire) | 5974 |
| 5120-00-498-9077 | (Please Inquire) | 5979 |
| 5120-00-074-1685 | HYD-WING SECURING LATCH CYLINDER | 5982 |
| 5210-01-054-9934 | GAGE STICK,PETROLEU | 5991 |
| 5120-00-372-0652 | (Please Inquire) | 5992 |
| 5120-00-653-9552 | (Please Inquire) | 5993 |
| 5120-00-759-5053 | (Please Inquire) | 5994 |
| 5120-00-139-2524 | TOOL, SPRING INSERT | 5997 |
| 5120-00-678-7114 | (Please Inquire) | 5998 |
| 5120-01-255-0435 | (Please Inquire) | 6001 |
| 5120-01-271-6315 | (Please Inquire) | 6006 |
| 5120-01-272-4065 | (Please Inquire) | 6007 |
| 5120-00-049-7978 | Pin, Spanner | 6008 |
| 5120-00-045-6536 | Puller, Mech. | 6010 |
| 5120-00-372-5036 | (Please Inquire) | 6017 |
| 5120-01-199-0097 | (Please Inquire) | 6018 |
| 5120-00-672-7428 | (Please Inquire) | 6019 |
| 5120-00-839-8139 | (Please Inquire) | 6021 |
| 5120-00-776-1841 | (Please Inquire) | 6024 |
| 5120-00-104-0553 | NO DRAWING IN FOLDER | 6036 |
| 5120-00-684-0404 | (Please Inquire) | 6053 |
| 5110-00-220-9538 | DIE,DIMPLING | 6061 |
| 5120-00-720-1975 | (Please Inquire) | 6067 |
| 5120-00-113-8211 | WRENCH, TORQUE | 6074 |
| 5120-01-021-7406 | (Please Inquire) | 6078 |
| 5120-00-006-9499 | Key, Socket Head | 6083 |
| 5120-00-070-1135 | EXPANDER PISTON RING | 6084 |
| 5120-01-074-0792 | (Please Inquire) | 6085 |
| 5210-01-316-7433 | GAGE,HOSE | 6086 |
| 5120-00-001-9954 | Driver, Bearing & Bushing | 6087 |
| 5120-01-292-3895 | (Please Inquire) | 6088 |
| 5120-00-475-5414 | (Please Inquire) | 6090 |
| 5120-01-199-0098 | (Please Inquire) | 6095 |
| 5120-01-199-0099 | (Please Inquire) | 6096 |
| 5120-01-230-7370 | (Please Inquire) | 6101 |
| 5110-01-255-8242 | PIPE CUTTER | 6102 |
| 5120-01-190-8992 | (Please Inquire) | 6104 |
| 5120-00-073-8971 | GAGE, GAP SETTING | 6105 |
| 5120-00-060-6995 | STUD REMOVER & SETTER | 6115 |
| 5120-00-277-4071 | (Please Inquire) | 6117 |
| 5120-00-293-1289 | WRENCH SOCKET | 6122 |
| 5120-01-040-9318 | (Please Inquire) | 6126 |
| 4900-00-906-1065 | REMOVER ASSEMBLY,BE | 6127 |
| 5120-00-473-7471 | (Please Inquire) | 6129 |
| 5120-00-277-4581 | (Please Inquire) | 6139 |
| 5120-00-277-4583 | (Please Inquire) | 6140 |
| 5120-00-277-4584 | (Please Inquire) | 6141 |
| 5120-00-277-4586 | (Please Inquire) | 6143 |
| 5120-00-863-7742 | (Please Inquire) | 6144 |
| 5120-01-149-1391 | (Please Inquire) | 6145 |
| 5120-01-285-7620 | (Please Inquire) | 6146 |
| 5120-00-277-2682 | (Please Inquire) | 6147 |
| 5120-00-222-1596 | (Please Inquire) | 6149 |
| 5120-00-378-4254 | (Please Inquire) | 6158 |
| 5120-00-398-4080 | (Please Inquire) | 6159 |
| 5120-01-165-4676 | (Please Inquire) | 6161 |
| 5120-01-279-4788 | WRENCH | 6165 |
| 5120-00-004-9968 | Extraction Tool | 6167 |
| 5120-01-256-9186 | (Please Inquire) | 6168 |
| 5120-00-004-1303 | Contact Insertion Tool | 6170 |
| 5120-00-789-4881 | NO QUOTE! (WE NO LONGER HAVE MOLDS) | 6174 |
| 5340-00-708-3883 | HANDLE,MANUAL CONTR | 6175 |
| 5120-00-071-5799 | WRENCH - SPECIAL | 6178 |
| 5120-00-071-5801 | WRENCH - SPECIAL | 6179 |
| 5120-00-847-8415 | (Please Inquire) | 6181 |
| 5120-01-112-0549 | (Please Inquire) | 6194 |
| 5120-01-112-0574 | (Please Inquire) | 6202 |
| 5120-01-119-2569 | (Please Inquire) | 6247 |
| 5120-01-319-2349 | (Please Inquire) | 6256 |
| 5120-01-205-0754 | (Please Inquire) | 6257 |
| 5120-00-189-7931 | (Please Inquire) | 6267 |
| 5120-01-316-9805 | (Please Inquire) | 6284 |
| 5120-01-316-9806 | (Please Inquire) | 6291 |
| 5120-00-770-2030 | (Please Inquire) | 6296 |
| 5120-01-154-2015 | (Please Inquire) | 6299 |
| 5120-00-034-7632 | Spacer, Adapter Puller | 6303 |
| 5120-00-474-2747 | (Please Inquire) | 6304 |
| 5120-01-115-1722 | (Please Inquire) | 6312 |
| 5120-01-113-9559 | (Please Inquire) | 6318 |
| 5120-01-119-0007 | (Please Inquire) | 6322 |
| 5120-00-103-9783 | WRENCH SET, OPEN END | 6377 |

| | | |
|------------------|-------------------------------|------|
| 5120-01-067-3998 | (Please Inquire) | 6378 |
| 5120-01-019-7864 | (Please Inquire) | 6386 |
| 5120-01-087-3616 | (Please Inquire) | 6389 |
| 5120-01-111-2611 | (Please Inquire) | 6391 |
| 5120-00-126-7282 | KEY, SOCKET HEAD SCREW | 6403 |
| 5120-01-175-7134 | (Please Inquire) | 6405 |
| 5120-01-252-7067 | (Please Inquire) | 6407 |
| 5120-00-277-3667 | (Please Inquire) | 6412 |
| 5180-00-596-1504 | (Please Inquire) | 6414 |
| 5120-01-209-3175 | (Please Inquire) | 6419 |
| 5210-00-546-6362 | LEVEL, PLATE MOUNTED | 6421 |
| 5120-00-104-4076 | SOCKET, AXEL NUT | 6422 |
| 5120-01-042-0667 | (Please Inquire) | 6424 |
| 5120-00-034-7634 | Spacer, Adapter Puller | 6430 |
| 5120-00-596-0924 | (Please Inquire) | 6432 |
| 5120-01-170-5088 | (Please Inquire) | 6435 |
| 5120-00-590-8692 | (Please Inquire) | 6436 |
| 5120-01-096-3726 | (Please Inquire) | 6437 |
| 5120-00-119-6134 | EXTRACTOR, CARD-RADAR | 6441 |
| 5120-00-618-5320 | (Please Inquire) | 6442 |
| 5120-01-315-6602 | (Please Inquire) | 6443 |
| 5120-01-179-8995 | (Please Inquire) | 6445 |
| 5120-01-273-6980 | (Please Inquire) | 6446 |
| 5120-01-330-1959 | (Please Inquire) | 6447 |
| 5120-00-442-1086 | (Please Inquire) | 6451 |
| 5120-00-288-6504 | (Please Inquire) | 6452 |
| 5120-00-333-2184 | (Please Inquire) | 6455 |
| 5120-01-090-1249 | (Please Inquire) | 6457 |
| 5120-00-277-1211 | (Please Inquire) | 6460 |
| 5120-00-288-6489 | (Please Inquire) | 6461 |
| 5120-01-114-5482 | (Please Inquire) | 6470 |
| 5120-01-112-5031 | (Please Inquire) | 6477 |
| 5120-01-312-1268 | (Please Inquire) | 6506 |
| 5120-01-111-3322 | (Please Inquire) | 6510 |
| 5120-01-120-2894 | (Please Inquire) | 6516 |
| 5120-00-104-0107 | NO DRAWING IN FOLDER | 6517 |
| 5120-00-104-0117 | NO DRAWING IN FOLDER | 6518 |
| 5120-00-075-1064 | PULLER BEARING | 6557 |
| 5130-01-324-0366 | (Please Inquire) | 6558 |
| 5120-00-595-8134 | (Please Inquire) | 6569 |
| 5120-00-263-4136 | (Please Inquire) | 6572 |
| 5120-00-263-4137 | (Please Inquire) | 6573 |
| 5120-00-263-4138 | (Please Inquire) | 6574 |
| 5120-00-263-4139 | (Please Inquire) | 6575 |
| 5120-00-263-4140 | (Please Inquire) | 6576 |
| 5120-00-263-4141 | (Please Inquire) | 6577 |
| 5120-00-263-4142 | (Please Inquire) | 6578 |
| 5120-00-263-4143 | (Please Inquire) | 6579 |
| 5120-00-263-4144 | (Please Inquire) | 6580 |
| 5120-00-263-4145 | (Please Inquire) | 6581 |
| 5120-00-263-4146 | (Please Inquire) | 6582 |
| 5120-00-263-4147 | (Please Inquire) | 6583 |
| 5120-00-263-4148 | (Please Inquire) | 6584 |
| 5120-00-263-4149 | (Please Inquire) | 6587 |
| 5120-00-287-4150 | (Please Inquire) | 6588 |
| 5120-00-287-4151 | (Please Inquire) | 6589 |
| 5120-00-287-4152 | (Please Inquire) | 6590 |
| 5120-00-287-4153 | (Please Inquire) | 6591 |
| 5120-00-287-4154 | (Please Inquire) | 6592 |
| 5120-00-287-4155 | (Please Inquire) | 6593 |
| 5120-01-008-6150 | (Please Inquire) | 6616 |
| 5120-01-062-8310 | (Please Inquire) | 6619 |
| 5120-01-158-0841 | (Please Inquire) | 6624 |
| 5120-01-307-4127 | (Please Inquire) | 6625 |
| 5120-01-052-3604 | (Please Inquire) | 6626 |
| 5120-01-332-2498 | (Please Inquire) | 6628 |
| 5120-01-086-8472 | (Please Inquire) | 6629 |
| 5120-01-115-8154 | (Please Inquire) | 6632 |
| 5120-01-318-6323 | (Please Inquire) | 6641 |
| 5120-01-108-9652 | SCREW, JACKING | 6643 |
| 5120-01-333-9796 | (Please Inquire) | 6644 |
| 5120-00-078-2889 | SCREWDRIVER | 6647 |
| 5120-00-008-5594 | Freeze Tool | 6651 |
| 5120-00-104-6686 | PUNCH, DRIVE PIN | 6652 |
| 5120-00-104-6684 | PUNCH, DRIVE PIN | 6653 |
| 5120-00-104-6685 | PUNCH, DRIVE PIN | 6654 |
| 5120-00-274-3782 | (Please Inquire) | 6657 |
| 5120-00-883-1681 | (Please Inquire) | 6660 |
| 5120-00-111-3566 | REMOVER/INSTALLER ASSY | 6661 |
| 5120-00-049-7651 | Wrench | 6668 |
| 5120-00-937-7428 | (Please Inquire) | 6671 |
| 5120-00-111-3562 | O RING INSTALLATION TOOL | 6672 |
| 5120-01-096-3493 | (Please Inquire) | 6674 |
| 5120-01-113-9564 | (Please Inquire) | 6675 |
| 5120-01-122-3118 | (Please Inquire) | 6678 |
| 5120-00-989-0017 | (Please Inquire) | 6681 |
| 5120-00-055-5033 | PULLER ATTACHMENT, MECHANICAL | 6686 |
| 5120-01-283-0316 | (Please Inquire) | 6687 |
| 5210-01-083-2926 | GAGE STICK, PETROLEU | 6688 |
| 5120-01-331-9046 | (Please Inquire) | 6689 |
| 5120-01-172-8079 | (Please Inquire) | 6691 |
| 5120-00-078-2887 | ALIGNMENT TOOL | 6701 |
| 5120-00-134-7481 | INSTALLER | 6706 |
| 5120-00-061-4785 | SPANNER WRENCH | 6708 |
| 5120-01-340-2005 | (Please Inquire) | 6715 |
| 5120-00-228-9503 | (Please Inquire) | 6720 |
| 5120-00-228-9505 | (Please Inquire) | 6722 |
| 5120-00-228-9506 | (Please Inquire) | 6723 |
| 5120-00-228-9507 | (Please Inquire) | 6724 |
| 5120-00-228-9508 | (Please Inquire) | 6725 |
| 5120-00-228-9510 | (Please Inquire) | 6727 |
| 5120-00-228-9511 | (Please Inquire) | 6728 |
| 5120-00-228-9513 | (Please Inquire) | 6730 |
| 5120-00-228-9517 | (Please Inquire) | 6734 |
| 5120-00-228-9518 | (Please Inquire) | 6735 |
| 5120-00-228-9519 | (Please Inquire) | 6736 |
| 5120-00-277-8834 | (Please Inquire) | 6737 |
| 5120-00-065-1031 | PULLER ASSEMBLY | 6738 |
| 5120-00-077-2081 | WRENCH | 6751 |
| 5120-01-143-9317 | (Please Inquire) | 6757 |
| 5120-00-056-3931 | Wrench, Socket | 6763 |
| 5120-00-894-1725 | (Please Inquire) | 6767 |
| 5120-01-246-6102 | (Please Inquire) | 6769 |
| 5120-00-025-9995 | Regulator Handle | 6773 |
| 5120-00-242-8673 | (Please Inquire) | 6774 |
| 5120-00-422-4960 | (Please Inquire) | 6775 |

| | | |
|------------------|--------------------------------|------|
| 5120-00-708-3639 | (Please Inquire) | 6776 |
| 5120-00-752-9008 | (Please Inquire) | 6777 |
| 5120-00-935-7309 | (Please Inquire) | 6778 |
| 5120-00-322-6231 | (Please Inquire) | 6779 |
| 5120-00-247-0748 | (Please Inquire) | 6781 |
| 5120-00-077-1851 | WRENCH | 6784 |
| 5120-00-224-3155 | (Please Inquire) | 6795 |
| 5120-00-224-3156 | (Please Inquire) | 6796 |
| 5120-00-224-3158 | (Please Inquire) | 6798 |
| 5120-00-224-3159 | (Please Inquire) | 6799 |
| 5120-00-224-3160 | (Please Inquire) | 6800 |
| 5120-00-277-2696 | (Please Inquire) | 6807 |
| 5120-00-277-2697 | (Please Inquire) | 6808 |
| 5120-00-277-5072 | (Please Inquire) | 6809 |
| 5120-00-203-4805 | (Please Inquire) | 6815 |
| 5120-00-203-4794 | (Please Inquire) | 6821 |
| 5120-00-203-4793 | (Please Inquire) | 6822 |
| 5120-00-277-4069 | (Please Inquire) | 6823 |
| 5120-00-517-5347 | (Please Inquire) | 6825 |
| 5120-00-277-4064 | (Please Inquire) | 6828 |
| 5120-00-289-0539 | (Please Inquire) | 6829 |
| 5120-00-289-0537 | (Please Inquire) | 6830 |
| 5120-00-277-4066 | (Please Inquire) | 6831 |
| 5120-00-507-4886 | (Please Inquire) | 6832 |
| 5120-01-115-1183 | (Please Inquire) | 6837 |
| 5120-01-207-8440 | (Please Inquire) | 6845 |
| 5120-00-892-4947 | (Please Inquire) | 6846 |
| 5120-00-103-9726 | WRENCH | 6847 |
| 5120-00-081-9102 | WRENCH | 6861 |
| 5120-00-277-5071 | (Please Inquire) | 6866 |
| 5120-00-277-1801 | (Please Inquire) | 6869 |
| 5120-00-277-1802 | (Please Inquire) | 6871 |
| 5120-00-126-0753 | WRENCH, SPANNER | 6881 |
| 5120-00-112-9349 | BLADE, SOCKET HEAD SCREW | 6883 |
| 5133-01-266-1929 | (Please Inquire) | 6889 |
| 5120-01-120-3595 | (Please Inquire) | 6892 |
| 5120-01-310-1996 | (Please Inquire) | 6893 |
| 5120-00-203-4798 | (Please Inquire) | 6897 |
| 5120-00-189-7932 | (Please Inquire) | 6901 |
| 5120-00-261-2832 | (Please Inquire) | 6925 |
| 5120-00-261-2833 | (Please Inquire) | 6926 |
| 5120-00-261-2836 | (Please Inquire) | 6928 |
| 5120-00-261-2837 | (Please Inquire) | 6929 |
| 5120-00-261-2840 | (Please Inquire) | 6931 |
| 5120-00-261-2841 | (Please Inquire) | 6932 |
| 5120-00-261-2842 | (Please Inquire) | 6934 |
| 5120-00-261-2843 | (Please Inquire) | 6935 |
| 5120-00-261-2844 | (Please Inquire) | 6937 |
| 5120-00-261-2845 | (Please Inquire) | 6938 |
| 5120-00-261-2846 | (Please Inquire) | 6940 |
| 5120-00-261-2847 | (Please Inquire) | 6941 |
| 5120-00-261-2848 | (Please Inquire) | 6942 |
| 5120-00-261-2849 | (Please Inquire) | 6943 |
| 5120-00-261-2851 | (Please Inquire) | 6945 |
| 5120-00-261-2852 | (Please Inquire) | 6946 |
| 5120-00-080-7803 | SOCKET WRENCH | 6951 |
| 5120-00-094-2768 | DISCONNECT TOOL | 6952 |
| 5120-00-095-2955 | PUSH ROD COVER | 6953 |
| 5120-00-064-5326 | WRENCH | 6954 |
| 5120-00-116-7993 | WRENCH, OPEN END BOX | 6956 |
| 5120-00-104-1777 | KEY SOCKET HEAD SCREW | 6958 |
| 5120-01-135-0062 | (Please Inquire) | 6960 |
| 5120-01-143-4542 | (Please Inquire) | 6961 |
| 5120-00-081-9100 | WRENCH | 6964 |
| 5120-01-347-1884 | (Please Inquire) | 6967 |
| 5120-01-298-0326 | (Please Inquire) | 6974 |
| 5120-01-145-0348 | (Please Inquire) | 6977 |
| 5120-00-134-7464 | DRIVER, CRANKSHAFT | 6979 |
| 5110-00-278-1063 | SUPPORT RAMP ASSEMB | 6980 |
| 5120-00-146-1438 | (Please Inquire) | 6983 |
| 5120-00-134-7472 | PULLER, MECHANICAL | 6987 |
| 5120-00-146-1435 | (Please Inquire) | 6988 |
| 5120-00-034-0879 | Replacer | 6989 |
| 5120-00-034-0880 | Replacer | 6990 |
| 5120-00-278-1059 | (Please Inquire) | 6991 |
| 5120-00-034-0885 | Replacer | 6992 |
| 5210-01-099-1477 | GAGE,FAN ROTOR | 6994 |
| 5120-00-134-7463 | PULLER, CRANKSHAFT | 6995 |
| 5120-00-473-7739 | (Please Inquire) | 6996 |
| 5120-00-146-5555 | (Please Inquire) | 6997 |
| 5120-01-307-9653 | (Please Inquire) | 6999 |
| 5120-00-041-1472 | Bender, Switchboard | 7000 |
| 5120-00-240-7466 | (Please Inquire) | 7001 |
| 5120-00-313-3217 | (Please Inquire) | 7005 |
| 5120-00-176-3698 | (Please Inquire) | 7010 |
| 5120-00-658-2258 | (Please Inquire) | 7012 |
| 5120-00-223-8848 | (Please Inquire) | 7014 |
| 5120-00-034-0873 | Rod, Bearing Remover | 7016 |
| 5120-00-473-6542 | (Please Inquire) | 7022 |
| 5120-00-618-5305 | (Please Inquire) | 7023 |
| 5120-00-797-8494 | (Please Inquire) | 7024 |
| 5120-00-797-8495 | (Please Inquire) | 7025 |
| 5120-01-106-0085 | (Please Inquire) | 7029 |
| 5120-00-073-4765 | REMOVER | 7034 |
| 5120-00-345-8010 | (Please Inquire) | 7037 |
| 5120-00-033-0250 | Post, Elec. | 7040 |
| 5120-00-033-0251 | Post, Elec. | 7041 |
| 5120-00-045-7170 | Post, Elec. | 7042 |
| 5120-00-045-7171 | Handle | 7043 |
| 5120-00-045-7179 | Removal Tool | 7044 |
| 5120-00-020-0176 | Extraction Tool | 7046 |
| 5120-00-126-2833 | TOOL, MISC | 7048 |
| 5120-01-090-1251 | (Please Inquire) | 7051 |
| 5120-00-008-3738 | Lifter, Road Wheel | 7058 |
| 5120-00-222-1594 | (Please Inquire) | 7072 |
| 5120-00-222-1595 | (Please Inquire) | 7073 |
| 5120-00-776-1861 | (Please Inquire) | 7087 |
| 5120-00-146-9625 | (Please Inquire) | 7093 |
| 5130-01-103-2330 | (Please Inquire) | 7094 |
| 5120-00-116-9327 | ADAPTER, PULLER | 7096 |
| 5120-00-070-9452 | ADAPTER (BIG DRAWINGS IN FILE) | 7098 |
| 5120-00-026-7089 | Wrench, Spanner | 7099 |
| 5120-00-116-7543 | TWEEZERS | 7100 |
| 5120-01-135-1059 | (Please Inquire) | 7102 |
| 5120-01-112-3339 | (Please Inquire) | 7111 |
| 5210-00-529-0833 | (Please Inquire) | 7112 |

| | | |
|------------------|-------------------------------------|------|
| 5120-01-144-5323 | (Please Inquire) | 7124 |
| 5120-00-381-9090 | (Please Inquire) | 7126 |
| 5120-00-708-3253 | (Please Inquire) | 7130 |
| 5120-00-679-2380 | (Please Inquire) | 7133 |
| 5120-00-146-9627 | (Please Inquire) | 7135 |
| 5120-00-677-6564 | (Please Inquire) | 7136 |
| 5110-00-449-7315 | PUNCH,CUTTING,GASKE | 7142 |
| 5120-01-333-3178 | (Please Inquire) | 7150 |
| 5120-01-131-6898 | (Please Inquire) | 7158 |
| 5120-01-323-0969 | (Please Inquire) | 7187 |
| 5120-01-333-9798 | Wrench, Spanner | 7197 |
| 5120-01-333-9797 | Hook Wrench | 7198 |
| 5120-01-333-9794 | Face, Spanner, Adjustable | 7204 |
| 5110-00-111-6416 | KNIFE,CRAFTSMAN'S | 7205 |
| 5110-00-156-0130 | FILE,HAND | 7206 |
| 5120-00-131-9300 | Plug, Control Plate Link | 7208 |
| 5120-01-285-5198 | Torque Tool, Sensor Plug | 7209 |
| 5120-00-005-1097 | Wrench, Special Brake Adj. | 7211 |
| 5120-00-753-1282 | Tool, Tie Bolt Turning | 7212 |
| 5120-00-277-1581 | Wrench, Open | 7213 |
| 5120-00-203-6440 | Wrench, Open End | 7214 |
| 5120-00-293-0318 | Socket Wrench Alt., Screwdriver | 7215 |
| 5120-01-315-2795 | Puller Mechanical | 7219 |
| 5120-01-346-5424 | Tool Handle | 7221 |
| 5120-01-346-5425 | Tool Head | 7222 |
| 5120-00-605-3926 | (Please Inquire) | 7226 |
| 5110-00-062-5816 | PUNCH AND DIE,KNOCK | 7227 |
| 5110-00-224-9928 | SCRAPER,SHIP | 7228 |
| 5110-00-359-6479 | BLADE,KNIFE | 7229 |
| 5110-00-679-4669 | BLADE,KNIFE | 7230 |
| 5110-00-596-1152 | REAMER SET,HAND | 7231 |
| 5110-01-083-9317 | PLIERS | 7232 |
| 5110-01-283-9326 | PLIERS | 7233 |
| 5120-01-362-3333 | (Please Inquire) | 7240 |
| 5210-00-708-3769 | GAGE,THICKNESS | 7243 |
| 5120-00-065-4902 | Wrench, Crowfoot | 7256 |
| 5120-00-104-4844 | FORCEPS, CURVED | 7266 |
| 5120-00-263-3458 | (Please Inquire) | 7267 |
| 5120-00-169-7635 | (Please Inquire) | 7270 |
| 5120-00-071-5790 | HEX SOCKET-TYPE SPEED WRENCH | 7272 |
| 5120-00-095-3126 | WRENCH | 7273 |
| 5120-00-113-4160 | SPANNER WRENCH | 7274 |
| 5120-01-095-7450 | (Please Inquire) | 7282 |
| 5120-01-352-5530 | (Please Inquire) | 7288 |
| 5120-01-146-8096 | (Please Inquire) | 7291 |
| 5110-00-177-7287 | STRIPPER,WIRE,HAND | 7292 |
| 5110-00-169-4595 | PLIERS | 7293 |
| 5110-00-449-7317 | PUNCH,CUTTING,GASKE | 7294 |
| 5110-00-449-7318 | PUNCH,CUTTING,GASKE | 7295 |
| 5110-00-449-7319 | PUNCH,CUTTING,GASKE | 7296 |
| 5110-01-187-8442 | STRIPPER, WIRE HAND | 7297 |
| 5110-01-241-7591 | RIFFLER, DIE SINKERS | 7304 |
| 5110-00-764-5222 | CUTTER | 7308 |
| 5120-00-726-3796 | (Please Inquire) | 7311 |
| 5120-01-141-4612 | TOOL ADJUSTING, FRONT | 7312 |
| 5120-01-274-0842 | (Please Inquire) | 7314 |
| 5120-01-311-5431 | (Please Inquire) | 7315 |
| 5120-01-347-6257 | (Please Inquire) | 7316 |
| 5110-00-193-5012 | GOUGE,FIRMER | 7319 |
| 5110-00-263-0315 | HANDLE,SAW | 7320 |
| 5210-01-343-0996 | GAGE,CANNON BORE ER | 7324 |
| 5120-01-355-9564 | (Please Inquire) | 7327 |
| 5120-01-298-6116 | WRENCH, SOCKET | 7332 |
| 5120-00-678-5287 | WRENCH, BOX | 7336 |
| 5120-01-330-3776 | ADAPTER, TORQUE WRENCH | 7337 |
| 5120-00-003-9542 | WRENCH, RETAINER PLUG | 7339 |
| 5120-00-257-2766 | (Please Inquire) | 7340 |
| 5120-00-146-9628 | TOOL, REMOVER, SEAL, RETAINER | 7362 |
| 5120-01-140-8123 | WRENCH, OPEN END | 7363 |
| 5110-00-255-6086 | GOUGE,TURNING | 7365 |
| 5120-01-302-8232 | DRIVE, HEX HEAD | 7368 |
| 5120-00-289-9059 | (Please Inquire) | 7375 |
| 5120-00-289-9063 | (Please Inquire) | 7376 |
| 5110-00-188-0745 | REAMER,HAND | 7379 |
| 5120-01-011-3658 | (Please Inquire) | 7381 |
| 5120-00-137-9166 | WRENCH, SPANNER | 7384 |
| 5120-00-684-7051 | WRENCH | 7391 |
| 5210-01-364-3357 | GAGE BLOCK | 7403 |
| 5120-00-076-2355 | TORQUE WRENCH ADAPTER | 7405 |
| 5120-00-649-8140 | (Please Inquire) | 7407 |
| 5120-01-037-2527 | (Please Inquire) | 7409 |
| 5210-01-010-4260 | GAGE,HEIGHT HUB | 7414 |
| 5120-01-326-5156 | (Please Inquire) | 7415 |
| 5110-00-961-3488 | FILE, HAND | 7423 |
| 5110-00-186-4205 | REAMER,HAND | 7424 |
| 5110-00-186-4193 | REAMER,HAND | 7425 |
| 5110-00-194-6054 | REAMER,HAND | 7426 |
| 5110-00-260-1724 | REAMER,HAND | 7427 |
| 5110-00-268-1310 | REAMER,HAND | 7428 |
| 5110-00-883-9158 | CONDUIT | 7429 |
| 5110-01-016-1485 | CONDUIT | 7430 |
| 5110-00-293-2427 | HARDY | 7431 |
| 5110-00-595-9295 | REAMER,HAND | 7432 |
| 5120-00-283-1993 | (Please Inquire) | 7433 |
| 5120-01-355-0856 | (Please Inquire) | 7436 |
| 5120-00-114-1176 | INSTALLING TOOL, SEAT | 7437 |
| 5120-01-341-8701 | (Please Inquire) | 7438 |
| 5120-01-016-2149 | (Please Inquire) | 7440 |
| 5120-00-140-2424 | SEAL | 7442 |
| 5120-00-146-9635 | (Please Inquire) | 7449 |
| 5120-00-146-9638 | (Please Inquire) | 7450 |
| 5120-00-608-5558 | (Please Inquire) | 7460 |
| 5120-00-213-9710 | (Please Inquire) | 7463 |
| 5120-00-081-7319 | KEY SET, SOCKET HEAD | 7465 |
| 5120-01-115-1820 | (Please Inquire) | 7469 |
| 5110-00-752-9754 | SAW, HAND, CROSSCUT 24" BLADE | 7476 |
| 5110-00-177-7285 | STRIPPER, WIRE, HAND | 7478 |
| 5110-00-188-0739 | REAMER,HAND | 7479 |
| 5120-00-106-4318 | TYPE III SCREW STARTER | 7481 |
| 5110-00-289-0531 | SLOTTING TOOL,COMMU | 7483 |
| 5120-00-073-5679 | MAIN GEAR- DRAG BRACE | 7491 |
| 5120-01-373-8976 | (Please Inquire) | 7497 |
| 5120-00-622-4486 | (Please Inquire) | 7499 |
| 5120-00-116-2383 | BAR ASSY, FULLCRUM STAKE PULLER KIT | 7508 |
| 5120-00-142-5240 | WRENCH SET, OPEN END | 7513 |
| 1005-00-908-2414 | PLATE,LOCKING | 7522 |

| | | |
|------------------|--------------------------------|------|
| 1015-01-033-8372 | LEVER,GRIP | 7523 |
| 3040-00-566-3834 | CONNECTING LINK,RIG | 7524 |
| 5120-01-225-9797 | (Please Inquire) | 7528 |
| 5120-00-399-1154 | (Please Inquire) | 7532 |
| 5120-00-476-7232 | (Please Inquire) | 7533 |
| 5120-01-345-5330 | (Please Inquire) | 7536 |
| 5120-01-376-5125 | (Please Inquire) | 7541 |
| 5120-00-140-2425 | ADAPTER, TORQUE WRENCH | 7546 |
| 5110-00-220-9553 | PUNCH,DIMPLING | 7547 |
| 5110-00-254-3469 | HANDLE,CHISEL AND G | 7551 |
| 5130-01-355-0819 | (Please Inquire) | 7552 |
| 5120-00-065-5111 | ALIGNMENT TOOL | 7568 |
| 5120-00-146-9626 | (Please Inquire) | 7570 |
| 5120-01-344-1315 | (Please Inquire) | 7572 |
| 5120-00-888-5833 | (Please Inquire) | 7574 |
| 5120-00-105-0564 | CRANKSHAFT GEAR REMOVER | 7579 |
| 5120-00-127-7757 | HAMMER, HAND | 7580 |
| 5120-00-254-5021 | (Please Inquire) | 7581 |
| 5120-01-176-1845 | (Please Inquire) | 7601 |
| 5120-01-054-4048 | (Please Inquire) | 7606 |
| 5120-01-378-8867 | (Please Inquire) | 7610 |
| 5110-00-473-7833 | SCRAPER,SPRAY BOOTH | 7611 |
| 5110-00-595-9565 | SCRAPER | 7612 |
| 5110-00-804-5651 | KNIFE, CRAFTSMEN | 7613 |
| 5120-00-018-4241 | Standard Slot Screw Driver | 7614 |
| 5120-00-059-6326 | DOUBLE OPEN END WRENCH | 7615 |
| 5120-00-060-8369 | BOX WRENCH | 7616 |
| 5120-00-061-1996 | SOCKET RATCHET | 7617 |
| 5120-00-066-0242 | DOUBLE OPEN END WRENCH | 7618 |
| 5120-00-126-0167 | EXTENSION BAR | 7619 |
| 5120-00-126-0171 | SOCKET SET, SOCKET WRENCH | 7620 |
| 5120-00-272-8984 | (Please Inquire) | 7642 |
| 5110-00-273-8474 | CHISEL,CAPE,HAND | 7643 |
| 5120-00-274-9654 | (Please Inquire) | 7644 |
| 5120-00-277-9810 | (Please Inquire) | 7645 |
| 5120-00-287-4525 | (Please Inquire) | 7646 |
| 5120-00-287-4526 | (Please Inquire) | 7647 |
| 5120-00-288-6481 | (Please Inquire) | 7648 |
| 5120-00-473-7830 | (Please Inquire) | 7657 |
| 5120-01-373-4625 | (Please Inquire) | 7674 |
| 5120-01-376-7740 | (Please Inquire) | 7676 |
| 5120-00-070-1014 | PULLER | 7677 |
| 5120-00-070-1016 | INSTALLER, SEAL RING | 7678 |
| 5120-00-070-1018 | PULLER, GEAR & BEARING | 7679 |
| 5120-00-070-1019 | INSTALLER, GEAR | 7680 |
| 5120-00-113-1004 | REMOVER AND INSTALLER | 7681 |
| 5120-00-116-3652 | INSTALLER, THERMOSTAT | 7682 |
| 5120-01-272-1893 | (Please Inquire) | 7737 |
| 5120-00-278-7592 | (Please Inquire) | 7739 |
| 5110-00-145-8171 | STRIPPER,WIRE,HAND | 7746 |
| 5110-00-186-6690 | REAMER,HAND | 7747 |
| 5110-00-801-1431 | REAMER | 7748 |
| 5110-00-234-1423 | DRILL | 7749 |
| 5110-00-920-0371 | CONDUIT | 7750 |
| 5110-01-352-7277 | CUTTING PUNCH ASSY | 7752 |
| 5120-01-344-1016 | (Please Inquire) | 7753 |
| 1015-00-678-4296 | EXTRACTOR,CARTRIDGE | 7756 |
| 1015-00-678-4297 | EXTRACTOR,CARTRIDGE | 7757 |
| 5120-00-113-4166 | KEY SOCKET HEAD SCREW | 7765 |
| 5110-00-234-1923 | DRILL,MASONRY,HAND | 7767 |
| 5120-00-223-8484 | (Please Inquire) | 7768 |
| 5120-01-076-0001 | (Please Inquire) | 7780 |
| 5120-00-116-7989 | WRENCH, RATCHET | 7796 |
| 5120-01-355-0820 | (Please Inquire) | 7801 |
| 5120-01-368-3847 | (Please Inquire) | 7802 |
| 5120-00-097-8425 | SPANNER WRENCH, VISCOUS DAMPER | 7803 |
| 5120-01-389-9071 | (Please Inquire) | 7807 |
| 5120-01-128-2672 | (Please Inquire) | 7814 |
| 5120-00-446-2860 | (Please Inquire) | 7820 |
| 5110-00-062-5873 | PUNCH AND DIE,KNOCK | 7821 |
| 5110-00-062-5874 | PUNCH AND DIE,KNOCK | 7822 |
| 5110-00-148-9810 | STRIPPER,WIRE,BENCH | 7823 |
| 5110-00-186-4206 | REAMER,HAND | 7824 |
| 5110-00-186-6688 | REAMER,HAND | 7825 |
| 5110-00-293-0216 | PUNCH,CUTTING,SINGL | 7828 |
| 5110-00-186-4204 | REAMER, HAND | 7829 |
| 5110-00-056-5536 | FILE SET,HAND | 7834 |
| 5110-00-149-1425 | RIFFLER | 7835 |
| 5110-00-149-1426 | RIFFLER | 7836 |
| 5110-00-156-0114 | FILE,HAND | 7837 |
| 5110-00-293-1487 | FILE,HAND | 7838 |
| 5120-00-089-5518 | KEY, SOCKET HEAD SCREW | 7841 |
| 5120-00-740-0447 | (Please Inquire) | 7842 |
| 5110-00-490-4116 | BLADE, KNIFE, LIFE RAFT | 7844 |
| 5110-00-260-1644 | REAMER,HAND | 7845 |
| 5110-00-186-6710 | REAMER,HAND | 7847 |
| 5110-00-555-1784 | DRILL, RATCHET (NO DRAWING) | 7848 |
| 5120-00-261-2820 | (Please Inquire) | 7851 |
| 5120-01-376-5147 | (Please Inquire) | 7852 |
| 5120-00-240-1538 | (Please Inquire) | 7858 |
| 5120-00-261-2811 | (Please Inquire) | 7863 |
| 5120-01-355-0860 | (Please Inquire) | 7873 |
| 5120-01-271-6296 | (Please Inquire) | 7875 |
| 5120-00-223-8485 | (Please Inquire) | 7877 |
| 5120-00-509-2965 | (Please Inquire) | 7878 |
| 5120-01-368-1646 | Wrench, Plastic Box | 7882 |
| 5120-01-375-4373 | (Please Inquire) | 7883 |
| 5120-00-001-3733 | Torque Wrench | 7885 |
| 5120-00-892-6000 | (Please Inquire) | 7888 |
| 5110-00-186-6692 | REAMER,HAND | 7893 |
| 5110-01-051-4163 | KNIFE | 7895 |
| 5120-00-140-2421 | ADAPTER, TORQUE WRENCH | 7900 |
| 5110-00-764-1431 | REAMER, HAND | 7902 |
| 5110-00-945-8055 | CHISEL | 7903 |
| 5110-01-003-9357 | WIRE STRIPPER | 7904 |
| 5110-01-011-3881 | STRIPPER, WIRE HAND | 7905 |
| 5110-01-040-0077 | KNIFE, POCKET | 7906 |
| 5110-01-051-4136 | KNIFE, POCKET | 7907 |
| 5110-01-225-6691 | KNIFE, CRAFTSMANS | 7908 |
| 5110-01-200-5121 | PLIERS | 7909 |
| 5110-01-115-9222 | FILE | 7910 |
| 5120-01-363-6719 | (Please Inquire) | 7913 |
| 5120-01-387-5435 | SOCKET, SOCKET WRENCH | 7915 |
| 5110-01-040-6136 | SCISSORS | 7920 |
| 5120-00-140-2422 | ASSEMBLY TOOL, SEAL RING | 7927 |
| 5110-00-156-0197 | FILE,HAND | 7929 |

| | | |
|------------------|---------------------------------|------|
| 5110-00-186-4207 | REAMER,HAND | 7930 |
| 5110-00-186-8176 | CHISEL,TURNING | 7931 |
| 5110-00-203-6893 | FILE,HAND | 7932 |
| 5110-00-243-8099 | FILE,HAND | 7933 |
| 5120-00-146-9631 | (Please Inquire) | 7937 |
| 5120-01-383-7979 | (Please Inquire) | 7938 |
| 5120-00-677-2259 | (Please Inquire) | 7947 |
| 5120-01-390-4162 | (Please Inquire) | 7949 |
| 5110-00-293-1198 | DRILL,MASONRY,HAND | 7952 |
| 5120-00-137-9181 | WRENCH, SPANNER | 7953 |
| 5110-00-233-9709 | FILE,HAND | 7954 |
| 5110-00-541-4961 | REAMER,HAND | 7955 |
| 5120-01-333-9003 | (Please Inquire) | 7957 |
| 5120-00-278-0814 | (Please Inquire) | 7960 |
| 5120-00-278-0815 | (Please Inquire) | 7961 |
| 5120-00-112-9396 | BURNISHER | 7963 |
| 5120-00-038-7989 | Wrench | 7965 |
| 5120-01-386-6864 | (Please Inquire) | 7968 |
| 5120-01-372-9839 | (Please Inquire) | 7971 |
| 5120-00-034-7633 | Spacer, Adapter Puller | 7972 |
| 5120-00-140-2426 | ADAPTER, TORQUE | 7977 |
| 5120-00-062-5105 | PUNCH, DRIVE PIN | 7978 |
| 5110-00-516-3816 | REAMER,HAND | 7985 |
| 5120-00-071-5802 | HEX SOCKET-TYPE SPEED WRENCH | 7986 |
| 5120-01-151-8049 | (Please Inquire) | 7987 |
| 5120-00-188-3250 | (Please Inquire) | 7988 |
| 5110-00-232-6329 | REAMER,HAND | 7991 |
| 5110-00-265-0315 | HANDLE,SAW | 7992 |
| 5110-01-033-9360 | CONDUIT | 7993 |
| 5120-00-050-8247 | Wrench | 8000 |
| 5120-00-240-5336 | WRENCH | 8002 |
| 5120-01-383-6209 | (Please Inquire) | 8003 |
| 5120-01-372-5795 | (Please Inquire) | 8009 |
| 5120-00-678-6594 | (Please Inquire) | 8015 |
| 5120-00-012-5130 | Crimping Tool Terminal Hand | 8016 |
| 5120-00-020-5888 | Extractor | 8017 |
| 5210-01-259-9103 | GAGE,PULLOVER,ARTIL | 8025 |
| 5120-01-343-2021 | (Please Inquire) | 8038 |
| 5110-00-735-5872 | TOOL, SCRAPING | 8055 |
| 5120-00-072-4312 | WRENCH, SOCKET | 8056 |
| 5120-00-132-2109 | PUCH ROD ADJUSTING SET | 8057 |
| 5120-00-808-5230 | (Please Inquire) | 8061 |
| 5120-00-223-8486 | (Please Inquire) | 8083 |
| 5120-00-357-5183 | (Please Inquire) | 8084 |
| 5120-00-086-7447 | REVERSABLE DECK BOLT AND SOCKET | 8087 |
| 5120-00-948-3606 | (Please Inquire) | 8101 |
| 5120-01-115-1892 | (Please Inquire) | 8107 |
| 5110-01-374-0905 | BURNER REAMING TOOL | 8108 |
| 5120-01-170-3279 | (Please Inquire) | 8114 |
| 5120-00-012-3645 | Wrench, Socket Att. | 8133 |
| 5120-00-261-2827 | (Please Inquire) | 8135 |
| 5120-00-595-8190 | (Please Inquire) | 8138 |
| 5120-00-056-3940 | Wrench, Socket | 8141 |
| 5120-00-908-4754 | (Please Inquire) | 8152 |
| 5120-00-872-3920 | (Please Inquire) | 8158 |
| 5110-00-186-6693 | REAMER,HAND | 8165 |
| 5110-00-186-6704 | REAMER,HAND | 8166 |
| 5110-00-186-6712 | REAMER,HAND | 8167 |
| 5110-00-232-6343 | REAMER,HAND | 8168 |
| 5110-00-253-3190 | REAMER,HAND | 8175 |
| 5110-00-260-1646 | REAMER,HAND | 8176 |
| 5110-00-260-1647 | REAMER,HAND | 8177 |
| 5110-00-260-1708 | REAMER,HAND | 8178 |
| 5110-00-260-1715 | REAMER,HAND | 8179 |
| 5110-00-260-1717 | REAMER,HAND | 8180 |
| 5110-00-289-1011 | REAMER,HAND | 8181 |
| 5110-00-529-2014 | REAMER | 8182 |
| 5110-00-541-4962 | REAMER,HAND | 8183 |
| 5110-00-204-0720 | FILE,HAND | 8184 |
| 5110-00-243-8100 | FILE,HAND | 8186 |
| 5110-00-254-3468 | HANDLE,CHISEL AND G | 8187 |
| 5110-00-271-9943 | CHISEL,HALF ROUND N | 8188 |
| 5120-00-143-0801 | (Please Inquire) | 8189 |
| 5120-00-468-8117 | (Please Inquire) | 8190 |
| 5210-00-197-9679 | GAGE,THICKNESS | 8195 |
| 5120-01-324-0368 | (Please Inquire) | 8216 |
| 5120-01-152-1141 | (Please Inquire) | 8217 |
| 5120-00-072-5362 | WRENCH, FRICTION | 8223 |
| 5120-00-287-3619 | (Please Inquire) | 8224 |
| 5120-00-699-3589 | (Please Inquire) | 8229 |
| 5120-00-089-4852 | KEY, SOCKET HEAD SCREW | 8231 |
| 5120-00-150-7352 | (Please Inquire) | 8247 |
| 5120-00-132-0862 | PLIERS | 8248 |
| 5120-00-060-6423 | ALIGNMENT TOOL | 8249 |
| 5120-00-230-7902 | (Please Inquire) | 8253 |
| 5120-01-422-3325 | (Please Inquire) | 8254 |
| 5120-00-264-3779 | (Please Inquire) | 8260 |
| 5120-00-089-5517 | KEY, SOCKET HEAD SCREW | 8263 |
| 5120-00-473-8350 | (Please Inquire) | 8264 |
| 5120-00-251-1527 | (Please Inquire) | 8268 |
| 5110-00-595-8411 | KNIFE,TWINE,FINGER | 8270 |
| 5130-00-203-6424 | (Please Inquire) | 8275 |
| 5120-00-254-4612 | (Please Inquire) | 8276 |
| 5120-00-473-6283 | (Please Inquire) | 8277 |
| 5133-00-177-7332 | (Please Inquire) | 8278 |
| 5120-00-139-2223 | WRENCH, BOX OPEN-END | 8281 |
| 5120-00-973-0257 | (Please Inquire) | 8288 |
| 5120-00-103-9754 | WRENCH | 8294 |
| 5120-00-261-2815 | (Please Inquire) | 8299 |
| 5120-00-261-2816 | (Please Inquire) | 8300 |
| 5110-00-509-8062 | DIE,FASTENER ASSEMB | 8321 |
| 5120-01-358-2749 | (Please Inquire) | 8344 |
| 5120-01-358-2751 | (Please Inquire) | 8345 |
| 5120-00-840-7289 | (Please Inquire) | 8353 |
| 5120-01-043-8491 | (Please Inquire) | 8361 |
| 5120-00-025-0707 | Pin Spanner | 8368 |
| 5120-00-025-0708 | Pin Spanner | 8369 |
| 5120-00-025-0709 | Pin Spanner | 8370 |
| 5120-00-612-8199 | (Please Inquire) | 8376 |
| 5120-00-254-6626 | (Please Inquire) | 8400 |
| 5120-00-277-3600 | (Please Inquire) | 8411 |
| 5120-00-398-4195 | (Please Inquire) | 8413 |
| 5180-00-955-5623 | (Please Inquire) | 8417 |
| 5120-00-255-4458 | (Please Inquire) | 8422 |
| 5120-00-278-7590 | (Please Inquire) | 8423 |
| 5120-00-277-1200 | (Please Inquire) | 8427 |

| | | |
|---------------------------|---|------|
| 5120-00-136-9453 | WRENCH, NOZZLE CRUNCH BOLT | 8429 |
| 5120-00-542-4751 | (Please Inquire) | 8434 |
| 5120-00-072-5859 | BAR, TURNING | 8438 |
| 5110-00-186-7107 | CHISEL,COLD,HAND | 8443 |
| 5110-00-221-8132 | CHISEL,COLD,HAND | 8444 |
| 5110-00-234-1927 | CHISEL,COLD,HAND | 8445 |
| 5110-00-234-1944 | CHISEL,COLD,HAND | 8446 |
| 5110-00-236-3272 | CHISEL,COLD,HAND | 8447 |
| 5110-00-236-3273 | CHISEL,COLD,HAND | 8448 |
| 5110-00-357-5593 | CHISEL,SET,COLD,HAN | 8449 |
| 5120-00-133-0061 | INSERTION TOOL | 8466 |
| 5120-00-139-6147 | TOOL, CONTACT INSERTION | 8470 |
| 5120-00-223-1019 | (Please Inquire) | 8474 |
| 5120-00-223-1020 | (Please Inquire) | 8475 |
| 5120-00-227-0635 | (Please Inquire) | 8477 |
| 5120-01-452-5904 | SPANNER WRENCH | 8490 |
| 5210-01-455-2672 | ALIGNMENT TOOL,BRUS | 8492 |
| 5210-01-455-2673 | GAGE,INSTALLATION,B | 8497 |
| 5120-00-224-1389 | (Please Inquire) | 8502 |
| 5120-00-679-4459 | KEY SET, SOCKET HEAD SCREW | 8508 |
| 5110-00-223-1084 | CHISEL,FLOOR | 8509 |
| 5110-00-220-9551 | PUNCH,DIMPLING | 8513 |
| 5110-00-293-2865 | BLADE,KNIFE | 8522 |
| 5210-00-234-8949 | PLUMB BOB | 8527 |
| 5342-00-679-4361 | CAP,FILLER OPENING | 8528 |
| 5340-01-308-6175 | CLEVIS,ROD END | 8534 |
| 5120-01-480-0700 | (Please Inquire) | 8535 |
| 5340-01-045-4097 | CLEVIS,ROD END | 8537 |
| 5342-00-671-8004 | BRACKET,CYLINDER RO | 8538 |
| 5120-00-029-9163 | Wrench | 8540 |
| 5120-00-733-8948 | (Please Inquire) | 8541 |
| 5120-01-346-8960 | (Please Inquire) | 8544 |
| 5210-00-884-4840 | GAGE STICK,PETROLEU | 8545 |
| 5120-00-473-7316 | (Please Inquire) | 8552 |
| 5120-00-718-8742 | (Please Inquire) | 8553 |
| 5340-01-260-0715 | PLUG,VENT | 8568 |
| 5120-01-346-8944 | (Please Inquire) | 8574 |
| 5120-00-708-2774 | (Please Inquire) | 8576 |
| 5120-01-210-4757 | (Please Inquire) | 8579 |
| 5120-00-840-7288 | (Please Inquire) | 8580 |
| 5120-00-076-1766 | PULLEY, DOWELL PIN | 8584 |
| 5120-00-293-1610 | (Please Inquire) | 8585 |
| 5120-01-019-9564 | (Please Inquire) | 8587 |
| 5120-00-735-5871 | (Please Inquire) | 8588 |
| 5120-01-021-8664 | (Please Inquire) | 8590 |
| 5120-01-245-0813 | (Please Inquire) | 8591 |
| 5120-00-708-3799 | (Please Inquire) | 8595 |
| 5120-00-134-0072 | WRENCH, SPANNER | 8596 |
| 1730-00-787-1532 | ROD,PISTON,LINEAR A | 8598 |
| 5120-00-070-7809 | WRENCH, AIR COMP | 8600 |
| 5120-00-055-9255 | WRENCH, SPECIAL | 8601 |
| 5120-00-733-8982 | (Please Inquire) | 8602 |
| 5120-00-473-7591 | (Please Inquire) | 8603 |
| 5120-01-333-9799 | (Please Inquire) | 8604 |
| 5120-00-091-0756 | WRENCH SPECIAL | 8605 |
| 5340-00-351-3815 | CLEVIS,ROD END | 8606 |
| 5120-00-593-3830 | (Please Inquire) | 8607 |
| 5340-00-680-3126 | SEAT,HELICAL COMPRE | 8617 |
| 2520-01-214-3240 | DISK,CLUTCH | 8618 |
| 5120-01-444-5155 | Wrench, spanner | 8620 |
| 5120-01-138-4811 | Safety, slide tool | 8621 |
| 5340-01-183-8350 | COVER,ACCESS | 8623 |
| 2590-01-183-8368 | PLATE,WEAR CENTER | 8624 |
| 2510-00-425-0512 | BAR,COUNTER BALANCE | 8626 |
| 2990-00-932-3565 | FLANGE,EXHAUST PIPE | 8627 |
| 5120-00-312-8234 | Adapter, torque | 8629 |
| 5120-01-160-5027 | Wrench, spanner | 8632 |
| 5120-00-708-3256 | REMOVER ASSEMBLY | 8636 |
| 5120-01-006-8847 | Punch, drive pin | 8637 |
| 5120-00-084-7626 | Puller, Bearing | 8639 |
| 5120-01-047-3294 | Adapter, torque wren | 8640 |
| 5120-01-222-7939 | Replacer | 8641 |
| 2010-00-508-4649 | SHAFT,LOW SPEED | 8642 |
| 5120-01-170-1238 | Installer, Bearing | 8644 |
| 2530-00-798-5569 | RING,LOCK,AUTOMOTIV | 8648 |
| 5120-00-959-7633 | handling tool, detent. | 8649 |
| 4910-00-016-8837 | ADJUSTER,TIRE BEAD | 8654 |
| 5120-00-966-5962 | Wrench, rosan insert | 8656 |
| 5120-01-442-2309 | Spanner, Ring | 8657 |
| 5342-01-242-9652 | SPINDLE ASSEMBLY | 8658 |
| 5120-00-070-4888 | REMOVER ASM | 8659 |
| 3040-00-925-5232 | SHAFT,SHOULDERED | 8660 |
| 5120-01-086-1604 | WRENCH, SPANNER | 8661 |
| 5120-00-116-6136 | PLIERS ASM | 8665 |
| 5120-00-918-0586 | BAR,LIFTING | 8666 |
| 5120-00-708-3258 | REPLACER, UNIV | 8667 |
| 4730-00-741-1903 | CONNECTOR,MULTIPLE, | 8668 |
| 5120-01-356-8827 | LIFTER, RDWHEEL | 8669 |
| 5120-01-272-5640 | EXTRACTOR, SCRE | 8672 |
| 5120-01-206-0203 | WRENCH, SPANNER | 8673 |
| 5120-00-977-7421 | ADAPTER, TORQ | 8674 |
| 5120-00-062-9477 | WRENCH, SPANNER | 8676 |
| 5120-01-180-4104 | EXTENSION, DRIVE | 8677 |
| 5120-01-278-6889 | WRENCH, CROWFT | 8679 |
| 5120-01-138-3990 | SOCKET, SPL CROW | 8684 |
| 5120-00-144-2088 | CHUCK, STUD | 8685 |
| 5120-00-560-6593 | ADAPTER TORQUE | 8686 |
| 5120-01-057-7777 | EXTENSION, TORQU | 8688 |
| 5120-00-070-9152 | WRENCH, BARREL | 8689 |
| 5120-00-708-3642 | WRENCH, SOCKET | 8690 |
| 5120-00-793-5048 | PULLER, MECH | 8691 |
| 5120-00-078-2778 | PULLER, MECH | 8694 |
| 5120-00-918-0596 | PULLER, CONNECT | 8695 |
| 5120-01-005-2996 | HOLDING TOOL | 8696 |
| 5120-00-303-1195 | ADAPTER, STEER | 8697 |
| 5120-00-625-3885 | ADAPTER SET | 8698 |
| 5120-00-613-6775 | PULLER, MECH | 8699 |
| 5120-01-315-9152 | FIN INSTAL. TOOL | 8700 |
| 5120-01-315-9152 MODIFIED | FIN INSTALLATION TOOL, MODIFIED FOR LOCKH | 9617 |
| 5120-00-795-0152 | REPLACER, SEAL | 8701 |
| 5120-00-340-2013 | FIXTURE, TRACK | 8702 |
| 5120-01-034-1698 | WRENCH, FIL CAP | 8703 |
| 5120-00-759-7640 | WRENCH, TUB | 8704 |
| 5120-00-134-7459 | SOCKET, WRENCH | 8705 |
| 5120-01-209-3462 | TOOL, BREECH BLK | 8706 |
| 5120-01-261-5535 | WRENCH, SPL PURP | 8708 |

| | | |
|------------------|------------------------------|------|
| 5340-01-052-6749 | PLUNGER,DETENT | 8710 |
| 5342-00-975-0885 | SEAL HOUSING,TORPED | 8711 |
| 5120-01-493-9099 | INSTALLATION TOOL | 8712 |
| 5120-01-129-7408 | REMOVER, D.H. | 8717 |
| 5120-00-348-7505 | SOCKET, WRENCH | 8718 |
| 5120-00-473-7475 | INSERTER SEAL | 8722 |
| 5120-00-616-9841 | WRENCH, SPANNER | 8725 |
| 5120-00-977-5582 | WRENCH ASM, FACE | 8730 |
| 5120-01-357-2327 | WRENCH, SOCKET | 8731 |
| 5180-01-005-2995 | TOOL, GEN COUP | 8734 |
| 5120-00-021-5278 | WRENCH, BREECH | 8735 |
| 5120-01-485-1010 | TOOL, IMP HANDLE | 8739 |
| 5120-00-875-6681 | WISE WORK POSIT | 8742 |
| 5120-01-102-4627 | REPLACER, BRG | 8745 |
| 5120-01-206-0806 | DRIVER, BEARING | 8747 |
| 5120-00-058-8860 | PUNCH, DRIVE PIN | 8752 |
| 5120-01-023-4211 | SOCKET, WRENCH | 8754 |
| 5120-01-500-9990 | SOCKET, WRENCH | 8755 |
| 5120-01-501-0535 | SOCKET, WRENCH | 8756 |
| 1730-00-509-8182 | RELEASE ASSEMBLY,TR | 8757 |
| 5120-01-222-7952 | SOCKET, WRENCH | 8760 |
| 5120-01-230-0282 | SPANNER WRENCH | 8761 |
| 5120-01-484-7171 | PLATE, BLEED BALL | 8768 |
| 5120-01-487-6583 | CONNECTOR B.BALL | 8770 |
| 5120-01-203-3316 | SPANNER ATTACH. | 8774 |
| 5120-01-119-7240 | WRENCH SPANNER | 8775 |
| 5120-01-203-8658 | DRIVER ASM | 8779 |
| 5120-01-484-0415 | REMOVER, INSERT | 8780 |
| 5120-01-494-1165 | REMOVER, VALVE | 8781 |
| 5120-00-678-5282 | PULLER, MECH. | 8785 |
| 5120-01-195-7357 | WRENCH, ADAPTER | 8787 |
| 5120-13-112-9600 | WRENCH, SPANNER | 8792 |
| 3110-00-679-0083 | RING,BEARING,OUTER | 8794 |
| 5120-00-931-1464 | WRENCH | 8796 |
| 5120-00-615-8843 | LEVER, TORQUE | 8798 |
| 5120-00-227-0633 | LEGS, PULLER | 8799 |
| 5120-00-048-7370 | REMOVER/REPLACE | 8801 |
| 5120-01-020-2603 | TOOL, KEYLOCK | 8805 |
| 5120-01-366-0626 | HANDLE, SOCKET | 8808 |
| 5120-00-143-9383 | ROD, TOOL | 8809 |
| 5120-01-250-7244 | TOOL ASY NUT | 8811 |
| 5120-01-227-2284 | TOOL HOLDER | 8812 |
| 5120-01-100-0391 | WRENCH | 8813 |
| 5120-00-610-6719 | REPLACER | 8814 |
| 5120-00-610-3723 | WRENCH ASM | 8817 |
| 1005-00-653-5441 | ROD,CLEANING,SMALL | 8820 |
| 4940-00-928-0384 | ADAPTER TIP,EXTENSI | 8821 |
| 5120-01-323-5183 | WRENCH, CONN | 8823 |
| 5120-00-763-0922 | WRENCH SPANNER | 8825 |
| 5120-00-074-9953 | PULLER, MECH. | 8826 |
| 5120-01-337-7229 | WRENCH, SPAN | 8828 |
| 5120-00-939-0543 | INSERTER, SEAL | 8829 |
| 5120-00-977-5605 | ADAPTER, TORQUE | 8830 |
| 5120-01-115-4943 | WRENCH, TRUNNION | 8832 |
| 5120-01-048-8640 | SOCKET, WRENCH, FACE SPANNER | 8845 |
| 1730-01-389-9876 | R-BEARING,SLEEVE | 8846 |
| 5120-01-096-5027 | TONGUE LEVER TOOL | 8847 |
| 5120-01-132-0879 | LIFTING TOOL | 8852 |
| 5120-00-795-0079 | REPLACER, BEARING | 8854 |
| 5120-00-312-8401 | ADAPTER, TORQUE | 8857 |
| 5365-01-109-1580 | SPACER,AXLE,LANDING | 8859 |
| 1560-00-859-9709 | SUPPORT,STRUCTURAL | 8861 |
| 1270-01-193-4142 | CAM,SHORT | 8862 |
| 2915-01-501-5849 | TUBE ASSEMBLY,AIRCR | 8864 |
| 1290-01-046-8320 | SPACER,PLATE | 8865 |
| 1005-00-716-1301 | STOP,GUN,AUTOMATIC | 8866 |
| 5120-00-818-8642 | EXTENSION, HAND SCREWJACK | 8868 |
| 5120-00-740-3346 | REMOVER & REPLACER | 8870 |
| 5120-00-972-0205 | ADAPTER, TORQUE | 8871 |
| 5130-01-156-0442 | SOCKET, IMPACT | 8872 |
| 5120-00-318-7505 | INSERTER, BEARING | 8873 |
| 5120-01-039-1793 | WRENCH, SPANNER | 8875 |
| 5120-01-222-7938 | REPLACER | 8877 |
| 5120-00-873-6943 | PULLER, FUEL INJ NOZZLE | 8878 |
| 5120-00-329-6264 | SOCKET WRENCH | 8880 |
| 5120-01-266-1270 | INSERTER, SEAL | 8881 |
| 5120-01-101-2925 | TOOL, STUD EJECT | 8884 |
| 5120-01-487-4072 | WRENCH, SPANNER | 8890 |
| 5120-01-445-3283 | WRENCH, SPANNER | 8894 |
| 5120-01-445-0711 | WRENCH, SPANNER | 8895 |
| 5120-01-439-0427 | WRENCH, SPANNER | 8896 |
| 5120-00-771-7018 | REMOVER & REPLACER | 8901 |
| 5120-01-050-2070 | WRENCH, BOX | 8902 |
| 5120-00-933-7357 | ADAPTER, TORQUE | 8903 |
| 5120-00-733-8951 | INSERTER, SEAL | 8905 |
| 5120-00-767-9102 | ADAPTER, MECH PULLER | 8906 |
| 5120-01-132-0881 | SLEEVE TRACK | 8907 |
| 5120-00-318-7481 | INSERTER, BEARING | 8911 |
| 5120-01-379-0155 | EXTENSION, REPAIR | 8912 |
| 5120-01-496-2427 | WRENCH, TEE | 8913 |
| 5120-01-507-3583 | WRENCH, MAIN LANDING GEAR | 8921 |
| 5120-01-507-3584 | WRENCH, NOSE LANDING GEAR | 8922 |
| 5120-01-017-5238 | TOOL, INSERTER | 8925 |
| 5120-01-129-2537 | WRENCH, SPANNER | 8926 |
| 5120-01-024-8596 | WRENCH, BOX, SPECIAL | 8927 |
| 5120-01-285-5192 | PUNCH, BEARING | 8929 |
| 5120-01-017-7934 | WRENCH, ASM | 8930 |
| 5120-00-073-9435 | BODY, PUMP | 8931 |
| 5110-00-220-9552 | PUNCH,DIMPLING | 8933 |
| 5110-00-220-9536 | DIE,DIMPLING | 8934 |
| 5120-00-330-4274 | COMPRESSOR ASM | 8936 |
| 5120-00-733-8953 | INSERTER, SEAL | 8940 |
| 5120-01-266-1165 | SOCKET, SPANNER WRENCH | 8943 |
| 5120-01-255-9372 | WRENCH, TORQUE | 8945 |
| 5120-00-118-4467 | WRENCH, SPANNER | 8947 |
| 5120-01-151-8817 | ADAPTER, TORQUE | 8953 |
| 5120-00-708-3210 | PULLER, MECHANICAL | 8954 |
| 5120-00-771-7019 | REMOVER & REPLACER | 8959 |
| 5120-00-053-2603 | SOCKET, WRENCH | 8961 |
| 5120-01-375-6309 | WRENCH, SOCKET | 8963 |
| 5120-01-507-1620 | ROLLER, SHEAVE | 8964 |
| 5120-01-242-7218 | HANDLE, SOCKET WRENCH | 8968 |
| 5120-00-075-1039 | WRENCH, NUT SHAFT ASSY | 8970 |
| 5120-01-041-2159 | WRENCH SPANNER | 8971 |
| 5120-01-429-8137 | HANDLE | 8976 |
| 5120-00-471-3610 | REMOVING TOOL | 8977 |

| | | |
|------------------|-----------------------------------|------|
| 5120-00-906-1051 | SOCKET, SOCKET WRENCH | 8978 |
| 5120-00-153-2808 | WRENCH, SPANNER | 8981 |
| 5120-00-575-7767 | SPREADER ASM | 8983 |
| 5120-01-494-7672 | BAR TOOL | 8985 |
| 5120-00-051-5567 | WRENCH, BOX | 8986 |
| 5120-01-095-6912 | HOLDER, SLEEVE | 8987 |
| 5120-00-473-7761 | WRENCH, SPANNER | 8988 |
| 5120-01-115-4920 | EXTRACTOR, TORSION BAR | 8993 |
| 5120-01-102-4628 | TOO, SHOCK ABSORBER | 8994 |
| 2510-01-395-6020 | HINGE,HATCH,VEHICUL | 8996 |
| 5120-01-203-7483 | ADAPTER, TORQUE WRENCH | 8997 |
| 5120-01-450-2330 | ADAPTER, MECH | 9001 |
| 5120-01-207-5984 | WRENCH, SPANNER | 9004 |
| 5120-01-242-6796 | INSERTER, SEAL | 9005 |
| 5120-00-723-0275 | WRENCH SPANNER | 9011 |
| 5120-00-880-4264 | WRENCH SPANNER | 9014 |
| 5120-00-078-3809 | CROWFOOT ATTACHMENT | 9017 |
| 5120-00-061-1301 | JACK, HYD, HAND | 9024 |
| 5120-00-966-5963 | INSERTER, BEARING | 9026 |
| 5120-00-769-0687 | WRENCH, VALVE SEAT | 9040 |
| 5120-00-678-2796 | REPLACER | 9042 |
| 5120-00-084-7627 | REMOVER/REPLACER | 9043 |
| 5340-01-485-1685 | NUT LOCKING CONTROL | 9046 |
| 4820-01-474-6330 | ARM,FLOAT,VALVE | 9047 |
| 5120-01-066-3849 | SOCKET, SOCKET WRENCH | 9055 |
| 5120-01-066-3851 | SOCKET, SOCKET WRENCH | 9058 |
| 5120-01-067-6168 | SOCKET, SOCKET WRENCH | 9059 |
| 1015-01-198-7574 | PULLER ASSEMBLY,CAM | 9062 |
| 5120-01-115-1893 | ADAPTER | 9065 |
| 1560-01-232-8816 | STOP,ARRESTING HOOK | 9067 |
| 5120-01-060-0348 | TOOL, FUSE REMOVAL | 9068 |
| 5120-00-374-2578 | BOLT PULLER | 9069 |
| 5120-01-170-1925 | INSTALLING TOOL | 9073 |
| 5120-01-127-6313 | INSTALLER, BEARING | 9074 |
| 5120-00-079-0155 | REPLACER, COMPANION FLANGE | 9077 |
| 5120-00-610-6720 | REPLACER ASSEMBLY | 9078 |
| 4910-00-870-2127 | ADAPTER,CYLINDER CO | 9081 |
| 5120-00-068-7238 | COMPRESSOR RING | 9082 |
| 5180-00-762-1737 | TOOL KIT, GEN MECH | 9100 |
| 5120-01-483-7455 | WRENCH, SOCKET | 9101 |
| 5120-00-722-4093 | REPLACER, BEARING | 9105 |
| 5120-00-931-7288 | WRENCH, SCARFING | 9112 |
| 5120-00-118-4402 | WRENCH, SPANNER | 9115 |
| 5220-01-259-9100 | PULLOVER GAGE-57MM | 9118 |
| 5210-01-259-9104 | PULLOVER GAGE -105MM | 9120 |
| 5210-01-259-9105 | PULLOVER GAGE -120MM | 9121 |
| 5210-01-259-9107 | PULLOVER GAGE -155MM | 9122 |
| 5120-01-533-4088 | WRENCH, STEM | 9123 |
| 5120-00-866-5850 | WRENCH, PIPE | 9127 |
| 5120-00-775-3744 | WRENCH, SPANNER | 9128 |
| 1730-00-155-6088 | PIN,GROUND SAFETY | 9132 |
| 1730-00-369-9490 | ADAPTER,AIRCRAFT JA | 9133 |
| 5120-01-505-1677 | WRENCH | 9135 |
| 5120-01-266-1271 | TOOL, SEAL INSTALLER | 9136 |
| 5120-01-137-9572 | SOCKET,SOCKET WRENCH | 9138 |
| 5120-00-933-6057 | COMPRESSOR ASSEMBLY | 9141 |
| 5180-01-545-9967 | FIELD MAINT SPECIAL KIT | 9143 |
| 5130-01-459-8266 | COVER | 9144 |
| 5120-00-678-5052 | BIT, HEX TIP | 9145 |
| 5120-01-375-9253 | WRENCH, SOCKET | 9146 |
| 5120-00-077-2240 | WRENCH, SLEDGING | 9147 |
| 5120-00-077-2241 | WRENCH, BOX | 9148 |
| 5120-01-256-4326 | WRENCH, HEADSCREW | 9151 |
| 5120-00-293-0159 | DRIFT PIN | 9158 |
| 5120-00-708-3246 | REMOVER/REPLACER | 9159 |
| 3040-00-725-3850 | END FITTING,FLEXIBL | 9164 |
| 5120-00-561-0855 | WRENCH, SPANNER | 9169 |
| 5120-01-501-4269 | WRENCH, RATCHET | 9171 |
| 5120-01-519-0361 | WRENCH | 9172 |
| 5120-01-358-2927 | HANDLING TOOL | 9174 |
| 5120-00-110-4235 | PULLER, MECHANICAL | 9175 |
| 5120-00-710-8075 | REMOVER, SHOCK ABS | 9178 |
| 5120-00-179-5667 | ADJUSTING TOOL | 9183 |
| 5120-00-113-4921 | KEY ARM SPANNER | 9184 |
| 3040-00-671-9084 | SHAFT, SHOULDRED | 9185 |
| 5120-00-140-1835 | COCKING TOOL | 9188 |
| 5120-00-869-3600 | ADAPTER, WELDMENT | 9190 |
| 5220-01-259-9108 | CANNON BORE GAGE | 9192 |
| 5120-01-095-1138 | DRIVER HEX HEAD | 9199 |
| 5120-01-492-6139 | WRENCH SOCKET SPANNER | 9202 |
| 5120-01-492-6137 | WRENCH SOCKET SPANNER | 9203 |
| 5120-01-492-6138 | WRENCH SOCKET SPANNER | 9204 |
| 5120-01-041-4624 | FIX, ASM TRACK | 9206 |
| 5120-00-572-8615 | REPLACER, SEAL BEARING | 9208 |
| 1005-01-531-1676 | ADAPTER ASM | 9215 |
| 5120-01-115-1811 | INSTALLING TOOL | 9216 |
| 5120-01-355-1862 | HANDLE,SOCKET WRENCH | 9217 |
| 5120-01-507-0430 | WRENCH | 9218 |
| 5120-01-352-5676 | TOOL CANISTER RETAINING | 9219 |
| 5120-00-104-2628 | INST & REMOVAL TOOL | 9220 |
| 5120-00-024-7210 | PICK, BODY & FENDER REPAIR | 9222 |
| 5120-01-560-1915 | SOCKET, WRENCH | 9225 |
| 5120-00-400-7187 | WISE, MULTI POST. | 9229 |
| 5120-01-453-4889 | WRENCH, SOCKET | 9230 |
| 5120-01-211-2772 | ADAPTER, TORQUE WRENCH | 9231 |
| 5120-01-297-0659 | SOCKET, SOCKET WRENCH | 9236 |
| 5220-00-916-9437 | GAGE, LENGTH | 9237 |
| 2540-01-267-2912 | TOW BAR | 9245 |
| 5180-01-330-3769 | FILTER CHANGE TOOL KIT | 9246 |
| 5120-01-433-4829 | WRENCH-- LABOR ONLY | 9249 |
| 1015-01-203-3346 | BAR AMMUNITION RACK | 9252 |
| 1005-00-716-1300 | LOCK, ACCELERATOR STOP | 9253 |
| 2520-01-261-1718 | UNIVERSAL JOINT, LOWER STR COLUMN | 9254 |
| 5130-01-470-7372 | SOCKET WRENCH | 9255 |
| 4030-01-124-6328 | EYE LIFTER | 9257 |
| 5120-01-013-1676 | SLIDE HAMMER | 9260 |
| 1015-00-923-4257 | SOCKET BASE PLATE | 9261 |
| 4940-01-496-5146 | SPLITTER BALL JOINT | 9264 |
| 4940-01-496-5133 | YOKE HOLDING | 9265 |
| 4910-01-559-7072 | SEAL DRIVERS | 9271 |
| 2590-01-559-6860 | SPANNER SOCKET | 9272 |
| 5120-01-559-7459 | CAB SUPORT TOOL | 9273 |
| 2590-01-559-6922 | TRANS LIFT BRACKET | 9275 |
| 5120-01-560-1921 | SEAL GUIDE | 9276 |
| 5120-01-560-1911 | SHAFT SEAL DRIVER | 9277 |
| 5120-01-560-1910 | SEAL DRIVER | 9278 |

| | | |
|------------------|--|------|
| 5120-01-560-1916 | SEAL DRIVER | 9279 |
| 5120-01-560-1914 | SEAL DRIVER | 9280 |
| 5120-00-215-8200 | ADAPTER TORQUE | 9282 |
| 5120-00-566-0617 | JACK ASSEMBLY | 9284 |
| 1015-01-203-3342 | ALIGNMENT TOOL | 9285 |
| 5120-00-221-1889 | MANIFOLD ACCUM | 9287 |
| 5120-00-472-9938 | ADAPTOR ACCUMULATOR | 9288 |
| 2530-01-355-3091 | M SUSPENSION | 9290 |
| 2590-00-678-6775 | SHAFT | 9297 |
| 5120-01-115-1895 | OIL SEAL INSTALLER | 9299 |
| 5120-00-184-8381 | CROWFEET WRENCH | 9300 |
| 1015-01-176-8762 | BLOCK | 9302 |
| 5120-00-557-3615 | PULLER SLIDE | 9308 |
| 5420-01-030-5815 | WRENCH BAY DRIVE PIN | 9309 |
| 5120-00-224-3153 | BOX WRENCH | 9310 |
| 5120-00-277-6471 | WRENCH | 9311 |
| 5120-00-931-9096 | WRENCH | 9312 |
| 5120-00-184-8677 | WRENCH | 9313 |
| 5120-01-281-6430 | JACK ASSEMBLY | 9314 |
| 4933-01-033-1503 | COMBO TOOL | 9315 |
| 5120-01-539-5599 | SPANNER WRENCH | 9316 |
| 5340-01-559-9008 | COMPRESSION TOOL | 9317 |
| 2590-01-559-6892 | LIFT BRACKET ASSY | 9318 |
| 5120-00-494-1911 | LOCKING PLIERS | 9319 |
| 5120-01-407-8044 | BAR BREECH CAP TOOL | 9321 |
| 5120-01-044-5870 | WRENCH SPANNER | 9322 |
| 5120-01-304-2258 | AIRSEAL INSTALLER | 9323 |
| 5120-01-429-3662 | SOCKET SET | 9326 |
| 5120-00-277-4243 | PLIER | 9327 |
| 5120-00-277-8833 | SOCKET | 9328 |
| 5120-00-423-6728 | WRENCH | 9329 |
| 5120-00-494-1910 | PLIERS, FASTNER | 9330 |
| 5120-00-935-7487 | SOCKET WRENCH | 9332 |
| 5120-00-945-4704 | SOCKET | 9333 |
| 5120-00-965-0604 | PLIERS, FASTNER | 9334 |
| 5120-01-386-5988 | WRENCH, BODY | 9337 |
| 5120-01-386-5999 | WRENCH, BODY | 9338 |
| 1025-01-557-2544 | TOOL, OBTURATOR REMOVAL | 9339 |
| 4820-01-558-4362 | SET, JACKING | 9341 |
| 5120-00-277-6470 | WRENCH, ADJUSTABLE PIN | 9342 |
| 5120-00-287-2512 | (Please Inquire) | 9343 |
| 5340-00-820-3193 | (Please Inquire) | 9345 |
| 5120-01-343-1859 | SPANNER WRENCH | 9346 |
| 5306-01-462-2190 | BOLT | 9347 |
| 5120-01-286-0460 | WRENCH, SPANNER | 9348 |
| 5120-01-573-1081 | WRENCH, SOCKET | 9350 |
| 5120-00-676-0556 | TOWBAR? | 9354 |
| 5120-00-510-4855 | (Please Inquire) | 9356 |
| 5340-01-555-9109 | (Please Inquire) | 9357 |
| 5120-01-495-2895 | (Please Inquire) | 9358 |
| 5210-01-266-1112 | (Please Inquire) | 9359 |
| 2590-00-420-8929 | BRACKET | 9360 |
| 4820-01-179-4869 | BLOCK VALVE GUAGE | 9362 |
| 1440-01-217-6856 | CAP, DUST | 9363 |
| 5130-01-366-0376 | socket wrench | 9365 |
| CTM-9366 | T-Handle Nut Driver (KENT MOORE J-28424) | 9366 |
| 5120-01-117-3604 | (Please Inquire) | 9367 |
| 5120-01-522-0776 | WRENCH, FIRING PIN 120MM MORTAR | 9368 |
| 4910-00-251-8013 | JACK STAND | 9369 |
| 5120-01-126-8637 | HANDLE, RELEASE-HOLD | 9370 |
| 5120-01-360-8508 | WRENCH | 9373 |
| 5120-01-390-6739 | WRENCH, BOX | 9374 |
| 5120-01-115-9810 | WRENCH, SPANNER | 9375 |
| 4925-01-007-4175 | TOOL, DISP DOWNLOADING | 9376 |
| 5120-00-784-2883 | EXPANDER-ROD, HORIZONTAL STABILIZER | 9377 |
| 5120-00-394-5864 | (Please Inquire) | 9378 |
| 5210-01-229-1617 | CASE, CARRYING | 9379 |
| 5210-01-266-1205 | GAGE, HANDLE | 9381 |
| 5120-00-310-4668 | HANDLE, SLIDE HAMMER | 9382 |
| 5120-00-288-7783 | TUNING WAND, ELECTRIC | 9383 |
| 5120-00-509-2965 | PULLER, MECHANICAL | 9384 |
| 5120-01-175-7134 | WRENCH, SPANNER | 9385 |
| 5120-01-415-8266 | SPANNER TOOL | 9386 |
| 5120-01-132-0882 | SLEEVE | 9387 |
| 5120-01-387-0561 | TOOL, UNDERBEAD, CHAM | 9388 |
| 5365-01-121-1569 | RING | 9389 |
| 5120-01-286-0456 | WRENCH, SPANNER | 9390 |
| 5120-01-581-4601 | PGK WRENCH | 9391 |
| 5120-00-422-3325 | REMOVER SEAL | 9392 |
| 5120-01-035-7076 | WRENCH, INPUT BEVEL GEAR | 9393 |
| 5120-01-442-2312 | SPANNER, RING, BREECH MECH | 9394 |
| 3120-01-563-1630 | COLLAR | 9395 |
| 5120-01-387-0562 | TOOL, UNDERBEAD | 9396 |
| 2540-01-542-3026 | TOW EYE | 9397 |
| 5210-00-346-8327 | ROD, MEASURING | 9398 |
| 5120-00-991-1907 | WISE, MULTI POSITION | 9399 |
| 5210-01-546-6618 | MOUNTED CIRCULAR LEVEL | 9400 |
| 5210-00-863-5651 | GAGE | 9401 |
| 5210-00-346-8332 | ROD, INSERT | 9402 |
| 5210-00-346-8327 | INSERT, ROD | 9403 |
| 5120-01-516-0409 | drawing in ctm server, no ctm file | 9404 |
| 5120-00-335-7345 | drawing in ctm server, no ctm file | 9405 |
| 5120-01-319-7131 | PLUG ASSEMBLY, BORESCOPE | 9406 |
| 5120-00-624-0556 | drawing in ctm server, no ctm file | 9407 |
| 5120-01-498-5921 | drawing in ctm server, no ctm file | 9408 |
| 5220-01-373-4613 | drawing in ctm server, no ctm file | 9409 |
| 5120-00-557-8171 | drawing in ctm server, no ctm file | 9410 |
| 5120-00-847-8416 | drawing in ctm server, no ctm file | 9411 |
| 5120-01-391-1137 | drawing in ctm server, no ctm file | 9412 |
| 5120-00-631-8969 | drawing in ctm server, no ctm file | 9413 |
| 5120-01-319-7130 | INSERTER AND REMOVER | 9414 |
| 5120-01-220-3712 | drawing in ctm server, no ctm file | 9415 |
| 5120-01-306-2176 | drawing in ctm server, no ctm file | 9416 |
| 5120-01-135-3287 | drawing in ctm server, no ctm file | 9417 |
| 5120-00-871-7198 | drawing in ctm server, no ctm file | 9418 |
| 5120-00-570-7486 | drawing in ctm server, no ctm file | 9419 |
| 5120-01-437-0480 | drawing in ctm server, no ctm file | 9420 |
| 5120-01-039-2571 | drawing in ctm server, no ctm file | 9421 |
| 5120-01-315-9971 | drawing in ctm server, no ctm file | 9422 |
| 3040-01-120-0713 | SHAFT, INTERLOCK FITTING | 9423 |
| 5120-00-150-7828 | drawing in ctm server, no ctm file | 9424 |
| 5120-01-045-6881 | drawing in ctm server, no ctm file | 9425 |
| 1005-01-128-5465 | POST, FRONT SIGHT | 9426 |
| 5120-00-886-1519 | drawing in ctm server, no ctm file | 9427 |
| 5120-01-097-6815 | drawing in ctm server, no ctm file | 9428 |
| 5120-00-473-7716 | drawing in ctm server, no ctm file | 9429 |

| | | |
|---------------------------|--|------|
| 1560-00-966-3263 | GUIDE BLOCK, STRUT DOOR | 9430 |
| 4933-00-275-5784 | KNOB-HOLD BACK TOOL | 9431 |
| 4933-00-473-7744 | WRENCH, SPANNER | 9432 |
| 5120-00-616-9841 | WRENCH, SPANNER | 9433 |
| 5120-06R-2808K | NO DESC, JUST HAND DRAWING IN FILE | 9434 |
| 5120-01-117-3604 | WRENCH, RATCHET 14MM | 9435 |
| 5120-01-160-8866 | HANDLE, HYDRAULIC JACK | 9436 |
| 5120-01-329-4860 | CANNON BORE EROSION GAGE | 9437 |
| 5120-00-157-1073 | PULLER, SHAFT SLEEVE | 9438 |
| 3120-01-476-6526 | BEARING, SLEEVE | 9439 |
| 5365-01-205-9246 | SPACER, PLATE | 9440 |
| 1015-00-133-9581 | VALVE BODY ASSY | 9441 |
| 5365-01-528-2764 | BUSHING SLEEVE | 9443 |
| 5220-01-591-7907 | GAGE, PROFILE | 9444 |
| 4910-01-591-5504 | LIFTER, ROAD WHEEL | 9445 |
| 5310-01-118-0770 | NUT, PLAIN, HEXAGON | 9446 |
| 4910-01-124-9299 | LIFTING ASSEMBLY | 9447 |
| 5365-01-472-4811 | SPACER, SLEEVE | 9448 |
| 5120-01-562-1077 | WRENCH, SPANNER | 9449 |
| 3120-01-342-6682 | BUSHING, SLEEVE | 9450 |
| 2530-00-678-6128 | PLATE, WEAR, BRAKE, SH | 9451 |
| 1730-01-042-6440 | BEAM, SUSPENSION, POD | 9452 |
| 5365-01-262-9068 | SPACER, SLEEVE | 9453 |
| 1730-01-009-0396 | JACK ASSEMBLY, STRUCTURE | 9454 |
| 5365-01-596-5183 | SPACER, RING | 9455 |
| 5120-00-771-7020 | REMOVER AND REPLACE TOOL | 9456 |
| 5365-01-596-5615 | SPACER, STRAIGHT | 9457 |
| 5120-01-567-4333 | EXTENSION, SEAT LAPPING TOOL | 9458 |
| 3120-01-527-8506 | BUSHING, BREECHCOLLAR | 9459 |
| 5120-01-516-0419 | PUSHER, BEARING TOOL | 9460 |
| 5120-01-206-0804 | DRIVER, BEARING | 9461 |
| 5120-01-343-1857 | SPANNER, WRENCH MUZZLE BRAKE | 9462 |
| 5120-01-345-1296 | WRENCH, SPANNER | 9463 |
| 5120-01-052-0296 | TOOL ASSEMBLY, REMOV | 9464 |
| 5365-01-058-7389 | SPACER SLEEVE | 9465 |
| 5120-01-198-0054 | TOOL, SPECIAL CABLE | 9466 |
| 3120-00-493-9192 | BUSHING SLEEVE | 9467 |
| 5365-00-740-9784 | SPACER, SLEEVE | 9468 |
| 2835-01-078-2089 | WRENCH SET, MANIFOLD | 9469 |
| 3040-01-291-8240 | LEVER, REMOTE CONTROL | 9470 |
| 2530-01-598-1728 | CONNECTOR, PIN END, TRACK | 9471 |
| 2530-01-587-6759 | WEDGE, TRACK | 9472 |
| 1005-01-388-7006 | SLIDER, MOUNT MACHINE | 9473 |
| 1005-01-388-5697 | SLIDER, MOUNT MACHINE | 9474 |
| 2530-01-587-6761 | GUIDE CHAIN VEHICLE | 9475 |
| 2530-01-587-6760 | CAP, GUIDE TRACK | 9476 |
| 5120-00-473-7352 | REMOVER ASSY | 9477 |
| 2590-01-136-4807 | DOG BONE | 9478 |
| 5120-00-386-6567 | SOCKET, SOCKET WRENCH | 9480 |
| 5220-00-373-1527 | GAGE, TRANSMISSION | 9481 |
| 5120-01-115-3131 | INSERTER, BEARING | 9482 |
| 5120-01-017-5328 | ADAPTER, TORSION BAR | 9483 |
| 5120-00-590-8828 | KEY, SOCKET HEAD SCREW | 9484 |
| 4910-01-519-3355 | MAINT FIXTURE | 9485 |
| 4910-01-118-7711 | LIFTER, ROAD WHEEL | 9486 |
| 5120-01-204-8715 | INSERTER, SEAL | 9487 |
| 5220-01-441-4158 | GAGE, PROFILE | 9488 |
| 5220-01-496-3692 | GAGE, TRACK WEAR | 9489 |
| 2590-00-148-7961 | CABLE KIT, SPECIAL P | 9490 |
| 5120-01-202-1297 | EXTENSION, LAPPING | 9491 |
| 5120-01-202-1296 | HANDLE, LAPPING TOOL | 9492 |
| 5220-00-731-4899 | GAGE, HEADSPACE | 9493 |
| 5120-00-224-3154 | BOX WRENCH | 9494 |
| 5120-00-224-3154 | BOX WRENCH | 9495 |
| LP368390 | STRAINER | 9496 |
| LP274184 | GUARD-FLYWHEEL | 9497 |
| LP360219 | GUARD | 9498 |
| LP32A61-03113 | CLAMP | 9499 |
| LP344648 | SPACER | 9500 |
| 275112 | CONN ROD, LONG | 9501 |
| 292265 | CONN ROD, SHORT | 9502 |
| LP370740 | ASSY-FLYWHEEL | 9503 |
| LP373660 | ASSY-FLYWHEEL | 9504 |
| LP344828 | COLLAR | 9505 |
| LP751-11322 | BUSHING | 9506 |
| 5180-00-936-4376 | (ctm # reassigned 5180-00-611-7945) | 9507 |
| 5120-01-543-0172 | WRENCH | 9508 |
| 3040-01-111-1557 | WRENCH, FUEL VALVE | 9509 |
| 5120-00-293-0013 SOCKET 9 | 3 9/32 TAK SOCKET | 9510 |
| 5120-01-202-1297 | (Please Inquire) | 9512 |
| 5120-01-274-0785 | LEVELING JACK | 9513 |
| 5120-01-327-5161 | (Please Inquire) | 9514 |
| 5120-01-202-1296 | (Please Inquire) | 9515 |
| 5220-01-479-9705 | GAGE, SNAP, FIXED | 9516 |
| 5220-01-226-4064 | GAGE, GO, NO-GO | 9517 |
| 5120-01-477-2319 | WRENCH, OPEN END | 9518 |
| 5120-01-102-6193 | TOOTH | 9519 |
| 5220-01-259-9099 | PULLOVER GAGE (CANNON BORE) | 9520 |
| 3040-01-249-3327 | SHAFT AND BEARING | 9521 |
| 5120-00-073-5674 | PILOT | 9522 |
| 5120-00-109-4568 | INSTALLING TOOL | 9523 |
| 5120-00-115-3315 | ADAPTER, TORQUE, 437 HEX NUT FUEL PUMP | 9524 |
| 1095-00-726-6835 | BODY ASSEMBLY, BARREL | 9525 |
| 5120-01-601-0377 | NRP, TOOL, REMOVAL, BR | 9526 |
| 5120-01-167-7455 | TOOL, INSTALLATION | 9527 |
| 5120-01-545-3354 | INSERTER & REMOVAL TOOL | 9528 |
| 3040-01-531-1671 | SHAFT ASSY, CURVED | 9529 |
| 3040-00-133-8069 | SHAFT ASSY | 9530 |
| 1005-01-587-6326 | FORE GRIP | 9531 |
| 5340-01-587-1877 | BRACKET, MOUNTING | 9532 |
| 5340-01-587-6329 | BRACKET, MOUNTING | 9533 |
| 5305-01-587-6325 | SCREW, CAP, SOCKET | 9534 |
| 1025-01-530-5873 | EXTRACTION TOOL, PRIMER | 9535 |
| 1010-01-605-7322 | KIT, LOCKING ASSY | 9536 |
| 1005-00-514-0216 | SLEEVE, SLIDING | 9537 |
| 1095-00-726-6835 | BODY ASSY BARREL BUFFER | 9538 |
| 1005-01-204-4340 | BLOCK, LOCKING, BARREL | 9539 |
| 1005-00-556-4102 | ROD, CLEANING, SMALL | 9540 |
| 5120-01-102-6193 | TOOTH | 9541 |
| 5120-01-562-4386 | SPANNER ATTACHMENT | 9542 |
| 3120-00-011-6622 | BEARING, PLAIN, ROD END | 9543 |
| 3120-01-487-0061 | BEARING SLEEVE | 9544 |
| 3120-01-079-2965 | BEARING SLEEVE | 9545 |
| 4910-01-414-3184 | LIFTER, ROAD WHEEL | 9546 |
| 4920-00-038-0496 | PROTECTOR, COMPRESSOR | 9547 |
| 4920-00-106-7587 | (Please Inquire) | 9548 |

| | | |
|------------------|--------------------------------|------|
| 5120-21-807-6460 | CROWFOOT SOCKET WRENCH | 9549 |
| 5120-01-434-4189 | INSTALLATION TOOL | 9550 |
| 5210-01-388-3740 | BLOCK, DEPTH SETTING, DRILL | 9551 |
| 5120-01-146-8247 | INSTALLER, BEARING | 9552 |
| 5120-01-029-4868 | TOOL, WRENCH | 9553 |
| 1010-01-151-6227 | MECH ASSY, ELEVATING | 9554 |
| 5120-01-333-2394 | GUIDE, DRILL | 9556 |
| 5120-01-537-2582 | WRENCH, FIRING MECH | 9557 |
| 5120-01-367-2954 | PULLER ATTACH MECH | 9558 |
| 50-004-1492TM | DRIVE HUB (ESKRIDGE) | 9559 |
| 4920-01-017-4486 | INSTALLATION ASSY | 9560 |
| 5120-01-567-7303 | INSERTER, SEAL | 9562 |
| 5310-01-137-5736 | NUT, SELF LOCKING | 9563 |
| 8290158 | FILL ADAPTER TOOL, COLD GAS | 9565 |
| 8290160 | FILL VALVE TOOL, COLD GAS | 9566 |
| 1005-01-536-7961 | TOOL, LOADING | 9567 |
| 5325-01-300-0091 | RETAINER, THREADED UPPER | 9568 |
| 3120-00-787-9829 | BEARING, PLAIN, ROD END | 9569 |
| 3020-01-461-7719 | GEARSHAFT | 9570 |
| 1005-01-185-3838 | CONVEYOR ELEMENT AMMO | 9571 |
| 5120-00-595-8996 | WRENCH, SPANNER | 9572 |
| 5120-01-442-2311 | WRENCH, SPANNER | 9573 |
| 5120-01-465-3963 | INSERTER & REMOVAL TOOL | 9574 |
| 5120-01-630-4324 | DRIFT, PIN | 9575 |
| 5120-01-559-6486 | KEY, SOCKET HEAD SCREW | 9576 |
| 5120-01-578-6476 | INSERTER AND REMOVER, SEAL | 9577 |
| 5120-01-485-1643 | ADAPTER, MECHAINICAL | 9578 |
| 5120-01-602-1125 | WRENCH, OPEN END | 9579 |
| 5120-01-163-4820 | INSTALLER, BEARING AND BUSHING | 9580 |
| 5120-01-171-4648 | EXTRACTOR, SHAFT | 9581 |
| 5120-01-163-4825 | INSERTER, BEARING AND BUSHING | 9582 |
| 5120-01-185-0209 | INSERTER, BEARING AND BUSHING | 9583 |
| 5120-01-187-3627 | INSTALLATION KIT, SCREW THREAD | 9584 |
| 5120-01-577-8376 | WRENCHM SPANNER | 9585 |
| 5120-01-163-4837 | INSTALLER, CUP | 9586 |
| 5120-01-630-2456 | WRENCH, SPANNER | 9587 |
| 5120-01-629-9286 | INSERTER, BEARING AND BUSHING | 9588 |
| 5120-00-624-7944 | EXPANDER, PROPELLER | 9589 |